

# User Guide

# User Guide

---

## 1 Welcome

Your K355 is packaged with the following state of the art features:

- VGA Camera
- 2.4 Inch screen
- Audio Player
- FM Radio
- King Movie
- Video and FM Recording
- Dual SIM (GSM + GSM)
- T-Flash Card support (up to 8 GB)
- Hindi Language Support
- Bluetooth

### **Important:**

1. Please read the contents of this manual to fully utilize the features of this phone.
2. Please read the Guidelines section provided with this Reference guide.

# User Guide

---

## Table of Contents

<b>1</b>	<b>Welcome .....</b>	<b>1</b>
<b>2</b>	<b>Know Your Phone.....</b>	<b>5</b>
2.1	Keys and Parts	5
2.2	Insert SIM Card	5
2.3	Keys and Parts	6
2.2	Insert Sim Card	6
2.3	Insert Memory Card	6
<b>3</b>	<b>Basic Operations .....</b>	<b>6</b>
3.1	Switch Phone ON/OFF	6
3.2	Unlock the phone	7
3.3	Make a call	7
<b>4</b>	<b>Notable Features.....</b>	<b>7</b>
4.1	Secure your Phone	7
4.2	Blacklist	8
<b>5</b>	<b>Call History .....</b>	<b>8</b>
5.1	Call History	8
<b>6</b>	<b>Phone book .....</b>	<b>9</b>
6.1	Create Contact	9
6.2	SMS	9
6.3	Call	9
6.4	Delete	9
6.5	Delete multiple	9
6.6	Move contacts	9
6.7	Add to Blocklist	10
6.8	Add to Whitelist	10

# User Guide

---

6.9	Import/Export Contacts	10
6.10	Send vCard	10
6.11	Others	10
6.12	Most used	11
6.13	Groups	11
<b>7</b>	<b>Audio player .....</b>	<b>11</b>
<b>8</b>	<b>Camera .....</b>	<b>11</b>
<b>9</b>	<b>Messages .....</b>	<b>12</b>
9.1	Write message	12
9.2	Use message Templates	12
9.3	Voice mail server	12
9.4	Settings	13
9.5	Message capacity	13
<b>10</b>	<b>Multimedia .....</b>	<b>13</b>
10.1	Video Recorder	13
10.2	Video Player	13
10.3	FM Radio	14
10.4	Images viewer	14
10.5	Sound Recorder	15
<b>11</b>	<b>File Manager.....</b>	<b>15</b>
11.1	File Manager	15
<b>12</b>	<b>Game.....</b>	<b>15</b>
12.1	Bubble Bash 2	15
12.2	Ninja Up	15
12.3	Sky Gift	15
12.4	Danger Dash	16
12.5	Sokoban	16
12.6	Snake	16

# User Guide

---

12.7 Tetris	16
<b>13 Organizer</b> .....	<b>16</b>
13.1 Bluetooth	16
13.2 Calendar	16
13.3 Alarm	17
13.4 World Clock	17
13.5 Torch	17
13.6 Calculator	17
13.7 Unit Converter	17
13.8 Stopwatch	17
13.9 Clock	18
13.10 Folder Lock	18
13.11 SIM toolkit	18
<b>14 Settings</b> .....	<b>18</b>
<b>15 Services</b> .....	<b>19</b>
15.1 Internet	19
<b>16 User Profile</b> .....	<b>19</b>
<b>17 Health and Safety Precautions</b> .....	<b>19</b>
<b>18 Taking Care of Your Device</b> .....	<b>21</b>
<b>19 FCC Caution</b> .....	<b>25</b>

## 2 Know Your Phone

### 2.1 Keys and Parts

Important keys and parts are listed here for you to use the phone better.

1. Left Key		2. Right Key		3. Dial Key
4. End Key		5. Navigation Key		6. Ok Key
7. Keypad		8. Receiver		9. Loud
10. Hands-free		11. USB Socket		12. Speaker
13. Camera Lens				

### 2.2 Insert SIM Card

The K355 is a Dual SIM mobile phone allowing you to use two SIM Cards.

1. Switch off the mobile phone and remove the rear insert SIM Card

# User Guide

---

## 2.3 Keys and Parts

### 2.2 Insert Sim Card

1. Switch off the phone and remove the rear cover and the battery.
2. Insert the Sim card into the slot.
3. Finally, insert the battery and the rear cover of the mobile phone.

### 2.3 Insert Memory Card

1. Switch off the phone and remove the rear cover and the battery.
2. Insert the memory card into the slot.
3. Finally, insert the battery and the rear cover of the mobile phone.

Note: Use only compatible memory cards approved by k355. Incompatible cards may damage the slot or corrupt the data stored in the card.

## 3 Basic Operations

### 3.1 Switch Phone ON/OFF

To switch ON/OFF your phone, press and hold the **End key** for a few seconds.

# User Guide

---

## 3.2 Unlock the phone

If you do not use the phone for a while, the screen is replaced with a locked screen.

1. Press any key to activate the screen.
2. Press **Left** key, and then press \* key.

## 3.3 Make a call

You can make a call in the following ways:

- Enter the desired number in standby mode and press the **Call key** to make the call.
- Go to **Menu > Phonebook** and then select and dial the desired number.
- Just press the **Call key** to dial the contacts listed in Call logs.
- You can also dial a contact from the messages.

# 4 Notable Features

## 4.1 Secure your Phone

**Menu>Organizer > Folder Lock > Phone Locked**



# User Guide

---

Let you lock/unlock your phone via a security password which you can change anytime.

The default security code to unlock the phone is **1234**.

Note: After you activate the phone lock, you would be asked for a password when you power on your phone next time.

## 4.2 Blacklist

**Menu > Settings > Security > Blacklist**

Blacklist undesired SMS senders and caller so that you do not receive SMS and calling from them.

# 5 Call History

## 5.1 Call History

**Menu > Call History**

Tip: Directly access the call logs of by pressing the **Call** key in idle mode.

The Call log lists the calls you have recently dialed, received, missed for SIM1 and SIM 2.

Press the Left/right navigation keys to access various call logs and work on the call history.

## 6 Phone book

Your phonebook stores all your saved contacts for anytime use. Your phonebook data can be stored in your SIM card or your phone memory. You can manage your contacts from here.

**Menu > Phone book**

### 6.1 Create Contact

**Menu > Contacts > Left Key > New**

### 6.2 SMS

**Menu > Contacts > Left Key>SMS**

### 6.3 Call

**Menu > Contacts > Left Key>Call**

### 6.4 Delete

**Menu > Contacts > Left Key>Delete**

### 6.5 Delete multiple

**Menu > Contacts > Left Key> Delete multiple**

In the Contacts list, select the entry you want to delete.

### 6.6 Move contacts

**Menu > Contacts > Left Key > Move**

# User Guide

---

In the Contacts list, select the entry you want to move.

## 6.7 Add to Blocklist

**Menu > Contacts > Left Key > Add to Blocklist**

Blacklist undesired SMS senders and caller so that you do not receive SMS and calling from them.

## 6.8 Add to Whitelist

## 6.9 Import/Export Contacts

**Menu > Contacts > Left Key > Import/Export**

You can copy, Import or Export contacts entries stored in the SIM card to the phone memory and vice-versa.

## 6.10 Send vCard

**Menu > Contacts > Left Key > Send vCard**

## 6.11 Others

**Speed dial**

**Menu > Contacts > Left Key > Others > Speed dial**

Set speed dial and view memory status.

**Memory status**

**Menu > Contacts > Left Key > contact settings Others > Memory status**

# User Guide

---

Check the memory status of SIM, and Phone.

## 6.12 Most used

**Menu > Contacts > Most used**

View the contacts that most used.

## 6.13 Groups

**Menu > Contacts > Groups**

Press the Left/Right navigation key to access the Group tab. Set up a list of numbers with similar preferences such as ringtone, profile etc.

## 7 Audio player

The phone comes with an inbuilt audio player that plays all your favorite songs stored in the phone memory or memory card.

- While in music mode, press the Left key to choose various music options
- **Adjust Volume:** Press \* and # keys to adjust volume

## 8 Camera

Press the left key in camera mode to choose various settings

Shortcut keys: Press the number keys on the phone's keypad to choose various settings.

## 9 Messages

### 9.1 Write message

**Menu > Messages > Write message > New SMS**

You can compose and send SMS . Pressing the **Left Key** during/after composing the message gives you a host of messaging features.

### 9.2 Use message Templates

**Menu > Messages > Templates**

Enter into preset message templates and use them. These preset templates can save you time if the theme of your message is the same as those existing in the template.

### 9.3 Voice mail server

**Menu > Messages > Voice mail server**

You can activate voicemail service to redirect your incoming calls (based on your call settings) to a voicemail server and retrieve them later via SMS alerts.

To divert incoming calls to a voicemail server, go to Settings>Phone tab >

# User Guide

---

Call Divert> Voice> (choose the desired call divert condition)> Activate> Phone Number/Voicemail Number.

## 9.4 Settings

**Menu > Messages > Options>Settings**

You can set your desired parameters for SMS, push message and Others.

## 9.5 Message capacity

**Menu > Messages >Options> Message capacity**

View the memory status of your SMS .

# 10 Multimedia

## 10.1 Video Recorder

**Menu > Multimedia > Video Recorder**

Press the left key in camera mode to choose various settings

Shortcut keys: Press the number keys on the phone's keypad to choose various settings.

## 10.2 Video Player

**Menu > Multimedia > Video Player**

Let you play videos stored in your phone or memory card.

# User Guide

---

Press 2 key while playing a video to change the display mode.

## 10.3 FM Radio

**Menu > Multimedia > FM radio**

Your phone comes with an FM radio to let you listen to FM channels.

- Go to Options> Search Channels> Auto Search to fill up the channels.
- Press the number keys on your keypad in accordance to the channel list.
- Press OK key to start/stop the radio.
- Press the Up or Down key to increase/decrease the volume.
- Press the Left key for various radio options.

## 10.4 Images viewer

**Menu > Multimedia > Images viewer**

Let you to view your saved images. You can also send the images via MMS or Bluetooth or use it as contact icon or wallpaper, etc.

# User Guide

---

## 10.5 Sound Recorder

**Menu > Multimedia > Sound recorder**

You can record surrounding sounds using this feature.

## 11 File Manager

### 11.1 File Manager

**Menu > File Manager**

To manage the space of phone or memory card.

## 12 Game

### 12.1 Bubble Bash 2

**Menu >Game>Bubble Bash 2**

### 12.2 Ninja Up

**Menu >Game>Ninja Up**

### 12.3 Sky Gift

**Menu >Game>Sky Gift**



## User Guide

---

### 12.4 Danger Dash

Menu >Games>Danger Dash

### 12.5 Sokoban

Menu >Games>Danger Dash

### 12.6 Snake

Menu >Games> Snake

T Your devices is supported Snake to take your free time.

### 12.7 Tetris

Menu >Games> Tetris

## 13 Organizer

### 13.1 Bluetooth

Menu > Organizer > bluetooth

### 13.2 Calendar

Menu > Organizer >calendar

# User Guide

---

To arrange your journey according to calendar.

## **13.3 Alarm**

Menu > Organizer > **Alarm**

To use the alarm service available with your mobile phone.

## **13.4 World Clock**

Menu > Organizer > **World Clock**

## **13.5 Torch**

Menu > Organizer > **Torch**

To turn on/off FlashLight.

## **13.6 Calculator**

Menu > Organizer > **Calculator**

To provide a calculator with 4 basic functions to facilitate simple calculations.

## **13.7 Unit Converter**

## **13.8 Stopwatch**

Menu > Organizer > **Stopwatch**

# User Guide

---

## 13.9 Clock

Menu >Organizer>Clock

Set up time, time will have ring tone hint

## 13.10 Folder Lock

Menu >Organizer >Folder Lock

## 13.11 SIM toolkit

Menu > Organizer> SIM tool kit

# 14 Settings

Choose various preferences to customize your handset according to your requirements. You can set:

- Phone Settings
- Display
- Security
- Call settings

# User Guide

---

- Connections

## 15 Services

### 15.1 Internet

Menu > Services>Internet

## 16 User Profile

Menu > User Profile

## 17 Health and Safety Precautions

Please read these simple guidelines. Not following them may be dangerous or illegal.

### SAR Compliance

- Your phone is designed not to exceed the limits of emission of radio waves recommended by international guidelines.
- SAR (specific absorption rate) is the measurement of body-absorbed RF quantity when the phone is in use. SAR value is ascertained according to the highest RF level generated during laboratory tests.
- The SAR value of the phone may depend on factors such as proximity to the network tower, use of accessories or other accessories.

# User Guide

---

## SAR Recommendations

- Use a wireless hands-free system (headphone, headset) with a low power Bluetooth emitter.
- Please keep your calls short and use SMS whenever more convenient. This advice applies especially to children, adolescents and pregnant women
- Prefer to use your cell phone when the signal quality is good.
- Maintain a preferable distance of 5 mm from the device.

## Safe Driving

- Do not use the phone while driving. When you have to use the phone, please use the personal hands-free kit.
- Please do not put the phone onto any passenger seat or any place from which it may fall down in case of vehicular collision or emergency braking.

## During Flight

- Flight is influenced by interference caused by the phone. It is illegal to use a phone on the airplane. Please turn off your phone during a flight.

## In Hospitals

- Your Phone's radio waves may interfere with the functioning of inadequately shielded medical devices. Consult a physician or the manufacturer of the medical device to determine whether they are

# User Guide

---

adequately shielded from external Radio Frequency. Switch off your device when regulations posted instruct you to do so.

- To avoid potential interference with implanted medical devices such as a pacemaker or cardioverter defibrillator:
- Always keep your phone at least 15.3 centimeters (6 inches) from the medical device.
- Do not carry the wireless device in a breast pocket.
- Turn off the phone if there is any reason to suspect that interference is taking place.
- Follow the manufacturer directions for the implanted medical device.
- If you have any questions about using your wireless device with an implanted medical device, consult your health care provider.

## Unsafe Areas

- Please turn off your phone when you are close to a gas station or in the vicinity of any place where fuel and chemical preparations, or any other dangerous goods are stored.

## 18 Taking Care of Your Device

Your device is a product of superior design and craftsmanship and should be handled with care: The following suggestions will help you protect your phone:

# User Guide

---

- Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that will rust electronic circuits. If your device does get wet, remove the battery without turning on the device, wipe it with a dry cloth and take it to the service center.
- Do not store the device in high or cold temperature. High temperatures can shorten the life of electronic devices and damage batteries.
- Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can be damaged.
- Do not attempt to open the device other than as instructed in this guide. Repairing this phone by yourself other than our authorized service agents/centers goes against the warranty rules.
- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device. Only use a soft, clean, dry cloth to clean the surface of the device.
- Do not store your device near magnetic fields or allow your device to come in contact with magnetic fields for extended period of time.

## **Battery Recommendations:**

- Please put the battery in a cool and well-ventilated place out of direct sunlight. We recommend you to charge the battery at room temperature range.

## User Guide

---

- Batteries have life cycles. If the time that the battery powers equipment becomes much shorter than usual, the battery life is at an end. Replace the battery with a new battery of the same make and specification.
- Do not discard the battery with household trash. Please dispose of used battery according to your local environmental laws and guidelines.
- Use manufacturer approved batteries, chargers, accessories and supplies. K355 will not be held responsible for user's safety when using unapproved accessories or supplies.

### Recycle Your Handset



The WEEE logo (shown at the left) appears on the product (battery, handset, and charger) to indicate that this product must not be disposed off or dumped with your other household wastes. You are liable to dispose of all your electronic or electrical waste equipment by relocating over to the specified collection point for recycling. of such hazardous waste.



# User Guide

---

Specified collection points for recycling of such hazardous waste. Collection and proper recovery of your electronic waste equipments at the time of disposal will allow us to help preserve the environment. Recycling of the electronic waste equipment will ensure safety of human health and environment. For more information on best practices for disposal of electronic and electrical waste, please visit to our web site: [www.micromaxinfo.com/weee.php](http://www.micromaxinfo.com/weee.php).

## Disclaimers

1. The colors and specifications shown/mentioned in the user manual may differ from the actual product. Images shown are for representation purpose only. Other product logos and company names mentioned herein may be trademarks or trade names of their respective owners.
2. KKT Ultra keeps the right to make modifications to any of the content in this user guide without public announcement in advance. The content of this manual may vary from the actual content displayed in the mobile phone. In such a case, the latter shall govern.

## Copyrights

All rights reserved. Reproduction, transfer, distribution or storage of part or all of the contents in this document in any form without the prior written permission of K355 is strictly prohibited.

# User Guide

---

## 19 FCC Caution

### **§ 15.19 Labeling requirements.**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### **§ 15.21 Information to user.**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### **§ 15.105 Information to the user.**

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

# User Guide

---

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## **Specific Absorption Rate (SAR) information:**

This mobile phone meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. FCC RF Exposure Information and Statement The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue.

## **Body-worn Operation**

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 0.5 cm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.