

Puts you in complete command of your arousal



Go to we-vibe.com for the complete user manual.

Electrical Rating

Model: Bond
 Model No.: NLS2A
 Power Input:
 5 V $\overline{=}$ 0.5 A;
 Built-in Lithium-Ion rechargeable battery.
 100-240 V $\overline{=}$ 50/60 Hz;
 When charged using USB.
 Charging device:
 USB AC adaptor (not included).
 Use original provided cable only.

Environmental Protection

As a distributor of electronic devices, we are legally obliged to accept the return of waste electrical and electronic devices free of charge. We expressly state that you as the user are legally obliged to return used batteries.

Customer Care
 +1 613 828 6678
 1 855 258 6678
 (U.S. & Canada)
care@we-vibe.com
we-vibe.com

Never throw away electronic devices or batteries in the household waste. The symbol shown below (crossed-out wheeled bin) is intended to expressly remind you of this.

Manufactured and distributed by
 WOW Tech Canada Ltd.
 1545 Carling Avenue, Suite 401,
 Ottawa ON, Canada K1Z 8P9
www.wowtech.com

WOW Tech Canada Ltd. reserves the right to make technical changes and changes to the design that serve to improve the device.

For information regarding patents see we-vibe.com/patents.

Designed in Canada. Made in China.

Date of issue: 08/2021.



Bond

Pleasure to meet you



Quick start guide

Undercover Tease

Bond puts you in command of your pleasure. Featuring a world-first easy-on quick-release system for comfort and safety, it's the only male wearable that can be put on and worn as easily as your watch, so you can enjoy your anticipation and sexual energy discreetly, wherever, and whenever, you desire.

Contents

Page 01. Power on	Page 07. Pairing
Page 03. Cleaning	Page 09. We-Vibe remote
Page 04. How to use	Page 10. Safety and legal
Page 06. Charging	

Box contains: Bond, Custom Fit link, We-Vibe remote, charging cable, pouch, quick start guide, safety instructions

Getting to know your Bond

1 We-Vibe button

Press the We-Vibe button to switch your toy on. Press the button again to cycle through 10 different vibration patterns.

2 Magnetic charging pins

3 Easy-on quick-release system

To close the ring, simply link the two bands together. To remove, press the bands together, and unlink.


4 Custom Fit link

For a larger ring, insert the Custom Fit link between the two bands, and connect it at both ends.

5 We-Vibe remote

Keep control in the palm of your hand with Bond's compact remote.

- 1. Low
- 2. Medium
- 3. High
- 4. Ultra
- 5. Pulse
- 6. Wave
- 7. ChaCha
- 8. Tease
- 9. Tempo
- 10. Heartbeat



Step 1: clean

- Rinse Bond with warm water and a premium toy cleaner, and dry with a lint-free cloth.

waterproof (IPX7)

Step 2: enjoy

Thanks to the adjustable, easy-on quick-release system, the ring can be mounted erect or otherwise, and adjusted for a perfect fit. Wrap the silicone band around your penis and testicles together.

The Custom Fit link allows you to create a custom size, perfect for your body. Add or remove the link to suit you, until it's comfortably in place.

With the ring in place, no further lubrication or adjustment should be necessary. You're ready to start building your pleasure, and anticipation.

Please Note
Wear your wearable stimulation ring carefully. 30 minutes is the recommended duration, however it is at the user's discretion.

Step 3: charge

Enjoy up to 2 hours of play with every charge. When it's time for a recharge, place charger on magnetic pins. After 90 minutes, your toy is ready to go.




90 min



Step 4: pair

Bond comes paired to your We-Vibe remote out of the box.



Bond can only pair to one remote or app-enabled device at a time.

Same room play

To pair Bond to We-Connect, follow the in-app pairing instructions on your app-enabled device.

Press and hold the We-Vibe button for 5 seconds. Bond vibrates twice and the LED will start flashing. Bond is in pairing mode now.

Once paired, Bond will vibrate three times and the LED will stop flashing.




Long distance play

To play long distance, both you and your partner need the We-Connect app on your smartphones. Bond is then paired to the phone that remains within Bluetooth range.



After exiting the We-Connect app, press and hold the We-Vibe button on Bond for 5 seconds. Bond vibrates twice and the LED will start flashing. Hold the We-Vibe button on your We-Vibe remote for another 5 seconds.

Once paired, Bond will vibrate 3 times and LED will stop flashing.



Step 5: battery

To change the battery in your remote, simply pull off the bottom cap and lift the battery out. Replace it with a non-rechargeable CR2032 button cell battery.

