

VIZIO

3D BLU-RAY™ PLAYER  
WITH INTERNET APPS

MODEL VBR338



**QUICK START GUIDE**

FOR FULL USER MANUAL  
GO TO [VIZIO.COM/SUPPORT](http://VIZIO.COM/SUPPORT)



## BEFORE YOU BEGIN

This Blu-ray Player is designed to play high-definition audio and video using an HDMI cable. HDMI cables come in various lengths and are available for purchase from most retailers.



Before you set up your Blu-ray Player, make sure your TV has an available HDMI port. This port is usually found on the back or side of the TV.

## IMPORTANT SAFETY INFORMATION



You may experience discomfort while watching 3D content. You may feel symptoms of eye strain, vision fatigue, color or depth distortion, motion sickness, nausea, dizziness, disorientation, or other discomforts. If you experience any of these symptoms, stop watching and take a break for at least thirty minutes before resuming. If the symptoms are severe or continue even after you have stopped watching 3D content, consult a doctor.



Some viewers may be susceptible to epileptic seizures or strokes when viewing 3D images, even if those conditions have not been previously diagnosed. If you or anyone in your family has a history of seizures or strokes, or if you have any other reason to think you or someone under your supervision may be susceptible to epileptic seizures or strokes, consult a doctor before watching 3D content.



Take care to monitor children's watching of 3D content. Children (including teenagers) may be more at risk of experiencing discomfort while watching 3D content and less likely to report symptoms. Monitor children's 3D content viewing and watch for signs of discomfort.



Even if you do not experience any of the above symptoms, take regular breaks from watching 3D content.

# PACKAGE CONTENTS



3D Blu-ray Player



Remote with Batteries



HDMI Cable



This Quick Start Guide

HELP VIZIO REDUCE PAPER WASTE.

DOWNLOAD THE FULL USER MANUAL AT  
**VIZIO.COM/SUPPORT**



# FIRST-TIME SETUP

1




Remove the battery cover from the remote.  
Insert the batteries, matching the + and - symbols in the compartment with the + and - symbols on the batteries.  
Replace the cover.

2



Connect the power cord from the back of the Blu-ray Player to an electrical outlet.

3



Connect the included HDMI cable to the HDMI port on the back of the Blu-ray Player. Connect the other end of the HDMI cable to the HDMI port on your TV.

Your Blu-ray Player is ready to use.

4



When inserting a disc, hold the disc by the edges.  
Gently push the disc into the slot until the Player takes it.  
The Player will pull the disc in.

Never force a disc into the Player.



# GETTING TO KNOW YOUR PLAYER

## FRONT



### USB Port


Insert USB thumb drive to play photos and music. Supported files include .jpg and .mp3.

Disc Slot  
Insert disc here.

Eject Button  
Touch to eject disc.

Power Button  
Touch to turn Player on or off.

## BACK



Ethernet

HDMI


Digital  
Optical  
Audio Out

RCA Stereo  
Audio Out

Digital  
Coaxial  
Audio Out

Power Cord

# USING THE REMOTE



\*Supported discs only.

### IMPORTANT

Do not cover this area. This is the transmitter.



#### ARROW

Use to navigate on-screen menus.

#### ALT

Press and hold this key to enter a blue character.  
For example, press **ALT** and **W** to enter a **#** character.

#### SHIFT

Press and hold this key to enter a capital letter.

#### APP SHORTCUTS

Control Internet Apps and other disc functions. Press Red to exit apps.



When using the remote, point it at the right side of the player. The sensor is located there.





# SETTING UP YOUR NETWORK CONNECTION

To enjoy online content and streaming video, you must connect the Blu-ray Player to your home network. For the best online experience, you should have a high-speed internet connection (Minimum 1Mbps-higher is better).



- 1 Connect an Ethernet cable\* to the Ethernet port on the back of the Blu-ray Player.

Ethernet cables are available from many retailers in lengths up to 50 feet.

- 2 Connect the other end of the ethernet cable to the Ethernet port on your router or modem\*.

The next time you turn the Player on, the network connection will be automatically detected.



Router / Modem