


Home Theatre System

Operating Instructions	US
Guide de référence	FR
Manual de instrucciones	ES








F:\HT-XZ1-11 UC\4559030111\4559030111HTXT100UC\01US-

HTXT100UC\020REG.fm

010COV.book Page 2 Monday, August 18, 2014 3:50 PM



Owner's Record

The model and serial numbers are located on the rear panel of the unit. Record serial numbers in the space provided below. Refer to them whenever you call upon your Sony dealer regarding this product. Model No. HT-XT100

Serial No.

1015-0001

H-1001-0001

WARNING

To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.

A-1021-0001

The unit is not disconnected from the mains as long as it is connected to the AC outlet, even if the unit itself has been turned off.

-1022-0002

To reduce the risk of fire, do not cover the ventilation opening of the appliance with newspapers, tablecloths, curtains,

Do not expose the appliance to naked flame sources (for example, lighted candles).

A-1016-0005

To reduce the risk of fire or electric shock, do not expose this appliance to dripping or splashing, and do not place objects filled with liquids, such as vases, on the appliance.

A-1020-0001

As the main plug is used to disconnect the unit from the mains, connect the unit to an easily accessible AC outlet. Should you notice an abnormality in the unit, disconnect the main plug from the AC outlet immediately.

1018-0001

Do not install the appliance in a confined space, such as a bookcase or built-in cabinet.

Do not expose batteries or appliances with battery-installed to excessive heat such as sunshine and fire.

Indoor use only.

For the customers in the U.S.A.


This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

A-1017-0001


This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

Important Safety Instructions


- 1) Read these instructions.
- Keep these instructions.
- Heed all warnings. 3)
- 4) Follow all instructions
- 5) Do not use this apparatus near water.
- 6) Clean only with dry cloth.
- 7) Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- 8) Do not install near any heat sources such as radiators, heat registers, stoves or other apparatus (including amplifiers) that produce heat.
- 9) Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into vour outlet, consult an electrician for replacement of the obsolete outlet.



HT-XT100 4-559-030-11(1)



4-559-030-11(1)



Bluetooth SIG, Inc. and any use of such

∆US

masterpage: Left L-0001-0004 .-0053-0002 .P-1200-000 Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils L'exploitation est autorisée aux deux conditions pas produire de brouillage, et (2) l'utilisateur de brouillage radioélectrique subi, même si le

