Appendix Ⅱ Internal Photographs


Open View of EUT




Internal View of EUT-1




Internal View of EUT-2




Internal View of EUT-3




Internal View of EUT-4




Internal View of EUT-5




Internal View of EUT-6




Internal View of EUT-7




Internal View of EUT-8




Internal View of EUT-9




Internal View of EUT-10



Internal View of EUT-11



Internal View of EUT-12



Adapter



RF Module & Antenna Location

