

AMCREST
SmartHome
Quick Setup Guide
4MP Wi-Fi Bullet Outdoor Camera
Model: ASH102-W



How can we help?

We are dedicated to providing the highest quality service to our customers and are available 7 days a week.

Online Video Tutorial & Quick Start Guide
amcrest.com/support

Need help?
amcrest.com/contactus
1-888-212-7538

2

01
Setting Up
the Camera

The Amcrest Smart Home app connects your Amcrest camera to your Android or iOS mobile device. The camera must be connected to what matters most.



To get the app, search for "Amcrest Smart Home" in the Google Play or App Store.

Note: To add your device to the Amcrest View Pro Smart Home app, please visit amcrest.com/support.

3


Connecting to the SmartHome app

Important: Please complete the entire initial setup process on your Wi-Fi router to ensure a stable connection.

Ensure your device is powered using the included power adapter and the Amcrest Smart Home app.

Tap on "Register" to register an account. After registering and tap "Add Device".

You will need to allow all permissions to allow the camera to connect to your mobile device.



4

Scan the QR Code or Manually Enter the S/N

Slide the QR code located on the bottom of your camera.

If you are unable to scan the QR code you can manually enter the serial number. Tap on "Manually enter SN".



5

Choose Your Setup Method


Choose between Wi-Fi and Ethernet Only Setup. Please note that the Ethernet function on either a Wi-Fi or Ethernet connection, the camera cannot connect to both.

Wi-Fi (Recommended)

This method allows you to connect your camera to your network via Wi-Fi using the camera's built-in Wi-Fi hotspot.

Ethernet Only

This method uses an Ethernet only connection device to the network. Follow the in app instructions to complete setup.



6

Note: Your camera must be powered on and connected to your mobile network during either setup method.


02 Camera Features

The main screen on the Amcrest Smart Home app will menu displays all of your oddity devices.




Built-in Microphone

Use the built-in microphone feature to listen to what matters most, anytime, anywhere.



SmartHome Cloud Storage


Use the Amcrest Smart Home premium cloud service to view, record and playback events from a secure, off-site location.



MicroSD Card Storage

A MicroSD card can be used to record and playback events locally.


Note: The MicroSD card must be formatted by FAT32.



Motion and Human Detection

Motion Detection allows you to receive alerts and automatically record when motion is detected.


Enable Human Detection to only receive alerts when a human figure is detected.



Push Notifications

Receive push notifications when motion is detected.

Note: To learn more visit amcrest.com/support



7

8

9

10

11

12

Devices
Displays all added devices in the app.

Events
Provides quick access to motion events and alerts.

Account
Manage account settings and information.