



## Antenna and Device Information

\* Distance between BT/wifi antenna and edge



\* Distance between Main antenna and edge



## SAR Test Setup Photographs

■ **Test Setup Photo (Left All)**




■ **Test Setup Photo (Left Touch/Tilt)**



■ **Test Setup Photo (Right All)**



■ Test Setup Photo (Right Touch/Tilt)



■ Test Setup Photo (Body All)




■ **Test Setup Photo (Rear)**




**[Distance of 1.0 cm from the EUT]**

■ **Test Setup Photo (Front)**



[Distance of **1.0 cm** from the EUT]

■ **Test Setup Photo (Left)**



**[Distance of 1.0 cm from the EUT]**

■ **Test Setup Photo (Right)**



**[Distance of 1.0 cm from the EUT]**

■ **Test Setup Photo(Bottom)**



**[Distance of 1.0 cm from the EUT]**

■ **Test Setup Photo (Rear)**



**[Distance of 1.5 cm from the EUT]**

■ **Test Setup Photo (Front)**



[Distance of **1.5 cm** from the EUT]