


Attachment 8.


- DUT Antenna Information and SAR Test SETUP PHOTOGRAPHS

DUT Antenna Information


* Placement of each antenna



* Distance between Main Antenna



* Diagonal Distance



SAR Test Setup Photographs

■ **Test Setup Photo (Body All)**




■ **Test Setup Photo (Rear)**




[Distance of 0 mm from the EUT]

■ **Test Setup Photo (Rear)**



[Distance of 22 mm from the EUT]

■ **Test Setup Photo (Rear)**



[Distance of 9 mm from the EUT]

■ **Test Setup Photo (Left)**



[Distance of 0 mm from the EUT]

■ **Test Setup Photo (Left)**



[Distance of 11 mm from the EUT]

■ **Test Setup Photo (Top)**



[Distance of 0 mm from the EUT]

■ **Test Setup Photo (Top)**



[Distance of 17 mm from the EUT]

■ **Test Setup Photo (Top)**



[Distance of 9 mm from the EUT]

■ **Test Setup Photo (Body Edge All)**



■ **Test Setup Photo (Body Corner All)**




Test Setup Photo (Corner 45° Tilt)



[Distance of 0 mm from the EUT]

■ Test Setup Photo (Corner 45° Tilt)



[Distance of 18 mm from the EUT]