


2.2. Return Loss & VSWR Test setup photo



※ Coaxial cables are connected to each antenna.

※ The coaxial cable is connected to the RTS60 chamber to measure the VSWR.

3. Radiation Pattern Test setup photo

