
Transmitter Location
Not being moved
New Location
Old Location
BREEZE WAY
WOMEN
MEN
PHONE & DATA RM.
L1
L2
L3
Telephone & Server Room
L4
L5
L6
Cafe'
L7
L8
L9
L10
L11
UTILITY ROOM
(Water heater, HVAC units)
Men
Women
Doors to Loading Dock
Shipping Area
Door to Outside
Double doors to outside
140'-0"
120'-0"
30'-0"
30'-0"
20'-0"
10'-0"