ColorFit Ultra

Please refer to this manual before using the product

What's in the box

Table of Contents

Get Started

- What's in the box
- Watch overview
- Charge the watch
- Turn the watch on and off
- Watch Navigation
- Screen Navigation
- Button

Set Up

- App setup
- Pair the Watch

General Device Information and Tips

Regulatory and Safety Information

Customer support

Watch Features

- Activity
- Workouts
- SpO2
- Heart Rate
- Sleep
- Breathe
- Weather
- Music
- Reminders
- Stopwatch
- Alarm
- World Clock
- Watch Faces
- Stocks
- Stress
- Flashlight
- Settings
- Cycle Tracker

Charging the ColorFit Ultra Smart Watch

Before using your ColorFit Ultra for the first time, it is recommended to fully charge it using the charging cable provided with the watch to charge. On a full charge, ColorFit Ultra can last up to 9 days.
Note: The battery life and time to fully charge the device may vary as per usage and other factors.

To charge ColorFit Ultra

- Plug the USB cable into a power adaptor. Plug the power adaptor into an electrical socket (Power adaptor not included).
- Place the magnetic charger on the magnetic charging points of the watch.
- While your watch is charging, the screen will show its progress.
- Once the battery is fully charged, remove the charger.

Power On

Press and hold the side button for a few seconds to turn on the watch.

Power Off

Press and hold the side button for a few seconds, select Shut down and confirm to power off.

Waking Up the Watch

To preserve battery, the watch screen turns off when not in use. To turn the screen back on, you can wake up the watch by:

- Pressing the side button
- Turning on the Wrist sense

Watch Navigation

The ColorFit Ultra smartwatch has an LCD colour touch screen. Navigate the watch by tapping on the screen, swiping side to side, up and down and pressing the side button.

Home Screen Navigation

The home screen is the watch face.
From the home screen:

- Swipe left or right to access shortcuts.
- Swipe up to go to quick settings menu.
- Swipe down to check your message notifications.

Button Navigation

- Press the side button to turn on the watch display.
- Press the side button again to go to the main menu.

Setup

Before pairing, make sure that your smartphone is compatible with the Noise app.
The app will ask for personal information such as height, weight and sex to calculate your stride length, distance covered, calorie burn rate.

- Turn on Bluetooth and the location on your mobile phone.
- In your smartphone, download the Noise® app from the Play store or the App store and install it.
- Create an account or login using an existing account.

Note: Ensure that your smartphone is running on Android 6.4+ or iOS 9+ and is connected to mobile data or a Wi-Fi network.

Pair the Watch

- Open the Noise® app and allow the Bluetooth and GPS positioning to be turned on.
- Feed in your personal information and health goals in the app.
- Go to 'Pair Device' page in the app, select the watch name and MAC address and link the watch.

Or you can follow these steps:

- Turn on the watch.
- Scan the QR code from the Noise® app on your phone.
- Select Pair with device and wait for it to pair.

Watch Features

Watch Face

You can switch between different watch faces in the watch, choose and download cloudbased, animated watch faces or create your own watch faces in the Noise® app.

Changing the Watch Face

Give your screen a personalised style by changing or customising the watch face from the Noise® app or the watch.

On the Watch

Touch and hold the home screen. Swipe and choose from the watch faces.

In the App

Go to watch faces, select the watch face of your choice and tap save to change the watch face.

noise

Activity

You can check your daily activity progress including steps, distance, endurance, covered, calories burned and active time.

Heart Rate

ColorFit Ultra supports 24/7 heart rate tracking. You can select the measurement mode between Manual and Auto.
To measure your heart rate in real time, go to the Heart Rate monitor and tap on 'Tap to measure'. You can view the all-day data on the watch and app.
Ensure that your arms and wrists are still and there is no space between your watch and the wrist.

Stress

ColorFit Ultra supports 24-hour stress level measurement and viewing of all-day measurement data.
To measure the stress levels real time, go to the Stress Level feature and wait for it to measure.
Note: Make sure your arms and wrists are still and there is no space between your watch and the wrist.

SpO2

ColorFit Ultra supports viewing of the highest and lowest values of Blood Oxygen level of the day and the measurement data throughout the day. You can also manually measure at any time, go to the Blood Oxygen monitor and let it measure.
Note: Make sure your arms and wrists are still and there is no space between your watch and the wrist.

Breathe

The Breathe feature helps you adjust your breathing rate to improve concentration and endurance.
You can choose from 3 speeds (fast, moderate and slow) to adjust your breathing rate according to your preference. You can see the change in the beats per minute.
Go to the Breathe feature, choose the time duration and speed and tap on start to enter the cycles of breathing and inhalation.
Tap on the screen to pause, swipe right or press a button, breathing is interrupted and you can choose to practice again or complete the cycle.

Sleep

You can view your most recent sleep record and sleep quality in various sleep stages in the Noise® app. The feature will measure your sleep time, wake time and REM, deep sleep, sleep states (light sleep and deep sleep), wake time and REM.

Weather

ColorFit Ultra supports 5-day weather forecast. Ensure that your phone is ringing. It is synced with the Noise® app. You can view today's current weather and for the next 4 days. Open the Weather app on your watch and change the location to see the weather of your current location.

Music

You can control your favourite songs and podcasts that play from your phone, right on your wrist as long as the watch is connected with the Noise® app in your phone. Tap on the music icon to pause, rewind, go to the next/previous track and increase/decrease volume.

Stopwatch

A stopwatch can be set on the watch. You can also set lap times in the stopwatch.

Alarm

You can add, delete, and enable/disable alarms. Alarms will be synced with the phone in the Noise® app and it will sync with the watch. You can also label alarms to identify them.

Stocks

You can update yourself with stock market information with this feature. Go to app and add Stock information.

Cycle Tracker

You can manage your cycles better by predicting your cycle based on recorded data. Fill in the cycle length, period duration and the date of your period and save. Note: This feature is available only for females.

Flashlight

You can use this feature to turn on the screen brightness to max to illuminate your surroundings better.
Go to the Flashlight. Tap to turn on.

Quick Settings

You can swipe from the watch's home screen to gain Quick Settings access.

- Battery
- Theatre Mode
- Screen Lock
- To unlock the screen, long-press the side button.
- Find Phone
  - You can make your phone ring using the watch even if your phone is on silent.
  - Click the icon to stop the ringing.
- DND
  - Tap on the DND to turn it off or on.

Device Information and Tips

Device Information

The ColorFit Ultra Smart Watch contains the following:

- 1.75" LCD Display
- Heart Rate Monitor
- Stress Monitor
- IP68 waterproof
- 120 Sports Modes
- 22mm Quick Change Pins

The ColorFit Ultra smartwatch stores your activity data for up to 7 days in between the time you last synced your watch. The stored activity data includes your steps, distance, calories, active minutes, heart rate, sleep duration and workout data. We recommend syncing the watch to the App daily.

Tips

How do I update my ColorFit Ultra?

You can update your ColorFit Ultra via the Noise® App. Go to My Profile and select Check for updates.

How do I find my watch's current firmware version?

You can find the watch's current firmware version in the Noise® App under the ColorFit app. Select Device Information, choose Check for updates and update if any update is available.

How do I save battery?

Follow these simple steps to save ColorFit Ultra's battery:

- Minimise the screen brightness
- Limit the notification you receive from the Noise® App.

How does the watch estimate how many calories have been burned?

ColorFit Ultra estimates how many calories you burn based on your age, physical data you entered when you set up your account.

How do I change my activity goals?

You can do it through the Noise® App. Go to My Profile, select Personal Information and Objectives. Change your goals and confirm.

How do I buy my weight?

You can log in your weight the first time you setup your Noise® App. However, you can update the weight later via Noise® app. Go to My Profile, select Personal Information and change or update your weight. You can also update your name, height, country and email id.

Disposal and Recycling Information

Electrical and electronic devices may not be disposed of with domestic waste. Consumers are obliged by law to return the electrical and electronic device at the end of their service lives to the public collection system free of charge, or to return or point of sale. Details for this are defined by the national law of the respective country. Your ColorFit Ultra product is manufactured in terms of utilising dd devices, you are making an important contribution to protecting our environment.

Regulatory and Safety Information

USA: Federal Communications Commission (FCC) Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

This device may cause harmful interference, and this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residen tial installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the in structions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The ColorFit Ultra smartwatch is not a toy. The watch contains small components that could be a choking hazard and are not intended for use by small children or pets. Unless otherwise specified, the ColorFit Ultra smartwatch is a fitness device and are not intended to diagnose, treat, cure or prevent any disease. We develop fitness algorithms to provide health and wellness information as accurately as possible. The accuracy of devices are not intended to be equivalent to medical devices or scientific measurement devices.

If this 76 equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The ColorFit Ultra smartwatch is not a toy. The watch contains small components that could be a choking hazard and are not intended for use by small children or pets. Unless otherwise specified, the ColorFit Ultra smartwatch is a fitness device and are not intended to diagnose, treat, cure or prevent any disease. We develop fitness algorithms to provide health and wellness information as accurately as possible. The accuracy of devices are not intended to be equivalent to medical devices or scientific measurement devices.

In some cases, prolonged use of products may cause skin irritation. Prolonged contact may contribute to skin irritation or allergies in rare cases. If you notice any skin irritation, keep the watch and watch band clean and dry. Don't wear it too tight and give your wrist a rest by removing the watch after an extended period of wear. If you feel any discomfort, stop wearing the watch or stiffness in your hands or wrists while or after wearing the watch, please immediately discontinue use.

Safety Instructions

- Do not disassemble the battery on your watch.
- Do not expose ColorFit Ultra to extremely high or low temperatures. Do not keep battery in a cold, overheat room.
- Do not open, crush, bend, deform, puncture or shred secondary cells or batteries. In the event of a battery leak, do not allow the liquid to come contact with skin or eyes. If this happens, immediately flush the areas affected with water and seek medical help.
- Keep the batteries out of children's reach and in a safe place to prevent danger.
- Do not place the batteries in the water.
- Do not short-circuit. Short-circuiting a battery can damage it and, consuming can occur when a metallic object, such as coins, causes the direct connection of positive and negative terminals of the battery.
- Do not use your product in a sauna or steam room.
- Do not dispose of batteries in the fire as that may cause an explosion. Dispose of used batteries in accordance with your local regulations. Do not dispose it as household waste.
- Use only the charging cable supplied to charge the battery. Do not charge for more than 24 hours.
- Do not attempt to repair or maintain the watch yourself; service and maintenance should be carried out by authorised technicians only. Any device failure should be referred to our after-sales service centre.
- To prevent device damage, accessory damage and device failure, always protect the device against strong impact or shock.

Customer Support

If you experience any problem with the watch, it may be fixed by restarting your watch. For any assistance, please reach out to us at **support.gonoise.in**

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residen tial installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the in structions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving an tenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.