SOMiC

M200头戴式无线耳机用户手册

在使用时请详细本说明书，并妥善保存

SC

产品概要

总体简述介绍：

M200是一款具备音乐、游戏两种音效模式的，具备超低延迟的，且可用于听音乐、看电影、玩游戏等场景的头戴式轻游戏蓝牙耳机。

电子规格

M200具有音频方案品质高，和手机、平板等产品兼容性强等优势，同时也具有以下特性：

- 蓝牙协议: A2DP，AVRCP, HSP，HFP
- 自动配对, 回连模式
- 自动关机功能
- 音乐、游戏两种音效模式
- Type-C USB接口5V充电

产品功能

支持立体声音乐播放, 暂停, 上一曲, 下一曲等功能；
支持电话接听，挂断等常用功能；
支持在没有找到可匹配连接的设备10分钟自动关机功能；
支持耳机低电量提示；
支持手机检测显示耳机电量。

按键及插口定义





按键/接口功能介绍：

①音量"+"键：提升耳机音量、下一曲

②智慧模块按键：开/关机, 暂停/播放，接听/拒接/挂断

③音量"-"键：降低耳机音量、上一曲

④工作指示灯窗口：显示耳机工作状态、低电提醒、显示充电状态

⑤Line IN 3.5mm音频输入接口

⑥TPYE-C充电口；耳机充电接口

基本操作说明

1 、开机和配对

长按③键 3秒开机，同时耳机发出"Power on"提示音

开机后，无历史匹配记录则进入配对模式，同时耳机发出"pairing"提示音，连接成功发出"Connected"提示音；

开机后，有历史匹配记录则进入回连模式。

2 、关机：(耳机关机时会发出"Power off" 提示音)

无线模式：开机状态下，长按③键3秒，耳机关机，同时耳机发出"Power off" 提示音；

进入配对模式10分钟后如未配对成功，耳机自动关机；

开机状态下，插入Type-C充电头充电时，耳机自动关机；

开机状态下，插入3.5mm音频线，耳机自动关机，此时耳机播放外接设备的信号配对持续10分钟，配对失败直接关机。

3 、回连模式

耳机在以下情况将进入回连模式：

开机时，耳机与手机有历史匹配记录；

使用中，耳机异常断连（不包括手机手动断开）；

回连持续10分钟，连接成功提前结束回连模式，回连失败则自动关机。

4、配对模式

耳机在以下情况将进入配对模式；

开机时，耳机与该设备无历史匹配记录；

回连失败时；

手机手动断开当前设备时；

在配对模式时，允许任何蓝牙设备进行主动连接；

配对持续10分钟，连接成功提前结束，配对失败则直接关机。

5 、清除配对

同时长按①键和③键3秒进行清除配对记录，耳机将清除原有的所有配对，然后进入等待的待配对状态，可被其他带蓝牙的设备搜索并连接。

6 、音效模式

耳机离在连接状态下，启动③键，两种音效模式来回切换，分为游戏模式 (提示音"Gaming_Mode")和音乐模式 (提示音"Music_Mode")。

7 、音乐播放/暂停

播放音乐时，单击③键可暂停/播放音乐。

8 、音量控制

加大音量：单击①键，音量调至最大时有提示音"Max volume"（音量调整范围，与外接设备同步）；

减小音量：单击②键，音量调至最小时有提示音"Min volume"（音量调整范围，与外接设备同步）。

9 、切换歌曲

下一曲：长按①键 2秒；

上一曲：长按②键 2秒。

10 、通话模式

来电时，单击②键，接听来电

来电时，双击②键，拒绝来电

通话中，单击②键，结束通话

来电时，音乐播放自动暂停，播放耳机铃声；

拒绝来电/结束通话后，音乐播放自动恢复。

11.尾号重拨

双击②一次，本机器会自动重拨手机最后一个拨出去的电话号码。

EN

Product summary

General introduction:

M200 is a bluetooth headset with dual sound effects,with music mode and game mode, with ultra-low latency, and can be used for listening to music, watching movies, playing games and other scenes.

Electronic Specifications

M200 has the advantages of high quality audio solutions and strong compatibility with mobile phones and tablets, as well as the following features:

- Bluetooth protocols: A2DP, AVRCP, HSP, HFP
- Automatic pairing and link back mode
- Automatic shutdown function
- Two sound modes: music and game
- Type-C USB port 5V charging

Product function

Support stereo music playback, pause, the previous song, thenext song and other functions;Supports common functions such as answering and hanging up the phone Support automatic shutdown function in 10 minutes when no matching device is found;
Support earphone low battery warning;
Support mobile phone detection and display headset power.

扫码关注硕美科官方微信
获取更多产品资讯

广东硕美科高新科技有限公司

硕美科官方网站: www.somic.cn

400-698-9993

12 、语音助手

在已连接设备的状态下，三击②键，触发手机语音助手；

在触发语音助手状态下，单击①键，退出手机语音助手。

13、低电量状态

低电状态提示时，耳机还能保证约15分钟工作（具体根据电池状况而定）；

耳机低电时，红灯每5秒闪烁一下。

14 、充电模式

耳机插入充电线连接电源，进入充电模式；

充电时，电源指示灯红色长亮；

充满时，电源指示灯蓝色长亮。

15 、有线模式

用3.5mm音频线接入耳机⑤处接口，即插即用；

如果正处于蓝牙连接模式，耳机⑤处插入3.5mm音频线后耳机自动关机，并进入AUX外接播放模式；外接播放模式时，耳机电源无法启动，且所有按键无功能和麦克风不工作；耳机锂电池消耗完后，仍可以使用AUX模式进行工作。

提示：
1、感到本产品的请仔细阅读使用说明书并妥善保管；
2、请注意操作时,请先阅读产品进行充电；
3、如果产品长期放过2个星期不用,请对其充电；
4、必须选择正规厂家生产且经过国家CCC认证的充电器；
5、新手机无法收到蓝牙耳机,请确认蓝牙耳机是否处于"配对模式",若长时间未进行配对或联络,请将蓝牙耳机放入充电仓,重置配对模式,然后手机按序出现,请重配手机。

售后服务

为不浪费您宝贵时间，在送修前请检查下列各项。

故障现象	可能原因	排除方法
无法开机	电池电量不足	及时给电池充电
无法配对	手机尚未启动蓝牙功能或尚未打开"可发现"的状态	启动手机蓝牙功能并设置为"可发现"状态
	配对时，耳机离发射器距离太远	距离请不要超过1米
	电池电量不足	及时给电池充电
噪音大	电池电量不足	及时给电池充电
断音	1,耳机离发射器距离太远或出现信息盲区。 2, 耳机离发射器距离之间有障碍物阻挡。	重新调整合适位置收听
接收距离短	1, 发射器设备兼容性问题。 2, 耳机离发射器距离之间有障碍物阻挡。	1,更换发射设备 2, 重新调整合适位置收听

硕美科无线降噪耳机保修说明

保修条例

硕美科无线降噪耳机售后服务承诺:产格依据(中华人民共和国消费者权益保护法)、《中华人民共和国产品质量法》实行售后三包服务,服务内容如下:

在三包有效期内,您可依照本规定享受修理、换货、退货的权利。

修理、换货、退货的权利应当凭发票或有效销售凭证办理。

1. 自您签收日起7日内,产品出现品质问题,可享受退货、换货或者免费维修服务。
2. 自您签收日起8日-15日内,产品出现品质问题,可享受换货或者免费维修服务。
3. 自您签收日起12个月内,产品出现品质问题,可享受免费维修服务。

非保修条例

1. 已超过三包有效期;
2. 无法提供发票或有效销售凭证;
3. 发票或有效销售凭证上的产品信息与实物不相符;
4. 未经授权的维修、误用或改动等人为因素或因不可抗力造成的损坏。

注意事项

1. 本产品兼容微软Windows7/8/10, 安卓Android, 苹果MAC与iOS操作系统，适配XBOX与PS4主机。如果在未列明的操作系统和设备上使用,导致无法正常工作,可联系售后服务寻求解决；
2. 产品使用过程中,如果出现部件受损,如线缆被咬等,请停止使用并寻找有维修资质的人员或售后服务解决,以免造成不必要的损失；
3. 本产品可能与部分品牌的延长器声卡不适配,如果因使用延长器而引起冲突,可联系售后服务寻求解决；
4. 使用本产品时,如果遇到驱动兼容性问题,可联系售后服务寻求解决。

产品保修卡

尊敬的顾客：

您好!申请售后时,请根据您的实际情况填写产品保修卡,并把产品与产品保修卡一同寄回到您所购买产品的商家处,谢谢!

1、请勾选进行售后的原因：

☐ 功能不好 ☐ 不够美观 ☐ 佩戴不舒适

其他：_____

2、请勾选您所寄的售后选项：

☐ 换新 ☐ 维修 ☐ 退货

3、请您给我们提供宝贵的意见：_____

注:具体售后地址请咨询商家。

请填写以下资料(以下均为必填)

产品信息

产品型号：_____

产品序列号：_____

购机信息

订单编号：_____

购买账号：_____

用户姓名：_____

联系电话：_____

回邮地址：_____





Button/Interface Function Introduction:

①Volume "+" button: increase headphone volume, next track

② Pause/Play button: power on/off, pause/play, answer/reject/hang up

③ Volume "-" button: decrease headphone volume, previous track

④Working indicator light: Display the working status of the headset,low battery reminder and display charging status

⑤Line IN 3.5mm Aux Jack interface

⑥TPYE-C charging port

Basic operating instructions

1 、Startup and pairing

Press and hold the ② key for 3 seconds to start the machine, and the headset will sound the "power on" prompt tone at the same time;After power on, if there is no historical matching record, it will enter the pairing mode. At the same time, the headset will give a "pairing" prompt tone, and a "connected" prompt tone will be given if the connection is successful;After startup, if there is historical matching record, it will enter the back connection mode.

2 、Power off (a "power off" tone will be emitted when the headset is turned off)

Wireless mode: in the power on state, long press the ② key for 3 seconds, the headset will turn off, and the headset will send out a "power off" prompt tone;After entering the pairing mode for 10 minutes, if the pairing is not successful, the headset will automatically shut down;When the type-C charging head is plugged in for charging, the headset will automatically turn off when the headset is powered on;In the power on state, insert the 3.5mm audio cable, and the headset will automatically shut down. At this time, the headset will play the signal of the external device;Pairing lasts for 10 minutes. If pairing fails, it will be shut down directly.

3 、Loopback mode

The headset will enter the loopback mode when:

When the phone is turned on, the headset and the mobile phone have historical matching records;

Abnormal disconnection of earphone during use (excluding manual disconnection of mobile phone);The loopback lasts for 10 minutes. If the connection succeeds, the loopback mode ends in advance. If the loopback fails, the system will shut down automatically.

4 、pairing mode

The headset will enter pairing mode when;

There is no historical matching record between the headset and the device when it is turned on;When the connection fails;

When the mobile phone manually disconnects the current device;

In the pairing mode, any device is allowed to actively connect;

Pairing lasts for 10 minutes. If the connection is successful, it ends in advance. If pairing fails, it will be shut down directly.

5 、Clear pairing

Meanwhile, long press the volume "+" key and the volume "-" key for 3 seconds to clear the pairing record. The headset will clear all the original pairing, and then enter the normal pairing status, which can be searched and connected by other devices with Bluetooth.

6 、Sound effect mode

When the headset is connected, press the ② key four times to switch back and forth between the two sound effect modes, which are divided into game mode (prompt tone "gaming_mode") and music mode (prompt tone "music_mode")

7 、 Music play / pause

when playing music, click ② to pause / play music.

8 、Volume control

Increase the volume: click the volume "+" button, and when the volume is adjusted to the maximum, there is a prompt tone "Max volume" (the volume adjustment range is synchronized with the external device);

Decrease the volume: click the volume "-" key, and the volume will be adjusted to the minimum with the prompt tone "Min volume" (volume adjustment range, synchronized with the external device).

9 、Switch Songs

Next song: long press the volume "+" key for 2 seconds;

Previous song: long press the volume "-" key for 2 seconds.

10 、Call mode

When you call, click ② to answer the call

When calling, double-click ② to reject the call

During a call, click ② to end the call

When an incoming call occurs, the music playback will be automatically suspended and the earphone ringtone will be played;

After rejecting the call / ending the call, the music playback will automatically resume.

11. Last number redial

Short press the button ② twice in succession, the machine will automatically redial the last phone number dialed by the mobile phone.

12 、Voice assistant

When the device is connected, press the ② key three times to trigger the mobile phone voice assistant;

When the voice assistant is triggered, click ② to exit the mobile phone voice assistant.

13 、Low battery status:

When the low power status is prompted, the headset can still work for about 15 minutes (depending on the battery condition); When the headset is low, the red light flashes every 5 seconds.

14 、Charging Mode:

Plug the headset into the charging cable to connect the power supply and enter the charging mode;

When charging, the power indicator light is red;

When it is full, the power indicator light is blue and on;

15. Wired mode

Connect the 3.5mm audio cable to the earphone for plug and play;

If you are in the Bluetooth connection mode, the headset will automatically shut down after the 3.5mm audio cable is inserted into the headset motherboard, and enter the aux external playback mode; In the external playback mode, the headset power cannot be started, and all keys have no function and the microphone does not work; After the lithium battery of the headset is consumed, it can still work in aux mode.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

– Reorient or relocate the receiving antenna.

– Increase the separation between the equipment and receiver.

– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

– Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning:

1.Please read the instruction manual carefully before using this product and keep it properly;

2.When using for the first time, please charge the product first;

3. If the product is not used for a long time (more than 2 weeks), please charge it;

4.The chargers produced must be by regular manufacturers and certified by the national CCC;

5. If the mobile phone cannot search the Bluetooth headset, please confirm whether the Bluetooth headset is in "pairing mode". If it has not been paired or connected for a long time, please put the Bluetooth headset into the charging case and reset the pairing mode. If there is an error in the mobile phone program, Please restart your phone.

Basic Operation Instruction

To avoid wasting your valuable time, pls check the following before sending repairs.

Fault phenomenon	Possible reasons	Exclusion method
Unable to boot	The battery power is insufficient.	Charge the battery in time.
Unable to Paring	The phone has not yet enabled the Bluetooth function or has not yet opened the discoverable status.	Start Bluetooth and set to discoverable.
	When paired, the headphones are too far from the transmitter.	Please do not distance to more than 1 meter.
	The battery power is insufficient.	Charge the battery in time.
The noise is large	The battery power is insufficient.	Charge the battery in time.
Staccato	1 、The headset is too far from the transmitter, beyond the receiving range. 2 、There is an obstacle between the headphones from the transmitter.	Resweak properly to listen.
The receiving distance is short	1 、Transmitter equipment compatibility issues. 2 、There is an obstacle between the headphones from the transmitter.	1 、Replace the transmitting equipment 2、Reset the appropriate location to listen

Product Features

1 、Headset is available in three connectivity modes (normal Bluetooth mode, Bluetooth low latency mode (with a transmitter) and 3.5mm wired mode) for a variety of scenarios and devices.

2、Headset has two sound modes of game and music, both listening to songs and games.

3、Thanks to 35ms super low latency,you can enjoy the game experience of audio and video synchronization.

4、Headphone microphone is a retractable microphone that can be adjusted according to the usage scenarios.

5、Headset is built-in 1000mA capacity battery with super long life and up to 50 hours without LED.

6、Headsets are ergonomic designed, tough appearance and domineering appearance.

7、Headphones feature large skin-stick leather earcases for comfortable wear.

Note

1 、This product is compatible with Microsoft Windows 7/8/10, Apple Mac OS system, Android system and IOS system;

2 、If it is not available on the operating system or equipment that is not listed, you can contact the after-sales service for a solution;

3 、During the use of the product, if there is no sound from the microphone or headset, it may be caused by compatibility problems or improper use, and you can contact the after-sales service to find a solution;

4 、During the use of the product, if any part is damaged, such as a broken cable, please stop using it and contact the after-sales service for a solution to avoid unnecessary losses.

5 、During the use of the product, if the headset does not respond for a long time, you can use a sharp object such as a paper clip to press the headset reset button for 1 second, and the headset can be forced to shut down.

6 、If you want to know more information, please visit Somic's official website www.itsomic.com.

SOMiC

M200 Wireless headset manual

Please read this manual carefully when using it and save it