80mm

100mm

XtremeMac™

**Multi Connection Mouse**

XWH-ALM-13

**XtremeMac, 1st on Apple accessories since 2001!**

www.xtrememac.com | facebook | pinterest | twitter

**Made in PRC | Merapat ve MIC | Designed in the EU| Dizenmiha Ed | © 1st of Ellas.**
**XtremeMac, the XtremeMac logo, and the XtremeMac product names are trademarks of XtremeMac corporation. Photos and specifications accurate at time of publication. Other trademarks are the property of their respective owners. Photos and specifications accurate at time of publication. | year manufacture.**

**Batch: 0XYZZ111**

## PRODUCT OVERVIEW





1. Left Click
2. Right Click
3. Scroll Wheel
4. DPI Button
5. Micro Charging Port
6. USB Connection Indicator Light
7. Bluetooth Indicator Light
8. TypeC Connection Indicator Light
9. Mode Switch Button
10. On / Off Button
11. TypeC Receiver
12. USB Receiver
13. Battery Indicator Light

## HOW TO CHARGE YOUR MOUSE

When the battery of your mouse is **low**, the battery indicator light will **flash** red. Use the included USB cable to charge your mouse. When charging the battery indicator light will turn red and will turn off when it's fully charged.

## HOW TO CONNECT YOUR MOUSE

<u>To connect your mouse with USB receiver:</u>
- Turn on your mouse.
- Press the mode switch button until the USB connection indicator light turns red.
- Open the battery cover and take out the USB receiver.
- Insert the USB receiver into your computer and your mouse will connect automatically.

<u>To connect your mouse with TypeC receiver:</u>
- Turn on your mouse.
- Press the mode switch button until the TypeC connection indicator light turns green.
- Open the battery cover and take out the TypeC receiver.
- Insert the TypeC receiver into your computer or smartphone and your mouse will connect automatically.

<u>To connect your mouse with Bluetooth:</u>
- Turn on your mouse.
- Press the mode switch button until the Bluetooth indicator light turns blue.
- Long press the mode switch button for 5 seconds until the Bluetooth indicator light flashes blue.
- Open the Bluetooth settings on your computer or smartphone and select "XWH-ALM-13" to pair.

## SPECIFICATIONS

Laser Battery: 500mAh
DPI: 1000/1600/2400
Dimensions: 115.07 x 59.19 x 37.35 mm
Weight: 82.3g

Bluetooth technology: 4.0
Working distance: 15m
Voltage: 3.7V
Working current: 4mA
Maximum radiofrequency power:
Frequency Bands:
Compatibility: Windows8, Windows10
Mac OS X 10.10 or higher, Android 4.3 or higher

2.4GHz wireless
Working distance: 30m
Voltage: 3.7V
Working current: 5.5mA
Maximum radiofrequency power: 8dBm
Frequency Bands: 2402MHz ~ 2480MHz
Compatibility: Windows XP, Windows7, Windows8, Windows10, Mac OS X 10.10 or higher

Warning:
Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Statement:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.