sanag

A30S Pro/A30S Pro Max

使用指南
Operating guide

操作按键进行相应

1 音量加/下一曲 按音量键加，按更长时间
2 开启降噪/透明模式 开启降噪/透明模式
3 音量减/上一曲 按音量减键，按更长时间
4 LED指示灯
5 MIC
6 麦克风，用于接听通话

侧面视图　　底部视图

充电说明

连接充电线时，红灯将保持亮起，表示正在充电。当红灯熄灭，表示充电已完成。

耳机会通过蓝牙连接至设备，并自动重新连接上次使用的设备。

蓝牙配对

■ 首次连接配对

关机状态下，长按开机键直到，红灯和白灯交替闪烁，表示进入配对模式。

随后打开设置菜单，从蓝牙列表中，选择"Sanag A30S Pro/A30S Pro Max"，并点击配对。

■ 开机状态下进行配对

耳机处于开机状态下，长按开机键，红灯和白灯交替闪烁，表示进入配对模式。

随后打开设置菜单，从蓝牙列表中，选择"Sanag A30S Pro/A30S Pro Max"，并点击配对。

■ 进行配对

耳机配对成功后，长按开机键，红灯和白灯交替闪烁，表示进入配对模式。

随后打开设置菜单，从蓝牙列表中，选择"Sanag A30S Pro/A30S Pro Max"，并点击配对。

按键操作

■ 开机/关机：

长按开机键，直到白灯和红灯交替闪烁，表示正在开机/关机。

■ 降噪模式切换至透明模式：

在开机状态下，快速按开机键两次，红灯和白灯交替闪烁，表示已切换至透明模式。

■ 降噪模式切换至普通模式：

在开机状态下，快速按开机键两次，红灯和白灯交替闪烁，表示已切换至普通模式。

■ 音量加：

耳机通过蓝牙连接，按音量加键增加音量。

■ 音量减：

耳机通过蓝牙连接，按音量减键减小音量。

■ 接听来电：

耳机通过蓝牙连接，按音量加键接听来电。

■ 挂断来电：

耳机通过蓝牙连接，按音量减键挂断来电。

■ 一键唤醒语音助手：

耳机通过蓝牙连接，长按音量加键唤醒语音助手。

■ 一键唤醒语音助手：

长按音量减键唤醒语音助手。

■ 切换歌曲：

耳机通过蓝牙连接，按音量加键切换至下一首歌曲，按音量减键切换至上一首歌曲。

■ 音量调整：

耳机通过蓝牙连接，按音量加键增加音量，按音量减键减小音量。

■ 音乐暂停/播放：

耳机通过蓝牙连接，按音量加键暂停音乐，按音量减键播放音乐。

注意事项：

- 请在清洁干燥的环境下使用，以保证设备安全。
- 请勿长时间将耳机放入口袋。
- 请勿以剧烈撞击或摔落设备，以免损坏内部电子元件。
- 请勿将耳机置于高温环境下，以免电池过热或损坏。
- 请勿拆解或改装耳机，以免造成设备损坏或失去保修资格。
- 请勿将耳机浸入水中，以免导致设备进水损坏。
- 请勿使用尖锐物品刺穿耳机，以免造成设备损坏。
- 请勿在设备充电时使用耳机，以免影响充电效果。
- 请勿将耳机放置在儿童或宠物可接触的地方，以免发生意外。
- 请勿在设备发热时继续使用，以免进一步损坏设备。
- 请勿将耳机暴露在腐蚀性物质中，以免腐蚀设备外壳。
- 请勿在设备内部进行任何修改，以免影响设备的正常使用。

基本参数

- 型号：A30S Pro
- 耳机类型：动圈蓝牙耳机
- 蓝牙版本：V 5.3
- 电池容量：DC 3.7mm（10mA）
- 电池类型：1.0Ah
- 产品重量：16.5±5%
- 耳机尺寸（长，宽，厚）：18.8*16.8*7mm
- 充电时间：1.5小时左右（原厂充电器或充电时间以产品为准）
- 工作温度：-10℃-70℃
- 存储温度：-10℃-70℃

Thank you, for choosing our bone conduction Bluetooth headset to enhance experience please read the instruction manual carefully before using this product. If there is any printing error or functions errors hope that the majority of users understand.

Overview of key features

1 Volume increase / Next song: short press volume increase, long press one song
2 Key on / noise/ortransition keys: switch on / off, also pause, mute/select on switching
3 Volume decrease / previous song: short press volume decrease, long press previous song
4 LED: Blue & red
5 MIC
6 Mic: on conduction sound generating unit

Charging use

When the earbuds are in use, the red light flashes continuously and stops when fully charged. At this time, please connect the power adapter. The headset charges the headset, and the headset will automatically shut down when the power of the headset is low.

The earphone is charged through a magnetic charging wire. After the charging is completed, the working indicator changes from red steady on to blue steady on. Note: Please use a DC charger to charge, the battery may be damaged if exceeds the power DC and reduce the charging.

Bluetooth pairing

■ First boot pairing

Power off the headset, long press the mode button for 2 seconds, the red light and blue light flashes alternately, and the headset is turned on and enter pairing mode. The power button is pressed for 2 seconds, and the mobile phone or smart electronic device is automatically searched for "Sanag A30S Pro / A30S Pro Max" and click Connect.

Key operation

■ Headset on

In the off state, press and hold the mode button for 2 seconds, the blue light is always on for 1 second, the red blue light flashes alternately, and the headset is turned on with a beep.

■ Headset off:

When the headset is turned on, press and hold the mode button button for 4 seconds, the red light will be on and then it will go out, and the headset will turn off. Accompanied by a beep.

■ Disconnection, over distance disconnection or equipment shutdown

When the mobile phone and headset exceed the Bluetooth connection distance, the headset appears with a prompt tone, and the mobile phone and headset are disconnected. Return to the Bluetooth connection range between the headset and the mobile phone within 5 minutes. The headset and the mobile phone can be automatically connected. After 5 minutes, the headset enters the standby mode. If it is not connected after 5 minutes, the headset will automatically shut down.

■ TF card mode or Bluetooth mode:

When the headset is on, double click the mode button, and the blue light flashes once every 10 seconds to switch the TF card mode or Bluetooth mode, accompanied by "Music" prompt tone.

■volume up

When the headset is on or off, short press the volume up key to continuously increase the volume to the maximum, accompanied by prompt tone.

■ volume down

When the headset is talking, press the volume reduction button and the volume continues to decrease the minimum tone, accompanied by a beep tone.

■Music play / pause:

Short press the ■ button center: music playback, play status blue light flashes once in 5 seconds. Pause status: blue light flashes once in 10 seconds.

■Single loop full loop:

Under the state of music, three times open loop, single cycle period "full" short open, all cycle "Prompt" "loop" "sections.

■Answer / reject:

The first call comes in, short press the mode button button to answer it, long press the mode button button to reject it.

■Hang up during a call

1 "hot press" "one" button button to hang up.

●Next song button/volume up

In the music state, short press the volume up button and the volume continues to increase. When it reaches the maximum, there will be a beep. Hang status, long press to switch to the next song.

●Previous song button/volume down

In the music state, short press the volume down button and the voice continues to decrease. When it reaches the minimum, there will be a beep. Hang status, long press to switch to the previous song.

●How to copy data

Turn on the machine, insert the U disk into the PC or U disk phone and the computer can read the U disk and delete, copy, the required data and paste it into the device.

●Low voltage alarm/shutdown

Alarm: the red light flashes once every second, accompanied by the short sound "Please charge".
Power off: When the red light is on for 3 seconds, the headset is turned off.

Matters needing attention:

- Wipe the device with a dry cloth before use to ensure safety and maintain its performance.
- Avoid prolonged use in high-volume environments to prevent hearing damage.
- Do not disassemble or modify the device to avoid damage to the device and voiding the warranty.
- Keep the device away from water to prevent damage to the device.
- Do not use sharp objects to puncture the device to avoid damage to the device.
- Do not use the headset while the device is charging to ensure charging efficiency.
- Keep the headset out of the reach of children and pets to prevent accidents.
- Stop using the headset if the device overheats to prevent further damage.
- Do not expose the headset to corrosive substances to prevent corrosion of the device.
- Do not disassemble or modify the device to avoid affecting its normal use.

Basic parameters

- weight: bare metal 20g
- headset type: Sports Bluetooth headset
- Bluetooth version: V 5.3
- charging input: DC 5V 2.0mA
- transmission distance: 10M
- product impedance: 16 ohm
- earphone size (length, width and height): 18.8*16.8*7mm
- charging time: about 1.5 hours (It is better to charge more than 2 hours for the first time)
- operating temperature: -10 ℃ to 70 ℃
- storage temperature: -10 ℃ to 70 ℃

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

このたびはご購入誠にありがとうございます。当社の製品をご購入いただいたお客様に、ご使用前に説明書をお読みになられてください。ファーストの使用に伴うトラブルがあるかもしれませんが、ご了承ください。

A30S Pro/A30S Pro Max

使用説明書
Operating guide

主な機能の概要

1 ボリュームアップ
2 ボリュームダウン
3 ノイズキャンセル/透明モード
4 LED指示ランプ（赤・青）
5 電源ボタン（長押しでペアリング）
6 マイク（通話時のみ使用）

通常ユニット　　骨伝導ユニット

充電方法

イヤホンが稼働状態の場合、赤い点滅状態が点灯する。充電が完了すると、赤い点滅が消えます。このとき充電器を接続してください。

イヤフォンをマグネット充電線に接続すると、赤い点滅状態になります。充電が完了すると、ワークインジケーターは赤から青に変わります。

イヤホンの電源が低下した場合、イヤホンは自動的にシャットダウンします。

ペアリング

■ 初回ペアリング

イヤホンが電源オフの状態で、電源ボタンを2秒間長押しすると、赤と白のライトが交互に点滅し、ペアリングモードに入ります。電源ボタンを2秒間長押しすると、携帯電話または電子機器が自動的に「Sanag A30S Pro / A30S Pro Max」を検索し、「接続」をクリックします。

■ ペアリングモードに入る

オフの状態で、電源ボタンを2秒間長押しすると、赤と白のライトが交互に点滅し、ペアリングモードに入ります。電源ボタンを2秒間長押しすると、携帯電話または電子機器が自動的に「Sanag A30S Pro / A30S Pro Max」を検索し、「接続」をクリックします。

■ 接続が完了したら

ペアリングモードに入ったら、長押しすると、赤と白のライトが交互に点滅し、ペアリングモードに入ります。

■ 接続解除

接続解除後、長押しすると、赤と白のライトが交互に点滅し、ペアリングモードに入ります。

■ 再接続

接続されていない状態で、長押しすると、赤と白のライトが交互に点滅し、ペアリングモードに入ります。

■ 音楽の再生/一時停止

音楽を一時停止するには、音楽を再生するには、音楽を一時停止するには、音楽を再生するには、音楽を一時停止するには、音楽を再生するには、