RS1000-2B2-G1A3H -美规



1.英语



● Table of Contents

User Manual 01
Product Function Introduction 02
Technical Specifications 04
Cleaning and Maintenance 05
Common Questions 06
Troubleshooting of Main Faults 07

●User Manual

Guideline for Safe Use

Read the User Manual carefully and familiar yourself with the product functions before performing operations.

Please operate as the manual, to avoid serious injury caused to yourself or others, or damage to products or property caused by failing to follow the instructions.

Do not disassemble, rent are not provided or recommended, and be sure to strictly follow the instructions to install and use the products, or else you are not eligible to enjoy our free after-sales services.

Charging Modes

Method 1: Charging through AC adapter

AC adapter — Outdoor power supply

Method 2: Charging through solar panel

Outdoor power supply

Method 3: Charging through car charger (12V)

Automotive power plug (cigarette lighter port) — Outdoor power supply

▲Caution

★ Batteries may be in sleep mode due to long-term transportation and storage, please charge the product with the adapter, the battery will be activated after charging for 10 minutes.

★ Before use for the first time, please fully charge the product to avoid product failure due to low battery.

01

●Product Function Introduction

Button Introduction

A: Power button
D: AC Output button
B: DC Output button
E: LED light button
C: ECO button

1.The AC/USB/DC output switch can be normally turned on only when the power switch is turned on; if you need to charge the electronic device through AC/ DC/ ECO, please turn on the power switch first, then turn on the AC/ DC/ ECO switch as you need. Once the switch is turned on, the LED lights up and displays the corresponding data.

2. Press the main power switch to turn on or off the outdoor power supply.

3.ECO mode: When the main power switch is turned on, the ECO switch will automatically turn on, and the ECO mode will start. After no load running for a period of time, it will automatically shut down (please consult customer service personnel for details). You can press the ECO button (the indicator is off) to disable the auto sleep function.

4.LED light: Press the LED button to turn on the LED light, press the LED button again to turn on the LED light, and press and hold the button for 2-3 seconds to enable SOS mode.

5.When the power switch is turned on, the wireless charging function is available.

Packing List

Car mount USB (Car charger port) — AC adapter — Operation Manual

02

●Product Function Introduction

LCD Interface Introduction

D F G B

E A H C

A: Battery indication: The percentage and the number of battery bars show the remaining battery level. The power icon will flash and pump when charging, and stop flashing when fully charged.

B: Battery time: The battery time is displayed in hours and minutes.

C: Output power: Indicates the total output power of AC, DC and USB.

D: Remaining discharge time: It is displayed in hours and minutes during the charging of the power supply.

E: Input power: Indicates the current input power of the energy storage power supply.

F: Low voltage warning: When this warning occurs, please charge the power supply in time.

G: Temperature warning: If this icon is displayed, it indicates that the temperature is too high or too low. The device can be used normally when the temperature is restored to room temperature.

H: Low battery (TO EMPTY): Prompt for the battery level less than 20%, please charge in time.

▲Caution

When the AC switch is turned on and there is no output, the LCD will display the output power, which is normal.

Please turn off the output switch if not in use.

03

●Technical Specifications

Product Name	Portable Power Station
Model	RS1000
Size	~290X231.5X304mm
Capacity	999Wh 243Ah/3.2V
Flashlight	3W (Max)
Weight	8.0Kg
LED Light	3W (Max)
Operating Temperature	-10~40°C
Input DC(7909 Port)	Adapter 12.28V (200W Max) / Solar Panel MPPT : 11-28V (120W Max) / Car Charger 12V 80W Max)
Output AC x2	110V~60Hz (1000W, Peak 2000W)
Output USB-A1	5V=3.4A or 9V=2A or 12V=1.5A (18W Max)
Output USB-A2	5V=3.4A or 9V=2A or 12V=1.5A (18W Max)
Output USB-A3	5V=3.4A or 9V=2A or 12V=1.5A (18W Max)
Output Type-C	5V=3A or 9V=2A or 12V=2A or 15V=2A or 20V=1A (60W Max)
Wireless Output	10W(Max)
Car Charger	12V=10A (120W Max)

04

●Cleaning and Maintenance

Product Maintenance

1.Do not completely discharge to 0%, otherwise, the battery will be damaged, when the battery is low, it will enter the sleep mode.

2.Please charge the product in a well-ventilated environment, and keep away from fire source and water source to prevent accidents.

3.Do not disassemble the product, or else it may lead to fire, explosion, electric shock and other unpredictable dangers.

Cleaning Product

1.Please clean the product periodically. During cleaning, ensure that the power supply is turned off, and wipe the product with a clean, dry and soft cloth. Do not use water to clean the product.

2.Do not clean the product with corrosive chemicals to prevent accidents.

3.Do not clean the product with metal objects for fear of short circuit or electric shock.

Transportation and Storage

1.To reduce safety risks, parents should closely supervise the use of this product by children in the vicinity. If a child accidentally swallows parts, seek medical help immediately.

2.If the product will be idle for a long time, please charge it before storage, otherwise, the battery in the product may be damaged. Recharge and discharge the product every 3 months to maintain the battery's capacity and extend the battery's service life. If you return transportation and storage, please charge the product with the adapter, the battery will be reactivated after charging for 10 minutes.

3.Store the product in a dry place. Do not place the product in water, under high temperature or near heat sources.

4.Low temperature may affect the battery performance of the precinct. Please charge the product within the temperature range of 0°C~40°C and use the product within the range of -10~40°C.

Disposal of Batteries

1.The batteries for the product include dangerous chemicals and must not be thrown into an ordinary trash can.

2.Ensure that the batteries of the product are completely discharged before thrown into the designated battery recycling box.

3.For product recycling, please follow local laws and regulations on battery recycling and disposal.

05

● Common Questions

1. Can I use the product while charging?

Our outdoor power supply supports charging while using, but it is not recommended to use it during charging, for it will affect battery life.

2. Is the charger heating normal during charging?

Heating is normal for the charger during charging. Our standard charger meets the requirements of the national safety standard. Please use with peace of mind.

3. Why does the fan start sometimes?

Outdoor power supply is equipped with high temperature protection function and the working of the built-in fan is conducive to the heat dissipation of outdoor power supply, thus avoiding high temperature. Usually, the fan will be activated automatically when the temperature reaches a certain value during use, and there will be a small sound.

4. Why does the product shut down automatically during use?

When the outdoor power supply stays on only even the low-power equipment, the output will automatically shut down after the time set by the system so as to avoid unnecessary energy consumption when the user forgets to shut down.

5. Why can't the charging equipment be used within the rated range of the product?

* The battery level is lower than 20%! Please charge it.
* The starting power of some charging devices is 3 times greater than the peak power of the outdoor power supply. Please select a charging device with a higher rated output power of the outdoor power supply! Therefore, it is recommended to choose a power supply with a higher power.

6. Can I take the outdoor power supply on board?

No, the outdoor power supply belongs to the lithium battery product. According to the regulations of aviation, passengers are prohibited to take lithium battery products with a capacity greater than 100Wh on board.

06

●Troubleshooting of Main Faults

Symptom	Troubleshooting	Solution
Charging failure	Check if not the product, adapter and mains supply are properly connected	Make sure whether it's a contact problem
	Good contact, adapter indicator lights off	The adapter is faulty, contact the after-sales service personnel
	The charging indicator light is on but charging fails	Contact the after-sales service personnel
No product output	Connecting lines of equipment are product not inserted in place	Check and debug the device connection carefully
	Check whether the corresponding output switch is turned on	Open the corresponding output switch and the display screen will display the output power
	Low battery level of product	Charge the product
	The product is still not usable after the above factors above be ruled out	Contact the after-sales service personnel.
Sudden interruption of output	The power of the electronic equipment in use exceeds the rated power of the product	Please purchase the product with the corresponding power and contact after-sales service personnel for more information
	The output power is too low and the product automatically shuts down after several hours of use	The automatic shutdown function is normal, please restart the power supply to start the product.
	Automatic protection against overcurrent, high/low temperature and short circuits cuts off the output	The product is equipped with 7 protective functions. If the output is shut down due to overcurrent or short circuit, please turn off the button again to start it when the product is restored to normal.

07