中

MONSTER

Monster Airmars XKT26
真无线蓝牙耳机
使用说明书

产品参数

- 蓝牙版本 ---------- V5.4
- 传输距离 ---------- ≥10m
- 喇叭直径 ---------- Φ13mm
- 喇叭阻抗 ---------- 32Ω±15%
- 灵敏度 ---------- 104±3dB
- 频响范围 ---------- 20Hz-20KHz
- 电池容量（充电盒） ---------- 300mAh 3.7V
- 电池容量（耳机） ---------- 40mAh 3.7V
- 充电时间（充电盒） ---------- ≤2小时
- 播放时间（耳机） ---------- ≥6小时
- 配合充电盒播放时间 ---------- ≥24小时

包装清单

产品示意说明



给充电盒充电

用Type-C充电线连接充电盒到5V电源适配器。



温馨提示：当未经充电盒，充电盒指示灯显示蓝灯闪烁，请给充电盒充电。

指示灯指南

模式	描述	语音提示
开机	耳机进蓝灯指示灯两次	"Power on"
关机	耳机红色指示灯长亮1秒熄灭	"Power off"
配对	耳机进蓝红指示灯交替闪烁	"Pairing"
连接	耳机蓝灯灯常亮	"Connected"
断开	耳机进蓝红指示灯交替闪烁	"Disconnected"
耳机低电	耳机红色指示灯闪烁	"Battery low"
耳机盒放耳机充电	充电盒进蓝指示灯长亮4秒熄灭	—
充电盒充电	充电盒进蓝指示灯闪烁	—
充电盒充满	充电盒进蓝指示灯长亮	—

产品操作说明

1. 开机
方式一：打开充电盒上盖，耳机自动开机。
方式二：长按左/右耳机MFB触键约2秒，耳机开机。

2. 关机
方式一：将耳机放回充电盒中，合上充电盒上盖，耳机自动关机。
方式二：长按左/右耳机MFB触键约2秒，耳机关机。

3. 配对
步骤一：打开充电盒上盖，耳机自动开机；
步骤二：打开智能设备的蓝牙列表，搜索"Monster Airmars XKT26"进行配对，连接成功后，会收到语音提示音"Connected"

* 超出距离，在断开连接3分钟内，回到有效距离，自动连接设备。

注意：
* 如果产品长时间不使用，应关闭清晰，并确保设备处于关机状态。
* 长期闲置后，请给充电盒配充，避免长时间充电造成电损坏。

触控键操作

常规模式

语音助手：长按2秒左耳机MFB
音量加：单击左耳机MFB
音量减：单击左耳机MFB

音乐播放模式

暂停/播放：双击左/右耳机MFB
上一曲：三击左耳机MFB
下一曲：三击右耳机MFB

电话免提

接听：双击左/右耳机MFB
拒接：长按2秒左/右耳机MFB
挂断：双击左/右耳机MFB

音乐模式/游戏模式/通透模式/ANC模式 切换：已连设备

游戏模式：长按2秒右耳机MFB进入游戏模式
通透模式：长按2秒左耳机MFB进入通透模式
ANC模式：长按2秒左耳机MFB进入ANC模式
音乐模式：长按2秒左耳机MFB进入音乐模式

恢复出厂设置

耳机开机后未与蓝牙设备配对状态下，左/右耳机配对成功，连击左/右耳机5次后左/右耳机关机（表明恢复到初始状态即可）

注意

1.从充电盒出现时，不需按任何按键，耳机自动开机，连接成配对，同时进入充电盒,充电盒将自动切换充电。耳机关机。
2.禁温度，高寒处，如长期不用，请以1天充电1次，延长电池寿命，耳机潮湿 充电盒内部分经常保持干燥和清洁。
3.电池充电或使用完成后不得擅自拆解，否则造成自己的的损失，禁止拆解，抛出，挤压或刺入，以免，起火或产爆炸。切勿接触腐蚀，切勿置于高温环境中，遠离强磁场。
4.由于本款产品采用无线连接方式，在日常使用过程中，受到环境，手机品牌，使用行为等因素影响，可能会偶现音频中断，音质模糊，轻微的声音卡顿等正常现象。

警 告

1.长期佩戴高音量会损害听力或造成听觉受损的风险。请以冷静而适当音量收听，请遵照所提示。
2.请不要将此款产品浸入水中，以免造成短路。
3.不要自行拆解产品或改装，以免导致损坏及保修失效。
4.请勿把产品安置在靠近热源或高温的地方。
5.请勿使用化学溶剂或溶剂类清洁产品。

Name of the Parts 部件名称	Hazardous Substances 有害物质					
	Pb 铅	Hg 汞	Cd 镉	CrVI 六价铬	PBB 多溴联苯	PBDE 多溴二苯醚
Housing 外壳	O	O	O	O	O	O
Loudspeakers 喇叭单元	O	O	O	O	O	O
PCBs 电路板组件	X	O	O	O	O	O
Accessories 电源线、连接线	X	O	O	O	O	O

This table is compiled according to SJ/T 11364.
本表根据第SJ/T 11364的规定编制。

O: Indicates that this hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.
(表示在该部件所用均质材料中的有害物质低于GB/T 26572的限量要求以下。)
X: Indicates that this hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.
(表示在该部件所用均质材料中的有害物质至少一种均高于GB/T 26572的限量要求。)

FCC 声明

根据FCC规则第15部分，本设备经过测试，符合有关数字设备的限制。这些限制旨在提供合理的住宅设施中的有害干扰防护。该设备产生使用并可辐射射频能量，如果未按照规定安装和使用说明书可能会对无线电通信造成有害干扰。然而，并不能保证在特定安装中不会发生干扰。如果这个设备有对无线电或电视接收造成有害干扰，可通过将此未确定设备关闭和打开时，鼓励用户尝试通过一个或多个以下更多措施：

—重新定向或重新定位接收天线。
—增加设备和接收器之间的间隔。
—将设备连接到与接收器不同的电路上的插座已连接。
—请咨询经销商或经验丰富的无线电/电视技术人员以获得帮助。

此设备符合FCC规则的第15部分。操作受以下两个条件限制条件：

（1）本装置不得引起有害干扰。
（2）本装置必须接受任何接收到的干扰，包括可能导致意外操作的干扰。未经合规责任方明确批准的变更或修改可能使用户对设备的操作权限失效。

FCC ID：2ABPV-QSMXKT26

Environment Friendly Use Period (EFUP)
环保使用期限

This logo refers to the period (10 years) during which the hazardous substances in electronic and electrical products will not leak or mutate so that the use of these [substances] will not result in any severe environmental pollution, any bodily injury or damage to any assets.

这标志标识的期间（10年）是电子电气产品中有害物质在正常使用的条件下不会发生外泄或突变，电子电气产品的产品使用会不对电气产品不会对环境造成严重污染或对其人身，财产造成严重损害的期限。

保修卡

感谢您的产，本保修卡是您将本申请保修的凭证，请您在收到商品或同开始保修更换用。

用户信息			
用户姓名		电子邮件	
联系电话		邮政编码	
通讯地址			

产品信息			
产品名称		产品型号	
产品条码/编号/批号			

销售商信息			
名 称			
地 址			
联系电话		邮政编码	
销售日期		发票号码	
备 注			

MONSTER
合格证
产品编号
生产日期
检 验 员
QC

英

MONSTER

Monster Airmars XKT26
True wireless Bluetooth headphone
instruction manual

Product parameters

- Bluetooth version ---------- V5.4
- Transmission distance ---------- ≥10m
- Driver diamter ---------- Φ13mm
- Driver impedance ---------- 32 Ω±15%
- sensitivity ---------- 104±3dB
- Frequency response ---------- 20Hz-20KHz
- Battery capacity(Charging case) ---------- 300mAh 3.7V
- Battery capacity(Headphone) ---------- 40mAh 3.7V
- Charging time(Charging case) ---------- ≈2 hours
- Music playtime(Headphone) ---------- ≈6 hours
- Music playtime with charging case ---------- ≈24 hours

Product Schematic Description



Product Schematic Description



Charge the charging case

Connect the charging case to the 5V power adaptor with Type-C charging cable.

TIPS: When the cover of the charging box is closed, the indicator light of the charging box flashes ice-blue, please charge the charging box.

Indicator guide

Mode	Describe	Sound prompt
Power On	Ice blue light of the headset blinks three times	"Power on"
Power Off	Red indicator light on the headphones remains on for 1 second and goes off	"Power off"
Paring	Ice blue and red lights of the headset flash alternately	"Pairing"
Connected	Headphones LED indicator is off	"Connected"
Disconnected	Ice blue and red lights of the headset flash alternately	"Disconnected"
Low Battery	Red indicator on the headset blinks	"Battery low"
Headphones placed in charging case (Headphones Low power	Ice blue indicator light of the charging case will keep on for 4 seconds and turn off	—
Charging case charged	Ice blue indicator of the charging case blinks	—
Charging case fully charged	Ice blue indicator light of the charging case is bright	—

Product operating instructions

1. Power on
Method 1: Open the top cover of the charging case, and the headset will turn on automatically
Method 2: Long press the MFB button of the left/right headset for about 3 seconds to power on the headset.

2. Power off
Method 1: Put the earphone back in the charging case, close the cover of the charging case, and the earphone will automatically shut down.
Method 2: The device automatically shuts down after 3 minutes of inactivity.

3. Pairing
Step one: Open the top cover of the charging case, and the headset will turn on automatically;
Step two: Open the Bluetooth list of smart devices, search for "Monster Airmars XKT26" to pair, and the connection is successful After that, you will hear the "Connected" tone

* Headphones will try reconnecting to the device within 3 minutes when connection is lost.



NOTE:
* Fully charge the headphones and power off before an intended not-in-use period.
* Unplug the charging cable after charging.

Operation

Normal

Voice Assistant: Press and hold left MFB for 2 S
Volume + : Click right MFB
Volume - : Click left MFB

Music playback

Pause/Play: Double click Left/Right MFB
Last song: Three hits left MFB
Next song: Three hits right MFB

Phone

Answer: Double click the left/right MFB
Reject: Long press left/right MFB for 2 S
Hang up: Double click the left/right MFB

Music/Game/Transparent/ANC switch: Connected device



Game mode: Press and hold right earphone MFB for 2 seconds enter Game mode
Transparent mode: Press and hold right earphone MFB for 2 seconds enter Transparent mode
ANC mode: Press and hold right earphone MFB for 2 seconds enter ANC mode
Music mode: Press and hold right earphone MFB for 2 seconds enter Music mode

Restore factory settings

When you turn on the headphone, make sure it does not connect to any Bluetooth device, and click the MF button 5 times to clear the pairing record, then turn off the headphone.

Precautions

1.Take out the earphone from the charging box, without pressing any button, the earphone will automatically turn on, connect or pair, put the earphone into the charging box, and the charging box will automatically Charge your headphones. Turn them off.
2.Often clean, long life, if not used for a long time, it is recommended to charge once every 15 days to extend battery life, and the charging part of the headset is often used with cotton swabs Alcohol wipe, can help smooth charging, avoid bad contact, affect the use experience. Do not disassemble the charging box and headset by yourself, do not throw, squeeze or stab, to avoid fire or explosion. Do not place in high temperature environment, Do not use after soaking water.
4. Because this product adopts wireless connection mode, it is affected by environment, mobile phone brand, usage behavior and other factors in daily use it may be normal to have a brief, slight sound delay during the playing of music.

Warnings
1.Do not use headphones at high volume for an extended period of time.
2.Do not expose to high temperatures or high humidity.
3.Do not disassemble the headphones and accessories, otherwise warranty will be violated.
4. Keep headphones away from any impact or vibration.
5. Do not use any chemical solvents or cleaning agent on the headphones.

Name of the Parts	Hazardous Substances					
	Pb	Hg	Cd	CrVI	PBB	PBDE
Housing	O	O	O	O	O	O
Loudspeakers	O	O	O	O	O	O
PCBs	X	O	O	O	O	O
Accessories	X	O	O	O	O	O

This table is compiled according to SJ/T 11364

O: Indicates that this hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.
X: Indicates that this hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

— Reorient or relocate the receiving antenna.
— Increase the separation between the equipment and receiver.
— Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
— Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.
(2) this device must accept any interference received, including interference that may cause undesired operations. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID：2ABPV-QSMXKT26

Environment Friendly Use Period (EFUP)

This logo refers to the period (10 years) during which the hazardous substances in electronic and electrical products will not leak or mutate so that the use of these [substances] will not result in any severe environmental pollution, any bodily injury or damage to any assets.

Warranty Service

Dear user, this warranty card is the proof of your future warranty application, please cooperate with the seller to fill it out and keep it for future use!

User info			
User name		Email	
Contact number		Postal code	
Mailing address			

Product information			
Product name		Product number	
Product barcode / Serial number / Batch number			

Vendor information			
Name			
Address			
Contact number		Postal code	
Sales date		Invoice number	
Remark			

MONSTER
Certificate of Approval
Product No:
Production Time:
QC

文件名称	魔声XKT26说明书			材料	全书60g书纸+单黑印刷+骑马钉	单位	mm	厂商物料编号	变更履历	修改		日期	
文件尺寸	60X90mm（单P尺寸）			工艺	1C印刷 风琴折 	公差	±0.5mm	XXXXXXXXX	V06：降噪变更ANC V07：增加通透模式	审核		日期	
设计日期	2023/11/25	文件版本	2023V07			比例	1:1			批准		日期	