封面

外页

折叠线

封底

内页

User Manual

True Wireless Earbuds

MODEL:ET-BH036

FCC ID: 2A94QET-BH036

Specifications

EN

Model	ET-BH036
Bluetooth Version	V5.2
Charging Case Battery Capacity	300mAh
Charging Case Rated Voltage	3.7V
Earbuds Fully Charged Time	1.5H
Charging Case Fully Charged Time	1.5H
Music Playback Battery Life	8H (50% Volume)
Charging Port	Type-C
Input	5V/0.3A(Charging Case)

Accessories



Note:

Remove the insulation cover from the earbuds before first use. Put the earbuds into the charging case, and take out for use.

All images in this user manual is for illustrative purpose only. Please refer to the actual product.

For Android mobile phones, if there is a phenomenon that the volume of the mobile phone and the volume of the earphone are not synchronized, it can be solved through the settings of the mobile phone. Solution: Settings -> Bluetooth -> Click the pop-up option menu in the upper right corner -> Advanced Settings -> Media volume synchronization, turn on the switch.

Using Your Earbuds



1. Charging

Charging Earbuds

When the earbuds prompt low battery, put the earbuds into the charging case, the earbuds will be in charging status automatically and the charging case lights up for 3 seconds before going off.

Charging the Case

Connect the charging case to any 5V/1A power supply port with the included charging cable.

While charging, the charging case is breathing white slowly.

After fully charged, the charging case stays solid white.

2. Control & Functions



Music:	Pause/Play	Double tap L/R
	Previous Track	Triple tap L
	Next Track	Triple tap R
	Volume -	Tap L once
	Volume +	Tap R once
Calling:	Answer	Double tap L/R
	Hang Up	Double tap L/R
	Reject	Tap & Hold L/R for 2s
Normal/Bass/Pop Mode:		Tap & Hold L for 2s
ANC/Normal/Pass Through:		Tap & Hold R for 2s

(Mode switch is not available for single earbud)

3. On/Off

When opening the lid of the charging case, the earbuds are turned on.

Put back the earbuds to the charging case and close the lid to turn off.



4. Bluetooth Connection



For the first connection, open the lid of the charging case, take out both earbuds, and they will enter Bluetooth pairing mode automatically.

Search for "FlyH NC BH036", select to connect, and prompt voice "connected" after the connection is successful.

When the earbuds are turned on again, they will connect to the last paired device. If re-connection fails or the Bluetooth is disconnected, they will enter Bluetooth pairing mode automatically.

WEEE Compliance

Correct Disposal of This Product (Waste Electrical & Electronic Equipment)
(Applicable in countries with separate collection systems)
This marking on the product, accessories or literature indicates that the product and its electronic accessories should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this

Manufacturer: Shenzhen Aspiron Technology Company Limited
Address: Room 2803B,Building C,Galaxy World Phase Ⅱ,Minle Community,Minzhi Street,Longhua District,Shenzhen,Guangdong,China

MADE IN CHINA

5.Dual Earbuds TWS Connection

Both earbuds were paired with each other when they were produced at the factory.

6.Clearing Pairing History

Open the lid of the charging case and Put the earbuds into the charging case:make sure the earbuds were not connected to any device.

Press the button of the case for about 8 seconds to clear the pairing history and enter the paring mode automatically.

The white light flashes five times, indicating clearing successfully.

FAQ

❶ The indicator is off when the charging case is being charged.

Make sure the charging port of the charging case is connected to power supply normally.

❷ Cannot hear anything from the earbuds

Make sure the earbuds are on.

Make sure the volume is set properly.

Make sure the earbuds are connected to the phone.

Make sure the earbuds are within the working range.

❸ Phone call effect is not good

Make sure the phone is in a strong signal area.

The effective working range of the earbuds is 10 meters, please make sure the earbuds are within the working range, and there are no obstacles between the phone and the earbuds.

❹ Cannot control with pause, resume and previous/next track while playing music

The device paired with the earbuds needs supporting AVRCP (Audio/Video Remote Control Profile) Protocol.

仕様

JP

モデル	ET-BH036
Bluetoothバージョン	V5.2
充電ケースバッテリー容量	300mAh
充電ケース定格電圧	3.7V
イヤホンフル充電時間	1.5時間
充電ケースフル充電時間	1.5時間
音楽再生バッテリー稼働時間	8時間（音量50%時）
充電ポート	Type-C
入力	5V/0.3A(充電ケース)

アクセサリー



注記:

初回ご使用前に、イヤホンから絶縁カバーを取り外してください。
イヤホンを充電ケースに入れ、取り出してご使用ください。

本ユーザーマニュアルのすべての画像は説明のためのものです。
実際の製品を基準としてください。

Android携帯電話の場合、携帯電話の音量とイヤホンの音量が同期しない現象が発生する場合は、携帯電話の設定で解決できます。解決策:［設定］->［Bluetooth］-> 右上隅のポップアップ オプション メニューをクリック ->［詳細設定］->［メディア音量同期］の順に選択し、スイッチをオンにします。

イヤホンの使用方法

1.充電

イヤホンを充電する
イヤホンのバッテリー残量が少なくなったと通知された場合、イヤホンを充電ケースに入れると自動的に充電状態になり、充電ケースは3秒間点灯してから消灯します。

ケースを充電する
付属の充電ケーブルで、5V/0.3Aの電源ポートに充電ケースを接続します。充電中、充電ケースはゆっくりと白く点滅します。フル充電になると、充電ケースは白く点灯します。

2.コントロール＆機能



音楽：	一時停止／再生	L/Rを2回タップ
	前の曲へ	Lを3回タップ
	次の曲へ	Rを3回タップ
	音量−	Lを1回タップ
	音量+	Rを1回タップ
通話：	受信	L/Rを2回タップ
	通話終了	L/Rを2回タップ
	着信拒否	L/Rを2秒間長押し
ノーマル/低音/Popモード		Lを2秒間長押し
ANC/パススルー/標準モード：		Rを2秒間長押し

（片方のイヤホンのみではモード切替はできません）

3.オン/オフ

充電ケースからイヤホンを取り出すと、電源がオンになります。
イヤホンを充電ケースに戻しフタを閉めると、電源がオフになります。

4.Bluetooth接続時



初回接続時、充電ケースのフタを開け、両方のイヤホンを取り出すと、自動的にBluetoothペアリングモードになります。

「FlyH NC BH036」を検索し、接続を選択し、接続が成功すると「接続されました」という音声が流れます。

イヤホンの電源を再び入れると、最後にペアリングしたデバイスに接続されます。

再接続に失敗したり、Bluetoothが切断された場合は、自動的にBluetoothペアリングモードになります。

5.両イヤホンTWS接続

工場生産時、どちらのイヤホンも互いにペアリングされています。

6.ペアリングの履歴を消去する

まず充電ケースの蓋を開け、イヤホンを充電ケースに入れます。イヤホンが機器に接続されていないことを確認してください。

次に、充電ケースのボタンを約8秒間押すと、ペアリング履歴がクリアされ、自動的にペアリングモードになります。白いランプが点滅すると、ペアリングがリセットされます。

よくあるご質問

❶充電ケースを充電しているとき、インジケーターが消灯状態になります。
充電ケースの充電ポートが電源に正常に接続されていることを確認してください。

❷イヤホンから何も聞こえません
イヤホンがオンになっていることを確認してください。
音量が正しく設定されていることを確認してください。
イヤホンがスマートフォンに接続されていることを確認してください。
イヤホンが使用可能範囲内にあることを確認してください。

❸スマートフォンでの通話に問題があります
スマートフォンが電波の強い場所にあることを確認してください。
イヤホンの有効動作範囲は10mです。イヤホンが動作範囲内にあり、スマートフォンとイヤホンの間に障害物がないことを確認してください。

❹音楽の再生中、一時停止、再開、前の曲へ/次の曲への操作ができません。
イヤホンとペアリングするデバイスはAVRCP（Audio/Video Remote Control Profile）プロトコルに対応している必要があります。

Technische Daten

DE

Modell	ET-BH036
Bluetooth-Version	V5.2
Akkukapazität der Ladehülle	300mAh
Ladekoffer Nennspannung	3.7V
Dauer bis zur vollständigen Aufladung der Ohrhörer	1.5H
Dauer bis zur vollständigen Aufladung der Ladehülle	1.5H
Akkulaufzeit bei Musikwiedergabe	8H (50% Lautstärke)
Ladeanschluss	Type-C
Eingang	5V/0.3A(Ladehülle)

Zubehör



Hinweis:

Entfernen Sie vor der erstmaligen Verwendung die Isolierabdeckung von den Ohrhörern. Platzieren Sie die Ohrhörer in der Ladehülle und nehmen Sie sie zur Benutzung heraus.

Alle Bilder in dieser Bedienungsanleitung dienen nur der Veranschaulichung. Orientieren Sie sich am tatsächlichen Produkt.

Wenn bei Android-Mobiltelefonen das Phänomen auftritt, dass die Lautstärke des Mobiltelefons und die Lautstärke des Kopfhörers nicht synchronisiert sind, kann dies über die Einstellungen des Mobiltelefons behoben werden. Lösung: Einstellungen -> Bluetooth -> Klicken Sie auf das Popup-Option smenü in der oberen rechten Ecke -> Erweiterte Einstellungen ->Synchronisierung der Medienlautstärke, schalten Sie den Schalter ein.

Ihre Ohrhörer verwenden



1. Aufladen

Ohrhörer aufladen

Wenn die Ohrhörer einen niedrigen Batteriestand anzeigen, legen Sie die Ohrhörer in der Ladehülle. Die Ohrhörer befinden sich im Ladestatus automatisch und die Ladehülle leuchtet 3 Sekunden lang auf, bevor es erlischt.

Hülle aufladen

Schließen Sie die Ladehülle über das mitgelieferte Ladekabel an einen Stromversorgungsanschluss (5 V/1 A) an.
Während der Aufladung pulsiert die Ladehülle langsam weiß.
Nach vollständiger Aufladung leuchtet die Ladehülle dauerhaft weiß.

2. Steuerung und Funktionen



Musik:	Pause/Wiedergabe	L/R zweimal antippen
	Vorheriger Titel	L dreimal antippen
	Nächster Titel	R dreimal antippen
	Lautstärke -	L einmal antippen
	Lautstärke +	R einmal antippen
Telefonieren:	Annehmen	L/R zweimal antippen
	Auflegen	L/R dreimal antippen
	Ablehnen	L/R 2 s angetippt halten
Normal/Bass/Pop-Modus:		L 2 s angetippt halten
ANC/Normal/Pass-Through:		R 2 s angetippt halten

(Moduswechsel ist bei einem einzigen Ohrhörer nicht verfügbar)

3. Ein/Aus

Beim Öffnen des Deckels der Ladehülle werden die Ohrhörer eingeschaltet.

Zum Ausschalten platzieren Sie die Ohrhörer wieder in der Ladehülle.



4. Bluetooth-Verbindung



Öffnen Sie bei der erstmaligen Verbindung den Deckel der Ladehülle, nehmen Sie beide Ohrhörer heraus und sie rufen automatisch den Bluetooth-Kopplungsmodus auf.

Suchen Sie nach „FlyH NC BH036" wählen Sie zum Verbinden und bestätigen Sie

Stimme „verbunden", nachdem die Verbindung erfolgreich war.

Wenn die Ohrhörer erneut eingeschaltet werden, verbinden Sie sich mit dem zuletzt gekoppelten Gerät. Wenn der erneute Verbindungsaufbau fehlschlägt oder die Bluetooth-Verbindung getrennt wird, rufen sie automatisch den Bluetooth-Kopplungsmodus auf.

5.TWS-Verbindung beider Ohrhörer

Beide Ohrhörer wurden bei der Herstellung im Werk miteinander gekoppelt.

6.Kopplungsverlauf löschen

Öffnen Sie die Abdeckung der Ladebox Und legen Sie die Ohrhörer in die Ladebox ein; stellen Sie sicher, dass die Ohrhörer mit keinem Gerät verbunden sind. Drücken Sie den Knopf des Gehäuses etwa 8 Sekunden, um die Kopplungsverlauf zu löschen und wechseln Sie automatisch in den Kopplungsmodus. Das weiße Licht blinkt fünfmal und zeigt den erfolgreichen Löschvorgang an.

Häufig gestellte Fragen (FAQ)

❶ Die Anzeige ist aus, wenn die Ladehülle geladen wird.

Stellen Sie sicher, dass der Ladeanschluss der Ladehülle normal an die Stromversorgung angeschlossen ist.

❷ Keine Tonausgabe über die Ohrhörer

Stellen Sie sicher, dass die Ohrhörer eingeschaltet sind.

Vergewissern Sie sich, dass die Lautstärke richtig eingestellt ist.

Stellen Sie sicher, dass die Ohrhörer mit dem Telefon verbunden sind.

Stellen Sie sicher, dass sich die Ohrhörer innerhalb der Betriebsreichweite befinden.

❸ Qualität beim Telefonieren ist nicht gut.

Stellen Sie sicher, dass die Signalstärke des Telefons gut ist.

Die Betriebsreichweite der Ohrhörer beträgt 10 Meter. Achten Sie darauf, dass sich die Ohrhörer innerhalb der Betriebsreichweite befinden und keine Hindernisse zwischen Telefon und Ohrhörern vorhanden sind.

❹ Während der Musikwiedergabe ist eine Steuerung von Pause, Fortsetzung und vorheriger/nächster Titel nicht möglich.

Das mit den Ohrhörern gekoppelte Gerät muss das AVRCP- (Audio/Video Remote Control Profile) Protokoll unterstützen.

Bluetooth EN The Bluetooth word mark and logos are registered trademarks owned by the Bluetooth SIG,Inc. and any use of such marks by Sunvalleytek International Inc. is under license. Other trademarks and trade names are those of their respective owners.

FCC Compliance

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

材质：80G书写纸 单色双面印刷

尺寸：58x75mm

折叠方式：风琴5折再沿虚线上下对折