CB: 10MHz

Mode	CB: 10MHz, QPSK

Low Channel, 1RB-1



Low Channel, 1RB-2

Low Channel, 1RB-3



Low Channel, 100%RB-1



Low Channel, 100%RB-2



Low Channel, 100%RB-3



Mode	CB: 10MHz, QPSK

High Channel, 1RB-1



High Channel, 1RB-2



High Channel, 1RB-3



High Channel, 100%RB-1



High Channel, 100%RB-2



High Channel, 100%RB-3



Mode	CB: 10MHz, 16QAM

Low Channel, 1RB-1



Low Channel, 1RB-2



Low Channel, 1RB-3

Low Channel, 100%RB-1



Low Channel, 100%RB-2



Low Channel, 100%RB-3



Mode	CB: 10MHz, 16QAM

High Channel, 1RB-1



High Channel, 1RB-2

High Channel, 1RB-3



High Channel, 100%RB-1



High Channel, 100%RB-2



High Channel, 100%RB-3



Mode	CB: 10MHz, 64QAM

Low Channel, 1RB-1



Low Channel, 1RB-2



Low Channel, 1RB-3

Low Channel, 100%RB-1



Low Channel, 100%RB-2



Low Channel, 100%RB-3



Mode	CB: 10MHz, 64QAM

High Channel, 1RB-1



High Channel, 1RB-2



High Channel, 1RB-3



High Channel, 100%RB-1



High Channel, 100%RB-2



High Channel, 100%RB-3