ET-780 REMOTE CONTROL GEL BEAD TANK INSTRUCTION MANUAL

22 MAY 2023

Size : 420 x 110 mm

AGES 14+

REMOTE CONTROL

GEL BEAD TANK

Instruction Manual

Thank you for purchasing the Remote Control Gel Bead Tank. This manual provides more information about this RC Tank, please read the instructions before using.

⚠WARNING: Keep gel beads out of reach of children

Product Overview

Remote Control Gel Bead Tank

Instruction Manual

Remote Controller

2(Two) Bags (500pcs per Bag) Gel Beads

⚠WARNING: CHOKING HAZARD
Small parts. Not for children under 3 years.

Package Contents

Includes:
1(One) Remote Control Gel Bead Tank
5.3in. x 5.8in. x 6.6in. (13.4cm x 14.7cm x 16.8cm)
1(One) Remote Controller
4.2in. x 4.1in. x 1.7in. (10.7cm x 10.5cm x 4.2cm)
1(One) Instruction Manual
2(Two) Bags(500pcs per Bag) Gel Beads

Specifications

Power supply:
Remote Control Gel Bead Tank:
Five (5) AAA 1.5V Alkaline Batteries (Not Included).
Remote Controller:
Two (2) AA 1.5V Alkaline Batteries (Not Included).
Frequency: 2.4 GHz

Remote Controller



Standard Control

Note: To avoid losing control, always pay attention when controlling the Remote Control Tank.



The joystick push to forward, the Remote Control Gel Bead Tank go forward



The joystick push to backward, the Remote Control Gel Bead Tank go backward

Standard Control



The joystick push to left, the Remote Control Gel Bead Tank turn left



The joystick push to right, the Remote Control Gel Bead Tank turn right

Standard Control



Press the Automatic Demonstration Button, The Remote Control Gel Bead Tank will move automatically



Press the Bullet Fired Button to shoot the gel bead

Power On/Off

Remote Control Gel Bead Tank:

Power On / Off Switch



Slide the ON/OFF Switch to ON to turn on the Remote Control Gel Bead Tank.
Slide the ON/OFF Switch to OFF to turn off the Remote Control Gel Bead Tank.

Remote Controller:
The Remote Controller will be turned on automatically when the batteries have installed.

* * Remove batteries if product is not being used.

Batteries Installation

For Remote Control Gel Bead Tank



To install batteries into the Remote Control Gel Bead Tank, unscrew the screw on the battery box cover to open the cover. Insert 5 x "AAA" 1.5V batteries (Not Included) into the battery box. Batteries should be placed as shown on the diagram. Replace battery box cover and tighten the screw.

For Remote Controller



To install batteries into the Remote Controller, unscrew the screw on the battery box cover to open the cover. Insert 2 x "AA" 1.5V batteries (Not Included) into the battery box. Batteries should be placed as shown on the diagram. Replace battery box cover and tighten the screw.

(Notice: When inserting the batteries, you must insert according to the correct polarity, the Remote Control Gel Bead Tank and the Remote Controller won't function if batteries are reversed.)

Soak Gel Beads Steps

Pour 500 pcs of the bag gel beads into a container or and inject purified water for about 8.09 oz. After soaking the bullets for 4 hours or more, the diameter of the gel beast increases to 0.276 inches - 0.315 inches (the increase of water volume and the duration of immersion cannot make the gel beads continue to increase). Do not use hot water or microwave heating, as this will burn and heat cause the gel beads to shrink and can be repeatedly dropped into the water, making it larger again.

Operation Method of Gel Beads

Open the lid on the top of the tank, then pour in the right amount of gel beads, then close the lid.
[Note: do not add water when adding gel beads to prevent short circuit of the circuit version.]



ATTENTION: If the gel beads are not launched as usual, please move the car back and forth, and then try to launch again.

Performance Tips

1. Do not drive the Remote Control Gel Bead Tank on grass, sand or go through water.
2. Do not drive the Remote Control Gel Bead Tank in windy or rainy weather.
3. Do not drive the Remote Control Gel Bead Tank into any sharp object
4. Keep fingers, hair and loose clothing away from Remote Control Gel Bead Tank.

Care and Maintenance

Always use dry and soft cloth to clean this product.
Avoid this product from being exposed to sunlight or heat.
Avoid immersing these toys in water, otherwise, the electronic parts may be damaged.
Check the product regularly. If any damages are discovered, please stop using immediately, until it is completely repaired in good working condition.

IMPORTANT: BATTERY INFORMATION

For AA Batteries

⚠WARNING: TO AVOID BATTERY LEAKAGE

1) Be sure to insert the batteries correctly, and always follow the toy/game and battery manufacturers' instructions.
2) Do not mix old and new batteries or alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
3) Remove the batteries from the product.
4) Remove the battery if the product is to be left unused for a long period of time.

IMPORTANT: BATTERY INFORMATION

For AAA Batteries

⚠WARNING: TO AVOID BATTERY LEAKAGE

1) The batteries used with this product are small parts and should be kept away from small children who still put things in their mouths. If they are swallowed, promptly see a doctor and have the doctor phone American Association of Poison Control Centers (1-800-222-1222).
2) Always choose the correct battery size and grade of battery most suitable for intended use.
3) Do not mix old and new batteries, alkaline, standard (Carbon - Zinc) or rechargeable (Nickel-cadmium) batteries.
4) Clean the battery contacts and those of the device prior to battery installation.
5) Ensure the batteries are installed correctly with the regard to polarity (+ and -).
6) Always remove batteries if consumed or if product is to be left unused for a long time.

Warning

This product is suitable to be used by people who has operating experience in remote toy or aged no less than 8 years old.
Please do not put the product in your mouth to prevent choking hazard of small parts.
Please do not put the finger into available interspaces.
Please keep the product away from fire, water, heat, throwing, crashing or twisting it.
Please store the smaller-sized product accessories in places that are out of reach of children, in order to avoid the occurrence of accidents.
Avoid placing the batteries in places in high temperatures and avoid exposure to heat.
When young children are operating the product, it shall be ensured that the adults are guiding and making sure the product control is within the viewing range of the controller (or instructor) so that it makes the control of the toy more convenient.
Please make sure to turn off the power switch or switch off the power supplies of the toy, and remove the batteries from the product.
Please note that we won't take any responsibility for any wrong operation as this may result in severe injury or loss of property, and we cannot control the operating process during the time when the user assemblies or uses this product.
Once this product is sold, we won't be responsible for any safety responsibility during the time the user operates or uses controls this products.

FCC Statement

This device complies with the part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or experienced radio/ TV technician for help.

RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID: 2AOMS-ET-0780

FC

Distributed by 1816 Holdings, Inc.
701 Market Street, Suite 200
Philadelphia, PA 19106

Made In Shantou, China
Keep All Relevant Information for Future Reference

Item# ET-0780