55mm

80mm

CALDWELL® POWER CORDS

TOTALLY WIRELESS BLUETOOTH® HEARING PROTECTION

Instructions #1134909 Rev. A
Product #1102673

Start-up

0 Quick Start



1 Choose EarTips & EarWings

Large × 2

Medium × 2

Small × 2

Semi-closed EarTips
(They suit to do sports as allow you to notice ambient sound.)

Large × 2

Small × 2

Memory Foam EarTips
They suit to hearing protection in noise environments.

Large × 2

Medium × 2

Small × 2

EarWings
(They secure earphones in place.)

Gently push the earbud into your ear canal and adjust the EarWing to fit yourself.

2 How to Connect

Power off the earphones, then hold MFB for 5s to power on again and it will auto trigger pairing mode. (Earphones will auto trigger pairing mode upon any dis-connectivity with current device.

On cellphone, search for POWER CORDS and tap to connect.
(Earphones will auto re-connect to the last device in the connectivity records,if any.)

How to Charge



Low battery will be warmed by tone.
(LED will be solid red when charging and turn to blue once fully charged.)

Factory Setting

In power off status, hold MFB 10s until LED blinks red and blue promptly.

General Functions

Power-on:
hold MFB for 1s(LED will turn blue for 1s)

Power-off:
hold MFB for 3s(LED will turn red for 2s)

Answer Call
Tap MFB to answer incoming call(LED blinks blue promptly).

Ignore Call
Hold MFB for 2s to ignore incoming call.

Mute on/off
When calling, double tap MFB to mute on/off.

Skip Track
When playing, hold Vol+/- to skip track forward/backward.

Volume Control
When playing or calling or in ambient sound mode, tap Vol+/-.

Play/Pause
When playing, tap MFB to pause and tap it again to play.

Voice Assistant
When standby, triple tap MFB to activate voice assistant(like Siri).

Switch Audio Output
When calling, hold MFB for 1s to switch audio output between cellphone and earphones.

Three-way Calling & Switch

Tap MFB to answer incoming call from phone1. If another call is coming from phone2 in sync, tap MFB to put the first call on hold while activate the second one.
Double tap MFB to switch between active call and held call. Hold MFB for 2s to ignore call from phone 2 and keep the phone call of phone1.

Features

With advanced PiXart v5.0 Bluetooth chip, it is compatible with most digital devices.

Shark fin stabilizer offers extra secure wearing experience.

Mini body and light weight(13.15g) make wearing experience cool and comfortable

Basic Parameters

Bluetooth version: V5.0
Model:
Pairing name: POWER CORDS
Charging time: approx. 2hr
Weight: 13.15g
Standby time: approx. 100hr
Operation range: 10m
Bluetooth profiles: HFP/A2DP/AVRCP
Music time: approx. 6hr
Battery capacity: 3.7V 74mAh
Battery type: li-ion
Input parameter:5V ⎓ 100mA
(All technical specification should be subject to practical performance.)

Noise Reduction Rating 23 DECIBELS
(WHEN USED AS DIRECTED)

THE RANGE OF NOISE REDUCTION RATINGS IS 7 DECIBELS (MINIMUM) TO 30 DECIBELS (MAXIMUM) IF YOU DO NOT FOLLOW DIRECTIONS, YOU MAY BE EXPOSED TO NOISE LEVELS HIGHER THAN THE PROTECTED LEVEL.

AMERICAN OUTDOOR BRANDS CORPORATION
CYLUSB9B, 1907

Federal law prohibits removal of this label from a purchase

EPA

LABEL REQUIRED BY U.S.E.P.A. UNDER RULE 40 CFR PART 211 SUBPART B

NRR = 23dB Tested in accordance with ANSI S3.19-1974 In-ear

Frequency (Hz)	125	250	500	1000	2000	3150	4000	6300	8000
Mean Attenuation dB	29.6	25.2	27.1	28.6	35.6	38.7	37.6	41.7	42.6
Standard Deviation dB	3.4	2.7	2.2	3.6	2.9	3.9	3.6	3.3	3.7	2.9

The NRR calculated from these laboratory-based attenuation data is 23

Improper fit of this device will reduce its effectiveness in attenuating noise. Consult instructions for proper fit. The level of noise entering a person's ears when a hearing protector is worn as directed is closely approximated by the difference between the A-weighted environmental noise level and the NRR.

Examples:

1. The environmental noise level as measured at the ear is 91 dB(A).
2. The NRR is 23 decibels (dB)
3. The level of noise entering the ear is approximately equal to [91 dB − 23] 68 dB(A).

Tips

- Before use, please read the manual carefully and keep for future reference.
- Charge earplugs completely before first use.
- If the earplugs cannot be found by your device, please check whether it is in pairing mode. If left unconnected for a long time, the earplugs will exit pairing mode; if a procedure error of your device occurs, reboot it; if a procedure error of the earplugs occurs, reboot or reset it.

Warnings

- Never disassemble or modify your earplugs or charging case for any reason.
- Do not store earplugs or charging case in extreme temperatures (Below 32°F or 110°F).
- Recharge before use if earplugs are left unused for over two weeks.
- Do not use harsh chemicals to clean earplugs or charging case.
- Keep earplugs and charging case dry.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: For noise environments dominated by frequencies below 500Hz, the C-weighted environment noise level should be used.

Although hearing protectors can be recommended for protection against the harmful effects of impulsive noise, the reduction rating (NRR) is based on the attenuation of continuous noise and may not be an accurate indicator of the protection attainable against impulsive noise such as gunfire.

FCC Requirement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Note:The equipment has tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: READ ALL INSTRUCTIONS AND WARNINGS BEFORE USING THIS PRODUCT. FAILURE TO FOLLOW WARNINGS MAY RESULT IN SERIOUS PERSONAL INJURY, INCLUDING HEARING LOSS.