英文(面)

250mm

86mm

Truck Speaker

CC-MAK-CKT

Operation manual

Please read the manual before operating this product.

M&S Accessory Network declares that radio equipment CC-MAK-TRK is in compliance with Directive 2014/53/EU.
The EU Declaration of conformity is available at https://gabbagoods.com/pages/compliance-documents

Introduction

Thank you for choosing our Coca-Cola Truck Speaker! This guide will help you get started with your new device and ensure you make the most out of its features.

Please use this manual to familiarize yourself with the functionality of your other devices before using this product.

Compatible with most Bluetooth® enabled devices.

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc.

Package Contents

Bluetooth Truck Speaker

USB-C Charging Cable

Instruction Manual

1

Safety Rules

1 Please follow the rules depicted in this manual closely to ensure your safety. Before using the product, we would strongly encourage you to read through this user manual.

2 Be wary of any edges, uneven surfaces, metal parts, accessories, and its packaging to prevent any possible injury or damage.

3 Do not modify, repair, or dismantle the product. Doing so may result in fire, electric shock, complete breakdown of the product, etc. All of which are not covered under warranty.

4 Do not use any diluent or volatile liquid to clean the product.

5 Do not use the product in a hazardous location.

Support

If you have problems with your device, please consult the instructions in this manual.

Manufacturer Warranty

We stand by our products! That's why we guarantee them from any functional defects for one year from the original date of purchase. Should you have an issue please call us at (877)995-8505 or email us at info@mnsbrands.com

2

Product Diagram

1. ON/OFF
2. Forward Button
3. Previous Button
4. Mode/Function Button
5. LED Screen/Indicator Light
6. AUX Port
7. Power Port
8. USB
9. Micro SD Card Slot



3

Buttons & Functions

Power Button M/⏻
- Long Press: Power On button for 2-3 seconds. The speaker will automatically power on at 50% volume.
- Short Press: Pause music or answer/hang up phone calls.

Power Indicator (LED LIGHT)
- Power On: The indicator is blue.
- Connected to Device: The indicator remains solid blue.
- Low Battery: The indicator flashes red.
- Charging: The indicator stays red.

Previous/Volume Down Button ⏮/V−
- Short Press: Decrease volume.
- Long Press: Play the previous song.

Next/Volume Up Button ⏭/V+
- Short Press: Increase volume.
- Long Press: Skip to the next track.

Mode Button P/P
- Short Press: Switch between FM Radio and Bluetooth mode.
- Double Press: Disconnect from the currently paired device.

4

Charging The Speaker

- To charge the speaker, plug the provided Type-C cable into a power outlet and the other end into the speaker's charging port.
- When the battery is low, the power indicator will flash red.
- While charging, the power indicator will stay red.
- Once the speaker is fully charged, the indicator light will turn off.

Pairing with a Bluetooth Device

- Turn on the speaker by long-pressing the power button.
- The power indicator will flash blue, indicating the speaker is in pairing mode.
- On your device, enable Bluetooth and select "Truck Speaker" from the available devices list.
- Once connected, the power indicator will stay solid blue.
- The speaker will automatically reconnect to the last paired device when powered on.

5

Notes

- Battery Life: For optimal performance, ensure the speaker is charged fully before the first use.
- FM Mode: If using FM Radio mode, ensure you have connected an auxiliary cable or antenna for the best signal.

Product Specifications

Bluetooth: Version 5.3
Bluetooth distance: 10M
Battery: 1200mAh
Music play time: 3-4 hours
Charging time: 2-3 hours
Power: 3W*2
Horn: φ52mm 4Ω3W*2
Port: Type-C
Input: 5V 1A"

6

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and

(2)This device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications not expresssly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

7

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC ID: 2AFXXGG-MAK

8

COCA-COLA, COKE, the Contour Bottle Design, the Dynamic Ribbon Device and the Red Disc Icon are trademarks of The Coca-Cola Company and, in Canada, Coca-Cola Ltd. ©The Coca-Cola Company. All rights reserved. Produced by M&S Accessory Network Corp. under a trademark license from The Coca-Cola Company.

CC-MAK-CKT

Designed in the U.S.A. | Made In China

Manufactured, marketed, and distributed under license by M&S Accessory Network Corp.,
10 W. 33rd St., New York, NY 10001

Designed in the U.S.A | Made in China.

For support call: (877) 995-8505 or

Email: info@mnsbrands.com

www.mnsbrands.com

9