ADDASOUND
SOUND CHANGING THE WORLD

ADDASOUND Denmark A/S
Skalhuse 5
DK-9240 Nibe
Denmark

CE FC RoHS

INSPIRE18
Professional wireless headset
User Guide
专业无线耳机
用户手册

Thank you for choosing ADDASOUND!

To ensure an optimum performance and safety, please read this user manual carefully before using the product.
Keep this user manual safe for future references.

Contents

1 . GENERAL SAFETY INFORMATIONS:
1.1. WARNINGS
AUDIO PRODUCT WARNING!⚠

PERMANENT HEARING LOSS MAY RESULT FROM LONG-TERM EXPOSURE TO SOUNDS AT HIGH VOLUMES. USE AS LOW A VOLUME AS POSSIBLE.
Avoid prolonged use of headsets at excessive sound pressure levels.
You can reduce the risk of hearing damage by following these safety guidelines:

Prior to using this product follow these steps
• Before using the product, turn the volume control to its lowest level,
• Put the headset on, if applicable
• Slowly adjust the volume control to a comfortable level.

During the use of this product
• Keep the volume at the lowest level possible
• If increased volume is necessary, adjust the volume control slowly
• If you experience discomfort or ringing in your ears, immediately discontinue using the product.

With continued use at high volume, your ears may become accustomed to the sound level, which may result in permanent damage to your hearing without any noticeable discomfort.

1.2. ATTENTION ⚠

• If you have a pacemaker or other electrical medical devices, consult your physician before using this product.

• This package contains small parts that may be hazardous to children. Always store the product out of reach of children. The bags themselves or the many small parts they contain may cause choking if ingested.

• Never try to dismantle the product yourself, or push objects of any kind into the product, as this may cause short circuits which could result in a fire or electric shock.

• None of the components can be replaced or repaired by users. Only authorized dealers or service centers may open the product. If any parts of your product require replacement for any reason, including normal wear and tear or breakage, contact your dealer.

• Avoid exposing your product to rain or other liquids.

• Keep all products, cords, and cables away from operating machinery.

• Observe all signs and instructions that require an electrical device or RF radio product to be switched off in designated areas such as hospitals or aircraft.

• If the product overheats, has been dropped or damaged or has been dropped in a liquid, discontinue use.

• Dispose of the product according to local standards and regulations (See http://www.addasound.com).

Remember: Always drive safely, avoid distractions, and follow local laws! The use of a speaker while operating a motor vehicle may be regulated by local laws. Using a headset while operating a motor vehicle, motorcycle, watercraft, or bicycle may be dangerous, and is illegal in some jurisdictions, just as use of this headset with both ears covered while driving is not permitted in certain jurisdictions. Check with your local authorities.

1.3. BATTERY

• For your protection and comfort, ADDASOUND Denmark A/S has implemented protective measures in this product designed to maintain safe volume levels and ensure that the product operates in compliance with government safety standards.

• In case of power source cut off, the back-up battery can hold the device in place for 20-30 minutes.

• The window cleaner can be used on frameless or framed surfaces. It has integrated falling sensors and obstacle detection function.

1.4. CHARGING

CHARGER CARE: Please observe the following if the product is supplied with a charger.

• Do not attempt to charge/power your product with anything other than the charger provided. The use of any other types may damage or destroy the product and could be dangerous. Use of other chargers may invalidate any approval or warranty. For the availability of approved enhancements, please check with your dealer.

• Charge/power the product according to the instructions supplied with the product.

Important: Please refer to the user manual for a description of the charging status indicator lights. Some products cannot be used while charging.
Charger warning!

• Do not use a wall charger with more than 5V and 2A output.

• When you disconnect the power cord or any enhancement, grasp and pull the plug, not the cord. Never use a charger that is damaged.

• Do not attempt to disassemble the charger as it may expose you to dangerous electric shock.

1.5. MAINTANENCE

• Unplug the product or charger before cleaning
• Clean the product by wiping with a dry or slightly damp cloth. The cord and charger may only be dry dusted.

2. PRODUCT OVERVIEW
2.1. PRODUCT DIAGRAM

Volume down
(short or long press)

Volume up
(short or long press)

Mute/unmute microphone

LED status indicator
(4 bars in total)

Call answer/end
(Microsoft Teams call answer/end)

USB-C charging
(full charge takes about 3 hours)

On/Off/Bluetooth

OFF BT

2.2. MAIN FUNCTIONS

• Clear sound thanks to the microphone equipped with background noise cancelling technology.
• Designed for professional use – call-center & online conferences.
• Multipoint technology – The headset can be connected to two devices at the same time and receive calls from either one.
• Increased wireless range of up to 30 meters.
• Synthetic leather and low weight offer increased comfort.
• Easy to use control buttons for answer/reject, volume, microphone mute.
• Increased battery autonomy, 24 hours talk time and up to 20 days of standby time.
• Multiple connections, direct using Bluetooth, with Bluetooth dongle, wired using the included USB A to Type-C cable (audio over USB mode).
• Multifunctional LED indicator offering key informations at a glance.

2.3. IN THE BOX

ADDASOUND Bluetooth Dongle

Inspire 18

User manual

USB-A to USB-C charging cable

Carrying bag

2.4. WEARING THE HEADSET

Right   Left

Adjusting the headset:
The headband and microphone can be adjusted to fit comfortably and for optimal use.


2.5. NOTES - For full technical specifications please check chapter 5

3. CONNECTING THE HEADSET
3.1. DIRECT CONNECT WITH BLUETOOTH

• Slide the on/off switch to the Bluetooth position and hold it there until the 1 and 4 indicators flash blue alternately.
• Go to the smartphone Bluetooth menu and select Inspire 18 from the list of available devices.

3.2. USING INCLUDED BLUETOOTH DONGLE

• Plug the included Bluetooth Dongle into a USB port on your PC/laptop. The Inspire 18 and Bluetooth Dongle are pre-paired and are ready to use right out of the box. The maximum Bluetooth range is about 30 meters.
• To listen to music with headphones, you may need to set the Bluetooth Dongle as the default playback device in the audio settings of your computer's operating system.
NOTE: If need to re-pair the dongle with the headset, please follow the instructions below:
• Press and hold the reset button on the Bluetooth Dongle until the LED indicator flashes red and blue alternately.
• Turn the headset switch to the Bluetooth position and keep it in this position until the blue LED indicators 1 and 4 of the headset flash alternately.
• Wait for the Inspire 18 and Bluetooth Dongle to pair again. After the pairing is completed, the LED indicator stops flashing.

3.3. WIRED, USING INCLUDED CABLE

• Plug the charging cable into the headset and plug it directly into the USB port powered by the computer.
• The headset will automatically switch from wireless mode to wired mode. Now the Inspire 18 can be used as a USB headset.

4. HOW TO USE

4.1. POWERING ON/OFF, FUNCTIONS

• Power on/off - Slide the on/off switch to the ON or OFF position to turn the headset on or off.

|	
Answer call/Hang up call	Press Call/Answer button
Reject call	Long press Call/Answer button for 3 sec
Play/Pause music	Press Call/Answer button
Activate voice assistant	When not in active call, long press Call/Answer button for 3 sec
End current call and answer new call	Press Call/Answer button
Hold current call and answer new call	Long press Call/Answer button for 3 sec
Switch between calls	Long press Call/Answer button for 3 sec
Volume up/Volume down	Use the dedicated buttons during call or music play

4.2. SYSTEM SUPPORT

• Windows 7, 8, 10,11 support Skype for Business to answer and hang up; support MS Teams to answer and hang up; support USB drive-free.
• Mac support Skype for Business to answer and hang up; support MS Teams to answer and hang up; support MS Teams button function; support USB drive-free.
• Android support phone answering and hanging up, music playback and other functions.
• iOS support phone answering and hanging up, music playback and other functions.

4.3 LED INDICATORS

LED status indicator (4 bars in total)

●●●● When the power is turned on, the 4-bar indicator lights turn blue in sequence (the battery is fully charged)

LED status indicator (4 bars in total)

○●●● When the power is turned on, the 3-bar indicator lights turn blue in sequence (indicating that the battery has consumed one bar of power, and so on)


LED status indicator (4 bars in total)

¤ ○ ○ ¤ In pairing mode, the 1 and 4 indicators flash blue alternately

LED status indicator (4 bars in total)

○ ¤ ¤ ○ When an incoming call comes in, the 2 and 3 lights alternately flash blue

LED status
indicator
(4 bars in total)

○●●○ During a call, the indicator
lights 2 and 3 are solid blue

LED status
indicator
(4 bars in total)

●○○○ 1 The indicator light is solid
red, indicating that the battery power
is lower than 20%

LED status
indicator
(4 bars in total)

¤ ○ ○ ¤ Do not disturb mode, 1 and
4 lights alternately flash red (long
press the microphone mute button for
3 seconds to turn on/off, let the
people around you know that you are
busy)

LED status
indicator
(4 bars in total)

○●●○ The microphone is muted,
and the 2 and 3 indicators are solid
red

4.4. CHARGING

• The headset can be charged using a compatible 5V output charger. It is
recommended to use the included charging cable to charge the headset.
• Plug the charging cable into the headset and plug it directly into the USB
port powered by the computer for charging.

4.5. TROUBLESHOOTING

Issue	Inspection Method	Solution
Not working	Check whether the USB interface is powered normally	The USB interface is powered normally
Can not boot	Bluetooth headset battery is low	Use the Bluetooth headset charging cable to charge the headset and then try to turn it on
	The keystroke is not long enough	The boot time of the Bluetooth headset is to press and hold the mute button for 3 seconds
Although the headphones are connected to the computer, nothing is heard .	Check the bluetooth headset option	In the lower right corner of the computer desktop, right-click the speaker, click the playback device option, and check whether the device Voice Pro Wireless is set as the default device
	Check the USB Dongle option	In the lower right corner of the computer desktop, right-click the speaker, click the playback device option, and check whether the device Bluetooth dongle is set as the default device
Bluetooth headset and mobile phone cannot be paired	The bluetooth headset is not paired	Check whether the bluetooth headset is in a state of alternating red and green lights; whether the flashing frequency of the lights is normal
	Is the Bluetooth function of the mobile phone turned on?	Check if the Bluetooth Pisces logo appears on the phone screen
Bluetooth headset is connected but no sound	The bluetooth headset is not properly connected to the phone	Re-pair the bluetooth headset with the phone
	The bluetooth headset is out of range	Keep the Bluetooth headset within the surrounding range of the mobile phone (within 30m), and there should be no obstacles within the range.

5. TECHNICAL SPECIFICATIONS

Bluetooth version:	v5.2
Frequency:	2.4GHz, Class 1
Wireless range:	30m
Supported profiles:	A2DP, AVRCP, HSP, HFP
Hearing protection:	Support sound limits up to 118 dBSPL
Multipoint technology:	Pair and maintain connections with two devices at the same time, remember up to 8 devices
Wired connection:	Included USB cable 1m (audio over USB mode)
Audio codecs supported:	SBC
Drivers size:	32mm
Ear cushions:	Leatherette
Speaker frequency range:	20Hz - 20KHz
Speaker impedance:	32Ω
Speaker sensitivity:	102dB (±3dB)
Speaker rated power:	10mW
Microphone:	2 microphones, noise cancelling technology
Microphone type:	Analog silicon microphone
Microphone frequency range:	20Hz-14kHz
Microphone sensitivity:	-38dB @ 1KHz x 2
Microphone impedance:	300Ω @ 1kHz
Control functions:	Call answer/end, Music play/pause, Volume up/down, Mic mute, Power on/off/Bluetooth pairing
LED indicator:	Multifunctional
Power supply:	USB Type-C charging port
Battery capacity:	270mAh, Lithium Ion
Talk time:	22 hours
Standby time:	Up to 20 days
Charge time:	Approx 3 hours
Headset dimensions:	193mm x 165mm x 70mm
Headset weight:	158g
Color:	Black
Package includes:	1 x ADDASOUND Inspire 18 headset 1 x Bluetooth USB dongle 1 x USB A to USB Type-C cable 1 meter 1 x Carrying bag

Disposal and recycling information

The crossed-out wheeled-bin symbol on your product, battery, literature or packaging   reminds you that all electronic products and batteries must be taken to separate waste collection points at the end of their working lives; they must not be disposed of in the normal waste stream with household garbage. It is the responsibility of the user to dispose of the equipment using a designated collection point or service for separate recycling of waste electrical and electronic equipment (WEEE) and batteries according to local laws. Proper collection and recycling of your equipment helps ensure EEE waste is recycled in a manner that conserves valuable materials and protects human health and the environment, improper handling, accidental breakage, damage, and/or improper recycling at the end of its life may be harmful for health and environment.

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help
Important Note:
Radiation Exposure Statement
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0mm between the radiator and your body.
This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

感谢您选择艾德声！

为确保最佳性能和安全，请在使用本产品前仔细阅读本用户手册。
在使用本产品之前，请仔细阅读本用户手册。
请妥善保管本用户手册，以备将来参考。

目录

1. 一般安全信息：

1.1. 安全警示！
音频产品须知！⚠

长期聆听过高音量的声音可能会导致永久性听力损失，使用时尽可能调节到较低的音量。请尽量避免在声压级过高的情况下长时间使用耳机。

您可以通过参考以下安全指南来降低听力受损的风险：

使用本产品前，请按照下列步骤操作：

• 使用产品前，请将音量调到最低水平

• 调整好舒适度并戴上耳机

• 缓慢地将音量调整到舒适水平

使用本产品的过程中：

• 请将音量保持在尽可能低的水平

• 如果需要调大音量，请缓慢调整音量控制旋钮

• 如果您感到不适或耳鸣，请立即停止使用该产品。

在高音量水平下持续使用，您的耳朵可能会习惯于该音量，这可能会对您的听力造成永久性损害，而不会出现任何明显的不适。

1.2. 注意 ⚠

• 如果您有心脏起搏器或其他电子医疗设备，请在使用本产品前咨询您的医生。

• 包装袋内含有可能对儿童有害的小部件，请务必将产品存放在儿童接触不到的地方。如果误食包装袋或包装袋内的小部件，可能会导致窒息。

• 切勿尝试自行拆卸产品，或将任何物体推入产品，否则可能会导致短路，从而引发火灾或触电。

• 用户不能自行更换或修理任何组件，只有经授权的经销商或服务中心才能打开产品。如果产品的任何部件因任何原因需要更换，包括正常磨损或破损，请联系您的经销商。

• 避免产品接触到雨水或其他液体。

• 尽可能使产品、电线和电缆远离运行中的机器设备。

• 在医院或飞机等指定区域，请遵守标志和指示的要求，关闭电子或射频无线电设备。

• 如果产品过热、坠落、损坏或掉入液体中，请停止使用。

• 根据当地标准和规定处理产品（参见 http://www. addasound .com）.

切记：务必安全驾驶，避免分心，并遵守当地法律法规！

当地法律法规可能会对驾驶机动车辆时使用扬声器作出相关规定。在驾驶机动车、摩托车、水上交通工具或自行车时使用耳机可能会有危险，在某些司法管辖区域这样的行为甚至是非法的，正如在某些司法管辖区不允许在开车时遮蔽双耳使用耳机一样。相关问题请咨询当地政府。

1.3.电池

• 为了您的安全和舒适，ADDASOUND Denmark A/S 在本产品中实施了保护措施，旨在保持安全的音量水平并确保产品在符合政府安全标准的情况下运行。
  安全标准：

• 在电源被切断的情况下，备用电池可供设备继续维持 20-30 分钟。

## 1.4.充电

充电器保养：如果产品随附充电器，请注意以下事项：

• 请勿尝试使用提供的充电器以外的任何其他设备为您的产品充电或供电。使用任何其他类型的充电器都可能会损坏或毁坏产品，并且可能造成危险。使用其他充电器可能会使已获得的批准或已有的保修失效。如需已获得批准的增强型充电器，请咨询您的经销商。

• 按照产品随附的说明为产品充电/供电。
  重要提示：有关充电状态指示灯的说明，请参阅用户手册。某些产品在充电时无法使用。

• 请勿使用输出电压超过 5V 或输出电流超过 2A 的壁式充电器。

• 当您断开电源线或任何增强装置时，请抓住并拔下插头，而不是电源线。切勿使用损坏的充电器。

• 请勿尝试拆解充电器，否则可能会有触电危险。

1.5. 维护

- 清洁前请断开产品的电源或拔下充电器的插头。
- 清洁时用干燥或微湿的布擦拭产品,电源线和充电器只能用干布擦拭。

2. 产品综述

2.1. 产品图示

音量减小
(短按或长按)

麦克风静音/解除静音

LED状态指示灯
(四个)

电话接听/挂断
(微软Teams接/挂)

音量增大
(短按或长按)

USB-C充电口
(充满电约需 3 小时)

开机/关机/蓝牙配对

### 2.2. 主要功能

- 卓越的双麦克风降噪技术可滤除大部分背景噪音,为通信提供安全保障。
- 钕磁体扬声器可提供更强大、更丰富的声音。
- 符合人体工程学的设计和蛋白皮耳垫提供全天舒适感。
- 解放双手,无线通讯距离可达30米。
- 即插即用,通过蓝牙适配器或USB连接线在PC上快速部署。
- 同时连接两个蓝牙设备,最多记住八个蓝牙设备。
- 自动激活语音提示提醒您操作状态和电池电量。
- 通话时间长达22小时,省电设计可在没有蓝牙连接上设备5分钟后关闭耳机。
- 轻松管理通话和音乐控制、蓝牙配对、音量+、音量-、将耳机静音。

2.3. 包装盒

蓝牙适配器

蓝牙耳机Inspire18

使用说明书

充电数据线

尼丝绒袋

2.4. 如何佩戴耳机

右　　　　　　左

如何调整耳机：

耳机头带是可以抽拉两边拉杆仓调整大小以优化使用；麦克风杆可以旋转和弯折调整到合适的位置以优化使用。


2.5. **说明** - 详细的技术规格参数请查阅第5章。

3.耳机连接

3.1. 直接蓝牙连接

- 将开启/关闭开关滑到蓝牙档位置，并保持在该位置，直到1和4指示灯交替闪烁蓝光。
- 转到智能手机蓝牙菜单并从可用设备列表中选择INSPIRE18。

3.2. 使用配套的蓝牙适配器（ADDA BT220）连接

- 将随附的蓝牙适配器插入电脑上的USB端口。INSPIRE18与蓝牙适配器已经预先配对，开箱即可使用。蓝牙距离最远约30米左右。
- 若要使用耳机听音乐，您可能需要在电脑操作系统的音频设置中将蓝牙适配器设置为播放设备。

注：若需要对INSPIRE18和蓝牙适配器重新进行配对，请按照下面介绍操作：

- 长按蓝牙适配器上重置按钮并保持，直到LED指示灯红蓝交替闪烁。
- 将耳机开关拨到蓝牙档并保持在该位置，直到耳机的LED指示灯1和4蓝色指示灯交替闪烁。
- 等待INSPIRE18和蓝牙适配器重新进行配对，配对完成后，LED指示灯停止闪烁。

3.3. 有线，使用附带的电缆

• 将充电线插入耳机，然后直接插入电脑供电的 USB 端口。

• 现在，inspire18 可以作为 USB 耳机使用了。

4. 如何使用耳机

4.1. 开机/关机，功能介绍

• 开机/关机 - 滑动开关机开关到ON或者OFF的位置来开或者关耳机。

| 电话接听/挂断	轻触接听/挂断按钮
拒接来电	长按接听/挂断按钮3秒
音乐播放/暂停	轻触接听/挂断按钮
启动语音助手	不在通话中,长按接听/挂断按钮3秒
结束当前来电并接听新来电	轻触接听/挂断按钮
保持当前来电并接听新来电	长按接听/挂断按钮3秒
切换不同来电	长按接听/挂断按钮3秒
音量增大/减小	在通话或播放音乐时使用专用按钮

4.2. 系统支持

• Windows 7、8、10、11 支持Skype for business接听挂断；支持TEAMS接听挂断；支持USB 免驱。

• Mac,支持Skype for business接听挂断；支持TEAMS接听挂断；支持Teams button功能；支持USB免驱。

• Android,支持电话接听挂断,音乐播放等功能。

• iOS,支持电话接听挂断,音乐播放等功能。

4.3. LED灯指示

LED 状态
指示灯
(共 4 条)

●●●●
电源开启,4格指示灯依次点亮蓝光(电池处于满电状态)

LED 状态
指示灯
(共 4 条)

○●●●
电源开启,3格指示灯依次点亮蓝光(表示电池已消耗一格电量,依次类推)

LED 状态
指示灯
(共 4 条)

¤ ○ ○ ¤
配对模式,1和4指示灯交替闪烁蓝光

LED 状态
指示灯
(共 4 条)

○ ¤ ¤ ○
来电时,2和3指示灯交替闪烁蓝光

LED 状态
指示灯
(共 4 条)

○●●○
通话中, 2和3指示灯蓝光长亮

LED 状态
指示灯
(共 4 条)

●○○○
1指示灯长亮红色, 表示电池电量低于20%

LED 状态
指示灯
(共 4 条)

¤○○¤
免打扰模式, 1和4指示灯交替闪烁红光

LED 状态
指示灯
(共 4 条)

○●●○
麦克风静音, 2和3指示灯红色长亮。

4.4. 充电

- 可使用兼容的5V电压输出的充电器对耳机进行充电。建议使用随附的充电线缆给耳机充电。
- 将耳机插上充电线缆, 直接插入电脑端供电的USB端口进行充电

4.5. 充电

故障现象	检查方法	解决方法
不工作	检查USB接口是否正常供电	USB接口正常供电
无法开机	蓝牙耳机电池电量低	用蓝牙耳机充电线给耳机充电后再尝试开机
	按键时间不够长	蓝牙耳机开机时间为长按静音键3秒
连接电脑话说无声	检查蓝牙耳机麦选项	电脑桌面右下角,右击喇叭,点击播放设备选项,查看设备ADDA INSPIRE18是否设置成默认设备
	检查USB Dongle选项	电脑桌面右下角,右击喇叭,点击播放设备选项,查看设备ADDA BT220是否设置成默认设备
蓝牙耳机与手机无法配对	蓝牙耳机不是处于配对状态	检查蓝牙耳机是否处于红绿灯交替闪烁状态;灯的闪烁频率是否正常
	手机蓝牙功能是否打开	检查手机屏幕上是否出现蓝牙双鱼标志
蓝牙耳机已连接却没有声音	蓝牙耳机未与手机妥善连接	让蓝牙耳机与手机重新配对
	蓝牙耳机没有在工作范围之内	保持蓝牙耳机位于手机周边范围(30m以内),范围内不得有障碍物阻

5. 技术规格

蓝牙版本	V5.2
频率	2.4GHz, Class1
无线通信距离	30米
支持协议	A2DP,AVRCP,HSP,HFP
听力保护	≤118dBSPL
多点连接技术	同时连接两个蓝牙设备,最多记住八个蓝牙设备。
有线连接	附赠1米长USB连接线(可以通过该线连接让无线耳机变为USB耳
支持音频编码	SBC
穿戴方式	头戴式
扬声器直径	Ø32mm
扬声器频响	20Hz - 20kHz
扬声器阻抗	32Ω
扬声器灵敏度	102dB(±3dB)
扬声器功率	10mW
麦克风	双麦克风降噪技术
麦克风类型	硅麦
麦克风频响	20Hz - 14kHz
麦克风阻抗	300Ω@1kHz
麦克风灵敏度	-38dB@1kHz x 2
控制功能	电话接听/挂断、音乐播放/暂停、音量增大/减小、麦克风静音/静音关闭、开机/关机/蓝牙配对
LED指示灯	多功能
电源提供	USB Type-C 充电端口
电池类型容量	270mAh,聚合物锂电池
通话时间	长达22小时
待机时间	长达20天
充电时间	充满电3小时
耳机尺寸	193mm x 165mm x 70mm
耳机重量	158g
耳机颜色	黑色
包装盒内包含	1 x ADDASOUND Inspire18耳机　　1 x 蓝牙适配器ADDA BT220 1 x 1米长USB-C转USB-A连接线　　1 x 尼丝绒包装袋

处置和回收信息

在您的产品、电池、资料或包装上的打叉轮式垃圾桶符号提醒您，所有电子产品和电池在其使用寿命结束时，必须单独送到垃圾分类收集点，不得将他们与生活垃圾一起丢弃。用户有责任根据当地法律法规，将废弃电子电器设备和电池送至指定收集点或回收服务机构，对其进行单独回收处理。妥善收集和回收您的废弃电子电器设备，既能节约宝贵的材料，又能保护人类健康和环境。处理不当造成意外破损、损坏和/或在其使用寿命结束时回收不当，都可能危害人类健康和环境。