ART DEPARTMENT			
Job # / Filename 2017-07-04_BS_RockslideMonster_RedBlu_Blk		Product Line Black Series	
Designer Dinh Tran / Luna Qin	Brand Manager Lisa Nagamoto	Finished Size 16.3" L x 9.45" D x 8.89" H - 41.4cm L x 24cm D x 22.57cm H	
File Format Adobe Illustrator CC (live)/CS4 (OL)	Fonts Helvetica, Univers, Din Next	Color (Spot or 4C) 4 Color Process	# of Colors 4
Printing Process / Finishing Matte PP Coating		Comments	

MerchSource

All copyright, trademark and patent rights or any other intellectual property rights or material associated with the content provided herein, and the selection, coordination and arrangement of such content, are owned exclusively by MERCHSOURCE LLC, or any third party licensors. The use or release of any copyrights, trademarks, patents or any other intellectual property or materials, except as permitted herein, is expressly prohibited. Any infringements shall be prosecuted to the fullest extent of the law, both foreign and domestic.

THE BLACK SERIES™

rc all-terrain vehicle

monster rockslide

Flexible chassis designed for extreme rock climbing

MULTI-DIRECTIONAL OPERATION

WIRELESS PERFORMANCE

Knobby tires for rugged all-terrain performance

spring-loaded shocks for hard jumps and turns

LONG DISTANCE 2.4 GHz RACE MULTIPLE VEHICLES

Full function wireless remote control

Operation requires 6 "AA" batteries (not included) for car and one 9v battery (not included) for radio controller. See bottom panel for complete operating instructions. Colors and styles may vary.

VERSATILE — KNOBBY TIRES FOR RUGGED ALL-TERRAIN PERFORMANCE

COMPETITIVE — RACE MULTIPLE VEHICLES FOR QUICKER RESPONSE LONG DISTANCE RACING

WIRELESS — REMOTE CONTROL FOR FULLY FUNCTIONAL RACING ACTION

OVERSIZED GRIP TIRES

THE BLACK SERIES™

SPRING LOADED SHOCKS FOR MAXIMUM OFF-ROAD ACTION!

BATTERY OPERATED PLAY VEHICLE

AGES 6 AND UP

⚠ WARNING! CHOKING HAZARD - Small parts. Not suitable for children under 3 years.

MONSTER ROCKSLIDE

MONSTER ROCKSLIDE

REMOTE CONTROL STICKER

LONG DISTANCE 2.4 GHz RACE MULTIPLE VEHICLES

EXTREME GRIP KNOBBY TIRES FOR EXTREME ROCK CLIMBING

rc all-terrain vehicle

monster rockslide

exciting all-terrain off road racing

WIRELESS RC ACTION!

THE BLACK SERIES™

rc all-terrain vehicle

monster rockslide

SPRING LOADED SHOCKS FOR MAXIMUM OFF-ROAD ACTION!

OVERSIZED GRIP TIRES

rc all-terrain vehicle monster rockslide

BATTERY INSTALLATION

Truck requires 6 "AA" 1.5V batteries (not included). The remote control requires 1 "9V" battery (not included).

- Carefully remove items from package.
- Locate the battery compartment on the bottom of the truck and the battery compartment on the remote.
- Locate the battery compartments and remove the battery cover doors.
- Insert 6 "AA" 1.5V batteries in truck, and 9V batteries into controller and replace the battery compartment doors to secure.

SAFETY PRECAUTIONS

- Do not operate during thunderstorms or rain.
- Avoid water and moisture damage to electronics.
- Do not submerge truck or controller in water.
- Never operate truck on the street or highway.
- Adult supervision is recommended when operating truck.
- Remove all batteries when not in use to avoid accidental operation.
- Never operate truck near people, pets or crowded areas, and do not use people or animals as obstacles.
- Do not run truck into furniture, objects or hard surfaces, as this will cause damage to both the objects and the truck.
- Avoid water and moisture damage to electronics, tires, gears and motor when the truck is switched to "ON" position.
- Do not leave truck or transmitter near sources of heat or under direct sunlight for long periods of time.
- Do not leave truck or transmitter outside overnight. Dampness is harmful to electronic components.

BASIC OPERATION

HOW TO PAIR REMOTE AND CAR:
1. Turn on the car and Remote Controller, they will pair automatically.
2. When operating more than 1 vehicle at a time, turn on each vehicle and remote pair separately to allow remotes to pair with the correct vehicle.

- Switch both the vehicle and controller power switches to the "ON" position.
- Adjust the steering alignment level located on the bottom of the vehicle (between front wheels) if the vehicle does not run straight when moving forward.



BATTERY WARNING:

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Install batteries using the correct polarity. Do not exceed the supply voltage.
- Remove batteries when the toy is not in use for an extended period of time. Dispose of old batteries safely according to local laws, and local laws. Do not dispose of batteries as a toy. Very rare explosion hazard if batteries are not disposed of properly. Do not short circuit the supply terminals. Do not charge non-rechargeable batteries. Remove rechargeable batteries from the toy before charging. Only use batteries of the same or equivalent type as recommended in the instructions. Insert batteries with the correct polarity. Remove exhausted batteries from the toy. Remove batteries if the toy is not used for a long time. Do not dispose of batteries in fire. Very rare explosion hazard if batteries are not disposed of properly. Do not short circuit the supply terminals. Do not charge non-rechargeable batteries. Remove rechargeable batteries from the toy before charging. Only use batteries of the same or equivalent type as recommended in the instructions. Insert batteries with the correct polarity. Remove exhausted batteries from the toy. Remove batteries if the toy is not used for a long time. Do not dispose of batteries in fire.
- Batteries (cells or batteries made from a combination of cells) shall be inserted with correct polarity.
- Non-rechargeable batteries shall not be charged.
- Rechargeable batteries shall only be charged under adult supervision.
- Exhausted batteries shall be removed from the toy.
- Supply terminals shall not be short circuited.
- Batteries of different types or new and used batteries shall not be mixed.
- Batteries shall be inserted with correct polarity.
- Rechargeable batteries shall be removed from the toy before being charged.
- Non-rechargeable batteries shall not be charged.
- Exhausted batteries shall be removed from the toy.
- Batteries shall be removed from the toy when not in use for an extended period of time.
- Batteries shall be inserted with correct polarity.
- Rechargeable batteries shall only be charged under adult supervision.
- Non-rechargeable batteries shall not be charged