Manual

TABLE OF CONTENTS

1.Product Appearance And Accessories ---- 2
1.1.Product Appearance And Accessories ---- 2
1.2.Product Structure And Button Instruction ---- 3

2.Installation steps ---- 6
2.1.Install TF Card ---- 6
2.2.Install Battery ---- 6
2.3Fixed Camera ---- 7
2.4.Install Power Source ---- 8
2.5.The Working Instructions Of Indicating Light ---- 9

APP Instructions ---- 9
3.1.APP Download ---- 9
3.2.APP Login ---- 9
3.3.User Registration ---- 10
3.4.Retrieve / Change Password ---- 10
3.5.Mobile Phone Connecting Device ---- 11
3.6.Camera Setting ---- 14
3.7.Real -Time Preview ---- 14
3.8.Video Playback ---- 15
3.9.Camera Setting ---- 16
3.10.APP Management ---- 18

4.Note ---- 24

5.FCC STATEMENT ---- 25

Product Appearance And Accessories

1.1.) Product Appearance And Accessories

1.2.)Product Structure And Button Instruction



Installation steps

2.1.) Install TF Card

Open the camera bottom cover and insert TF card into card slot according to the direction shown in the picture. Pull out from card slot side of the card, Do not put in wrong direction.

2.2.) Install Battery

Open the camera bottom cover, turn the battery buckle into the battery slot direction, then put the battery into the battery slot, close the buckle. Turn the fixed screw switch to the lock direction, tighten the screw to the bottom cover.

2.3) Fixed Camera

1. Select Fixed: Install the camera stand into the camera by fixed screw, then adjust the camera direction manual shake, it's the stand into fixture by using screw.

2. Bell Fixed: Put the bell through the bell clip of the back of the camera, then it's another way to fix it.

2.4.) Install Power Source

Open the camera bottom cover turn the base power switch to the open direction, then the camera will be power on, close the bottom cover, insert the power plug into hole's 5V jack, connect the other end of power adapter to the 110V-240V socket, camera enters the connecting mode (about 40S), then the indicator light will flash.

2.5) The Working Instructions Of Indicating Light

Indicator Light	Status
Red Light Long Bright	Starting Mode, WiFi connecting
Flashing Red Light Short 0.1S	TF Card is abnormal
Flashing Red Light Long 1S	Upgrading through TF Card

Notice: Maximum support 128GB TF Card. Must use Class 10 or higher TF Card. Recommend to use Samsung or SanDisk brand TF Card. Do not support formatting TF Card in camera. Maximum support 64 GB for Android system, 128 GB for IOS system. Otherwise unable to detect.

Notice: Do not remove the power during rightning protection for Camera and end power supply.

APP Instructions

3.1.)APP Download

Search Apple APP store or Google Play store, searching "Tuya Smart" or "Smart Life" to download the APP software. Then search "Owlzer cam" on app search "OWLZER" in APP store for downloading.

3.2).APP Login

Click "OWLZER" icon → login interface → enter the mobile phone number → click "Get" → enter the code → set the login password → accept the protocol → Sign up and enter the main interface. The APP will automatically recognize the camera and prompt "Add Device".

3.3) User Registration

1) Click "register" in the "login screen" → "Area code" → "Mainland China" → "Mobile phone number" → "Get" → "Code" → "Set password" → "Sign up".

2) Enter the mobile phone number and email which you received in your mailbox, you can use this to log onto your account. The interface:

3.4) Retrieve / Change Password

1) In the "Login Screen", click "Forgot Password" Interface → "Area code" → "Mainland China" → "Mobile phone number" → "Get" → "Code" → "Set new password" → "Sign up" → "Sign in" → "Add Device".

2) Open the password reset email which you received in your mailbox, you can use this to log onto your account. The interface:

3.5) Mobile Phone Connecting Device

Android System Open connected APP software, "Camera" → "Add Device" → "Camera (Wi-Fi)" → "Confirm" → "Next" → "Confirm" → "Next" → enter password → choose device. You can close "Ios Connection" if you don't need it.

IOS System Open "Browser (Safari)" or your iPhone setting Android → select "OWLZER_WiFi" → enter connected password → "Return" → "Add Device" → "Camera (Wi-Fi)" → "Next" → "Confirm" → "Next" → "Confirm" → "Next" → "Confirm