Nokia Solo Bud+ (SB-201)

Quick Start Guide

NOKIA

What's in the box

- Headset
- Ear Tips (S/M/L)
- Micro USB port
- Quick Start Guide

Product Overview



Get started

Fully charge before use. Any attempt to remove or replace your battery will damage your headset.

The battery status LEDs show the current battery status.

For optimal fit and audio performance, replace the ear tips with the size that best suits you.

Pair and connect with Bluetooth®

1. Pairing with the device

a. Turning on and pairing ①

Press and hold the MFB for 3 seconds until the LED flashes blue and red.

b. Connecting with your Bluetooth® device

Turn on Bluetooth® in your device and choose "Nokia Solo Buds" from the Bluetooth® menu to connect.

The LED indicator lights of the earbuds will flash blue every 3 seconds when they are successfully connected via Bluetooth®.

2.After the initial pairing, the earbuds will automatically connect with your Bluetooth® device whenever it is turned on.

3.The earbuds will automatically power off if there is no Bluetooth® connection within 5 minutes.

Using your earbuds

1.Touch control

Play / Pause music	x 1 MFB
Answer / End calls	x 1 MFB
Reject calls	x 1 sec MFB
Activate voice commands	x 2 secs MFB
Volume down	x 1 VOL-
Volume up	x 1 VOL+
Previous track	x 4 secs VOL-
Next track	x 4 secs VOL+

Product and safety information

Interference may occur in the proximity of TV sets, radios, computers or medical equipment.

Your wireless device may be susceptible to interference, which could affect performance.

Do not use your wireless device near medical equipment without permission. If you have any questions about using your wireless device with an implanted medical device, consult your healthcare provider.

Operate your wireless device in the normal operating position as described in the product documentation. Your wireless device complies with RF exposure guidelines when used either against your ear or at a distance of 1.5 centimeters (5/8 inches) from your body. When using any data features, ensure that the device, with any attached cable, is positioned at a distance of 1.5 centimeters (5/8 inches) from your body.

Do not use your wireless device if it is damaged, cracked, or broken.

Do not use your wireless device in any way that is not described in the user guide.

Do not touch the antenna unnecessarily.

Do not use your wireless device if you suspect that it has been damaged in any way.

Do not use your wireless device in areas where blasting is in progress, where explosive atmospheres may be present, or where flammable gases or fumes may be present.

Do not use your wireless device while flying in aircraft, while in areas where aircraft may land, or while using unauthorized equipment.

Do not use your wireless device while driving a vehicle unless it is essential to do so. In that case, only use your device after ensuring that it can be used safely. Give full attention to driving at all times in order to reduce the risk of an accident.

Do not use your wireless device in explosive atmospheres (such as petrol stations, areas where the air contains chemicals or particles, such as grain, dust, or metallic powders).

Do not use your wireless device in a moving vehicle if doing so will distract you from driving safely.

Do not use your wireless device in areas where its use is prohibited (for example, in aircraft or in areas where using wireless equipment is dangerous).

Do not use your wireless device if doing so will cause a danger or disturbance to normal network operations.

Do not use your wireless device in areas where its use is prohibited (for example, in aircraft or in areas where using wireless equipment is dangerous).

Do not use your wireless device if doing so will cause a danger or disturbance to normal network operations.