90mm

135mm

HD308-3G02

Wireless Ergonomic Keyboard
无线人体工学键盘



User manual

Thank you for choosing our keyboard. Please read the user manual carefully before using this product.

Package content
- 2.4G wireless keyboard x 1
- USB receiver x 1
- User Manual x 1

Compatibility
Compatible with Windows 8/10/Mac OS

Keyboard Usage

1.Connection
Place 2PCS dry cell(AAA battery)into battery slot,then switch to "ON"button,next insert the receiver into USB port of the device. Now the keyboard is working. If not, please try above steps again.

2.How to code
Switch the power to "ON"again, and press ESC+Q keys at the same time, when the third green indicator is flashing,insert the receiver then the indicator will be off, which shows you have finished coding properly.

3.Battery Capacity Detecting
When the battery voltage is too low, the red low-voltage indicator will be flashing, which indicates that you have to charge your keyboard in time.

4.Three green indicator: Numlock, Caps Lock, FN.

5.Multimedia keys
Previous Track, Play/Pause, Next Track, Stop, Mute, Volume-, Volume+.

6.Indicator Icon
[1] Numlock on, Numeric keys zone on, and green indicator on.
[A] Uppercase on, and green indicator on.
[Fn] FN lock key on, and green indicator on.

Key Function

Icon	MAC	Android	Windows	Icon	MAC	Android	Windows
⌂	N/A	HOME	Homepage	✉	N/A	Email	Email
🗀	File	N/A	File	♫	N/A	N/A	Music
🔍	N/A	Search	Search	☼	Brightness-	Brightness-	Brightness-
☼	Brightness+	Brightness+	Brightness+	⏮	Previous track	Previous track	Previous track
⏯	Play/Pause	Play/Pause	Play/Pause	⏭	Next track	Next track	Next track
🔇	Mute	Mute	Mute	🔉	Volume-	Volume-	Volume-
🔊	Volume+	Volume+	Volume+	▭	N/A	N/A	APP switch
🖩	N/A	N/A	Calculator	🖶	N/A	N/A	Printer
⚙	N/A	N/A	Setting	🔒	N/A	N/A	Lock screen
Fn	F1-F12 Lock	F1-F12 Lock	F1-F12 Lock				

Above multimedia function is set by Uncombined keys.F1~F12 is working under Fn lock status, and the Android is set based on Samsung devices,may vary slightly from other manufacturers' Android devices.

感谢您选购了这款键盘，请您在使用这款产品之前认真阅读此说明书，以发挥其最佳性能，避免造成一些不必要的损失。

包装内容
键盘/接收器/说明书

操作系统要求
2.4G：Windows 8/Windows 10/Mac OS
驱动下载方式: 说明书或驱动请登录以下网址
https://www.deluxworld.com/service.html-服务支持-下载专区进行下载或描关注多彩科技服务号点击底部菜单栏--服务支持-在线售后

使用需知
1. 连接方式：按正负极相应方向装入电池，拨动电源开关至ON位置，将无线接收器插入电脑USB端口，即可使用键盘（若键盘无反应，请按以上步骤重新连接）
2. 对码方式：重新拨动电源开关至ON位置，同时按下ESC键+Q键对码，第三颗指示灯绿灯快闪，插入接收器指示灯熄灭即对码成功,
3. 当电池电压较低时，低压指示灯红灯闪烁，请及时充电。
4. 三款绿色指示灯：Numlock指示灯，Caps Lock指示灯，FN键指示灯
5. 快捷多媒体键：上一曲、播放/暂停、下一曲、停止、静音、音量减、音量加。

指示灯图标
[1] Numlock数字键区打开，绿色指示灯长亮
[A] 大写状态打开，绿色指示灯长亮
[Fn] FN锁定键打开，绿色指示灯长亮

按键功能

按键图标	MAC 系统功能	Android 系统功能	Windows 系统功能	按键图标	MAC 系统功能	Android 系统功能	Windows 系统功能
⌂	N/A	HOME	主页	✉	N/A	邮件	邮件
🗀	文件管理器	N/A	文件管理器	♫	N/A	N/A	音乐
🔍	N/A	搜索	搜索	☼	亮度减	亮度减	亮度减
☼	亮度加	亮度加	亮度加	⏮	上一曲	上一曲	上一曲
⏯	播放/暂停	播放/暂停	播放/暂停	⏭	下一曲	下一曲	下一曲
🔇	静音	静音	静音	🔉	音量减	音量减	音量减
🔊	音量加	音量加	音量加	▭	N/A	N/A	应用切换
🖩	N/A	N/A	计算器	🖶	N/A	N/A	打印机
⚙	N/A	N/A	设置	🔒	N/A	N/A	锁屏
Fn	F1-F12锁定	F1-F12锁定	F1-F12锁定				

以上多媒体功能键默认都为单键实现，Fn锁定状态F1-F12单按实现。
我司Android以三星的为主要设备进行设定的，其他厂商Android设备根据厂商定义可能存在差异

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

设计说明：

1、尺寸：90*135mm(公差+/-1mm)
2、材质：70g书写纸
3、颜色：单色双面印刷
4、装订方式：风琴折页

DELUX 多彩	深圳市多彩实业有限公司 SHENZHEN DELUX INDUSTRY CO., LTD.		
	名　称	GM901D国内海外共用说明书	
	料　号	R3.4.GM90106001B	
审　核		设　计	王欣宇/21.11.25

分　发：☐研发部 ☐产品部 ☑资材部 ☑品保部 ☑生产部 ☑工程部 ☐海外营销部 ☐国内营销部 ☑文控中心

批　准：（签名）