AUSDOM

User Manual

KAM200

Wireless Keyboard and Mouse Combo

Thank you for purchasing AUSDOM Wireless Keyboard and Mouse Combo

AUSDOM®
Enjoy Smart Life

For more information, please visit our official website: www.ausdom.com.

Your valuable comments and suggestions on improving AUSDOM products are welcome!

support@ausdom.com sales@ausdom.com
www.ausdom.com

EN-1

1. Product Overview



2. Packing list

1* Wireless Keyboard
1* Wireless Mouse
1* USB Receiver (keyboard and mouse use the same USB Receiver)
1* USB To Type-C charging cable
1* User manual

EN-2

3. Connections

Wireless Keyboard

Turn on the keyboard power switch

Plug the USB Receiver into your computer device to use

Wireless Mouse



Turn on the mouse power switch

Plug the USB Receiver into your computer device to use

EN-3

4. Function key description

Key	System Functions	Key	System Functions
F1	Mute	F9	Play/pause playback
F2	Volume reduce	F10	Previous track
F3	Play/Pause	F11	Next track
F4	Decrease brightness	F12	Increase brightness
Fn	Calculator	Del	Insert
Q	Setting	Ctrl	Turn on Setting
C	Window Switch	Alt	Open Browser
Shift	Media Desktop	⊞	LOCK/Unlock
Fn+F1	Mute & power on state		
Fn+F2/F3/Switch			

5. Indicator

	Action	Color	Activity
Keyboard	Power ON/OFF/Charging & Pairing	Red	Normally on when powering on, Turn off after 3 seconds
	Caps Lock Indicator	Green	Illuminate in pairing mode
	Num Lock Indicator	■ Green	Flash
	Scroll Lock Indicator	Green	Illuminate in low power
	Power ON/OFF/Charging & Pairing	Red	Normally on when powering on, Turn off after 3 seconds
	Caps Lock Indicator	Green	Illuminate in low power
	Num Lock Indicator	Green	Illuminate in low power
	Scroll Lock Indicator	Green	Illuminate in low power
Mouse	Power ON/OFF/Charging & Pairing	Red	Normally on when powering on, Turn off after 3 seconds
	Mode Switch	Green	Illuminate in pairing mode
	Charging	Red	Illuminate in charging, Turn off when fully charged
	Low power indicator light	Red	Flash ■ 5 times/gap

EN-4

6. Charging

When the power of the keyboard and mouse is too low, the power indicator light will flash red. Please charge in time to ensure normal use.
Note: When the power level is low, the transmission of the keyboard and mouse will be delayed, stuck and unstable.

7. Specifications

Keyboard	Connections	2.4G wireless Technology (USB Receiver)
	Working Range	10m
	Battery Capacity	1200mAh
	Continuously working time	>200 hours
	Standby Time	>120 days
	Charging Time	<2.5 hours
	Keys Life	5 million times
Mouse	Connections	2.4G wireless Technology (USB Receiver)
	Working Range	10m
	Battery Capacity	300mAh
	Continuously working time	>30 hours
	Standby Time	1 year
	Charging Time	<1.5 hours
	DPI	800±100/1200±100/1600±100

Note: Features and technical specifications are subject to change without notice; we apologize for any inconvenience.

EN-5

8. Warranty

The Wireless Keyboard and Mouse Combo is covered by a 1-year manufacturer warranty. For more information, visit www.ausdom.com

EN-6

CAUTION
RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE
DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

RECYCLING

This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment.
User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.

CE FC RoHS

DC voltage

FC

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
•Reorient or relocate the receiving antenna.
•Increase the separation between the equipment and receiver.
•Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
•Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

EN-7

1. 产品概览

2. 包装清单

1*无线键盘
1*无线鼠标
1*USB无线接收器（键盘和鼠标共用一个接收器）
1*USB-C充电线
1*用户说明书

CN-1

3. 连接方式

无线键盘

打开键盘的电源开关

将USB接收器插入电脑设备即可使用

无线鼠标



打开鼠标的电源开关

将USB接收器插入电脑设备即可使用

CN-2

4. 按键交互功能

键盘组合	系统功能	按键组合	系统功能
F1	静音	F9	播放/暂停
F2	音量减	F10	上一曲
F3	播放/暂停	F11	下一曲
F4	亮度减	Del	Insert
Fn	计算器	Ctrl	唤醒设置
C	视窗切换	Alt	打开浏览器
Shift	桌面模式	⊞	锁屏
Fn+F1	开机静音状态		
Fn+F2/F3/切换			

5. 指示灯

	操作行	灯光颜色	状态
键盘	开机/充电/配对	红灯常亮3秒后熄灭	开机成功
	大写锁定指示灯	绿灯闪烁	电量不足，提示充电
	数字锁定指示灯	绿灯长亮	正常状态
	滚动锁定指示灯	绿灯长亮	电量充满
	大写锁定指示灯	绿灯长亮	大写锁定
	Num Lock指示灯	绿灯长亮	Num Lock锁定
鼠标	开机/充电/配对	红灯常亮3秒后熄灭	开机成功
	电量充电指示灯	红灯闪烁	电量不足，提示充电
		红灯长亮	充电中
		绿灯长亮	充电完成
	DPI指示灯	绿灯闪烁一下后灭	切换DPI一档
		绿灯闪烁两下后灭	切换DPI第二档
		绿灯闪烁三下后灭	切换DPI第三档

CN-3

6. 充电

当键盘或者鼠标电量过低时，电源指示灯会一直闪烁红灯，请及时充电，以免影响正常使用。
备注：当电量过低时，键盘和鼠标的传输可能会出现延迟、卡顿、连接不稳定的情况。

7. 参数

键盘	连接方式	无线2.4G连接
	有效距离	10M(空旷)
	电池容量	1200mAh
	续航时间	>200天
	充电时间	<2.5小时
	按键寿命	500万次
鼠标	连接方式	无线2.4G连接
	有效距离	10M(空旷)
	电池容量	300mAh
	续航时间	>30小时
	待机时间	1年
	充电时间	<1.5小时
	DPI	800±100/1200±100/1600±100

温馨：功能和技术规格如有更改，恕不另行通知，对于造成的给您带来的任何不便，我们深表歉意。

CN-4

8. 保修

无线键鼠套装有1年的质量保修。更多详情，请登录www.ausdom.com

9. 安全须知

⚠ 警告：不遵循以下安全说明可能会导致起火、触电、严重伤害或者死亡。
请在保存此份手册的基础上遵守以下说明和使用警告。⚠ 注意在使用过程中关注。
⚠ 上述条件除
⚠ 上述条件除外
⚠ 上述条件除外
⚠ 上述条件除外

CN-5

产品中有害物质的名称及含量

部件名称	有害物质					
	铅（Pb）	汞（Hg）	镉（Cd）	六价铬（Cr(VI)）	多溴联苯（PBB）	多溴二苯醚（PBDE）
电路板组件	×	○	○	○	○	○
塑料部件	○	○	○	○	○	○
金属部件	×	○	○	○	○	○
电缆	×	○	○	○	○	○
电池	○	○	○	○	○	○
其它附件	×	○	○	○	○	○

本表格依据SJ/T 11364的规定编制。
○：表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下。
×：表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。
注：“×”部件应依据欧盟有关RoHS法规申请豁免或者采用替代方案。
此环保使用期限只适用于产品在用户手册所规定的条件下工作。

CN-6

保修卡

保修期

产品自售出之日起12个月，发生质量问题，消费者可以选择退货、换货或维修，产品自售出之日起15日内，发生质量问题，消费者可选择换货或者维修，客户选择以旧换新以产品价格补以超过7个月内有效。

免费服务：

在产品保修期内，为客户提供免费维修服务。

以下情况除外免费维修：

1.充电线不在保修客户范围。
2.因个人额外原因损坏。
3.因未长期保存造成的故障及人为机械损坏。
4.因不可抗力造成的故障或损坏。

客户姓名：	
联系电话：	
联系地址：	
产品名称：	
产品型号：	
购买日期：	
销售员：	
S/N号：	
维修记录：	

CN-7

WARRANTY CARD

ATTENTIONS:
- Please read the return procedures and warranty policy carefully on www.ausdom.com before sending items back to point-to-point purchase.
- Please fill the card and send it to your reseller together with the product if your products warranty is valid.

S.N:	
Date of Purchase:	
Product Mold:	
RMA Number:	
Return Reason:	
Customer Name:	
TEL:	
E-mail:	
Address:	

EN-8

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.