**VERSATILE**
OMNI-DIRECTIONAL FUNCTION PROVIDES EASY MANEUVERING DURING PLAY

**COMPETITIVE**
THROW HOOKS AND JABS IN AN ATTEMPT TO KNOCK OUT YOUR OPPONENT

**CORDLESS**
OPERATE TWO ROBOTS VIA REMOTE CONTROLS

**2 PLAYER ACTION!**

Each robot requires 3 "AAA" 1.5V alkaline batteries (not included). Each remote control requires 1 9V alkaline battery (not included). Colors and styles may vary.

THE BLACK SERIES™ by shift3®

**remote control**
# battle boxing robots

THE BLACK SERIES™

**WARNING!**
**CHOKING HAZARD** - Small parts. Not suitable for children under 3 years.

BOX CONTAINS THE FOLLOWING FREQUENCY:
☐ 27 MHz
☐ 49 MHz

**BATTERY OPERATED PLAY ROBOTS**
AGES 6 AND UP

**2 PLAYER ACTION!**

**WINDOW DIE-CUT**
Tray Insert Prints 40C/100Y (Green)




**remote control**
## battle boxing robots

THE BLACK SERIES™

**remote control**
## battle boxing robots

- robot's head ejects when chest plate is hit by opponent
- two robots/remote controls for thrilling 2-player battles
- perform hooks, jabs and 360 degree spins
- built-in digital sound effects for thrilling battles

Each robot requires 3 "AAA" 1.5V alkaline batteries (not included). Each remote control requires 1 9V alkaline battery (not included).
Colors and styles may vary.

THE BLACK SERIES™ **remote control battle boxing robots**

**SAFETY PRECAUTIONS:**

- Do not use the product near small children or animals, the detachable head can pose a choking hazard.
- Adult supervision is recommended at all times.
- Avoid water, sand and snow when operating your robot. Never submerge any portion of the product in water.
- Never leave the product near sources of heat, under direct sunlight or outside overnight as this is harmful to internal components.

**OPERATING INSTRUCTIONS**

Each robot requires 3 "AAA" 1.5V batteries (not included). Each remote control requires one 9V battery (not included). When changing batteries, adult supervision is required. Use alkaline batteries for best performance.

1. Carefully remove items from the package.
2. Locate the battery compartment on the back of each robot, as well as each remote.
3. On robots, loosen the screws and remove battery doors. Slide doors open on RC units.
4. Insert "AAA" batteries inside robots while observing the correct polarity in each compartment (see diagrams). Insert one 9V battery into each remote control.
5. Replace the battery doors and tighten screws.
6. Switch robot and remote control power switches to the "ON" position. The power switch is located on the side of the robot(s).

**NOTE: Before use, adjust the robots to make sure both feet have good contact with the ground. Use on a hard, flat surface for best results.**

Made in China

©2018 MerchSource, LLC.
The Black Series, and all associated logos are trademarks of MerchSource, LLC.
All rights reserved.

Distributed by MerchSource, LLC, Irvine, CA 92618.

China Patent No. ZL201320161104.7, ZL201330053437.8.X
US Design Patent No. D712,980

For technical support, please call 1-800-374-2744.

The artwork and design of this package are protected by US copyright law and may not be reproduced, distributed, displayed, published or used for any purposes without prior written permission. It is not permitted to alter, remove or reproduce any trademarks or copyright notice from this package.

**BATTERY WARNING:**

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- Insert batteries using the correct polarity. Do not short-circuit the supply terminal.
- Remove batteries when not in use. Recycle or dispose of exhausted batteries according to federal, state, and local laws. Do not dispose of batteries in a fire, as they may leak or explode.
- Only use manufacturer specified battery(ies), charger(s) and/or adapter, if applicable, specified by the manufacturer.
- Always use, replace, and recharge (if applicable) batteries under adult supervision.

KEEP THIS PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.



Each robot requires 3 "AAA" 1.5V batteries (not included).



Remote requires one 9V battery (not included).




**OPERATING CONTROLS**

- Push both levers up to move forward
- Push both levers down to move backwards
- Push left lever to move right and hook
- Push right lever to move left and jab
- Push the left lever up and the right lever down to spin clockwise
- Push the left lever down and the right lever up to spin counter-clockwise

**HOW TO PLAY**

There are sensors located beneath each robot's chest plate. The object of the game is to knock the opposing boxer's head off by making contact with the chest (thus ejecting the robot's head). To replace the head, place it face forward onto the neck and gently press down until it clicks into place.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

| ART DEPARTMENT | | | |
|---|---|---|---|
| **Job # / Filename**<br>2018-05-22_BS_ToyRCBoxingRobots_RedBlu_Blk | | **Product Line**<br>Black Series | |
| **Designer**<br>Jack Ma/Nick Xue/Luna Qin | **Brand Manager**<br>Lisa Nagamoto | **Finished Size**<br>12.8" L x 10.63" H x 8.7" D / 32.5cm L x 27cm H x 22cm D | |
| **File Format**<br>Adobe Illustrator CC (live)/CS4 (OL) | **Fonts**<br>FF Gothic, September, Trade Gothic | **Color (Spot or 4C)**<br>4 Color Process | **# of Colors**<br>4 |
| **Printing Process / Finishing**<br>Matte PP Coating | | **Comments** | |

All copyright, trademark and patent rights or any other intellectual property rights or material associated with the content provided herein, and the selection, coordination and arrangement of such content, are owned exclusively by MERCHSOURCE LLC., or any third-party licensors. The use or misuse of any copyrights, trademarks, patents or any other intellectual property or materials, except as permitted herein, is expressly prohibited. Any infringements shall be prosecuted to the fullest extent of the law, both foreign and domestic.

MerchSource