Y10001811--V1说明书（日语）-V1(20230725)
技术要求：
1.成型尺寸：125*215mm，风琴折；
2.材质：80g书纸，
3.印刷：单色 双面印刷 色彩准确，无套印不准等现象；
4.裁切整齐无毛边；
5.其他要求：产品需满足REACH法规及最新RoHS指令要求。
　　产品需满足欧可林《包装材料来料检验通用标准》。
6.公差：±1mm
7.标注单位mm

English

Oclean
Product User Manual

Oclean X Ultra Wifi Smart Sonic Electric Toothbrush
User Manual

● Important Safety Tips

This product is recommended for use by persons over 12 years of age.
This product can only be used with Oclean replacement heads. We will not be responsible for any consequences resulting from the use of non-Oclean replacement heads.
This product is for personal cleaning only and is not recommended for medical purpose.
This product is for indoor use only. Do not place the toothbrush under direct sunlight for a prolonged period of time. It is recommended to charge the product at a temperature between 5°C and 40°C.
Please keep the body dry before charging, dry it with a soft cloth, and clean the charging base with a dry cloth regularly to prevent the drain from building up.

Brush Head:
Please install the brush head, please pull out or insert it vertically and do not rotate left or right.
It is recommended to detach to change the brush head every two to three months.

Attention should be paid for those with the following conditions of oral sensitivities:
Those who have recently undergone periodontal surgery or are undergoing treatments.
Individuals with other symptoms in the mouth including those with unstable dentures or have persistent heavy bleeding from the gums.
Those who have sensitive teeth or gum recession.
This product is not recommended for use with the above gum or tooth & professional dental before use.

This product is not suitable for people with disabilities, mental illness or lack of relevant experience and knowledge (including children 12-17 years old), unless used under the supervision of their guardians.



● User Guide

App Setup Use
To turn on the toothbrush, press the power button, The toothbrush will enter standby mode after turning on, and Bluetooth and Wifi will remain on while the screen is lit. After the screen turns off, Bluetooth and Wifi will turn off automatically after 10 seconds of inactivity.

App Installation
Use your phone to download the "Oclean Care +" app, then search for and connect to the toothbrush within the app. Note: connecting to the toothbrush through "Bluetooth settings" in your phone's system settings will not work.

App Connection
On the "Connect" page of the app, click the top device picture to enter the "Device Information" page, then turn on "Automatic switch between working/night mode" under "Function Settings" to allow the toothbrush to switch between "Active Brushing" and "Smart Cleaning" modes automatically.

Brushing Plan Settings
After successfully binding the toothbrush to the app, fill in your dental information to receive recommended brushing plans that fit you the most. Alternatively, customize your own exclusive brushing plan by clicking "Exclusive Mode" on the "Devices" page of the app.

Viewing Brushing Records on the app
Data will be synced to the app automatically during brushing if the toothbrush is connected to Wifi and bound to the app. Toothbrush data (starting less than 15 seconds will not be saved. The toothbrush can only be synced a maximum of 30 brushing data (up to 1 days) to preserve correct data. Please connect and synchronize the data on the app within 7 days.

Brushing plan
Without any settings, the toothbrush will run in the "extreme clean mode" by default, where strong clean will be given when the toothbrush runs for 2 minutes and will automatically stop running after 5 minutes of operation.

Charging the toothbrush
Dry the toothbrush bottom before charging, and then insert the USB Cable on the charging base into an adapter. After that, you can place the toothbrush on the charging base for charging. Please ensure the toothbrush is properly placed on the charging base. The LED will remain active for the toothbrush from the charging base in time. After charging, please recharge it when the toothbrush alerts you. To be battery status.

Automatic Wake-up
1) The toothbrush and toothbrush will automatically wake up the screen.
2) The toothbrush is automatically activated via Mobile Phone in time without brushing teeth, the user can will require pressing a button to wake it up. When the battery is low, lifting the toothbrush will not automatically wake up the screen.

● Scientific Guidance Program

Brush Activity Cover: The Brush Activity Cover realizes daily and cloins closest loop management. It records the number of brushing section (one day counts are required to brush their teeth at least twice a day), brushing time (brushing for more than 2 minutes each time), and brushing plan coverage rate (brush for 2 minutes each time, 3 times a day) to help you develop good habits.

Pressure Reminder: During the brushing process, if too much pressure is applied, it may hurt the gums or brush surfaces. Therefore, when the toothbrush detects excessive pressure, it will sound an alarm, and the bristle light will also flashy red.

Excessive Lateral Brushing reminder: During the brushing process, if the lateral brushing is too large, it may cause gum bleeding or damage to the neck of the tooth. Therefore, when the toothbrush detects excessive or rapid lateral brushing, it will sound an alarm, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception,
which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.
This device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID: 2ANSD-V8100

● CE WARNING
1) The appliance is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.
2) ---children being supervised not to play with the appliance.
3) Signal words WARNING, CAUTION, DANGER in uppercase having a height as specified. Uppercase letter of the text explaining the signal words WARNING, CAUTION, DANGER. ---- engraved, or stamped metal type either raised above or have a depth below the surface of at least 0.25 mm, unless
4) This appliance contains batteries that are non-replaceable

Shenzhen Yuming Information Technology Co.Ltd
Address: Room 1101, Building 1, Yuehai Business Center,Nanshan District,Shenzhen 518067, China
Website: www.oclean.com

Important Charging Alert
As the electric toothbrush is provided with the fast charging mechanism, it is recommended to connect and charge the toothbrush when required. Don't put the toothbrush on the charger when charging is not required or if a fully charged, because keeping the fully charged toothbrush in charging for a long time may have a negative impact on the health of battery, thus affecting the voltage expected.

● Recommended Tooth Brushing Method

Move the toothbrush slowly at 45° angle between the bristles and to gum line. There is no need to manually brush up and down during the process.

Hold the toothbrush handle gently, move slowly in a circular motion and please do not apply excessive pressure.

Please gargle with clean water after brushing.

● Specifications

Product Name	Oclean Wifi Smart Sonic Electric Toothbrush
Model	V8100
IP Rating	IPX7
Charger	WPC Wireless Charging Base
Input	5v=1A
Battery Life*	40 days
Battery Capacity	400 mAh
Charging Time	Approx. 2.5 hours
Standard	GB/38698.2020
Bluetooth	Bluetooth 4.2 above
Weight	240

* Using default mode, it is calculated at 2 minutes/time, 2 times/day working condition.

- Do NOT disassemble, strike, extrude or throw the device into a fire.
- Do NOT use the toothbrush if its battery is bulging or has expanded.
- Do NOT use the device if its battery has been damaged.
- Do NOT use the device if its battery has been subjected to immersion in water.

● CE WARNING
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

Some reminder Brushing needs to cover all areas to effectively prevent dental problems. Therefore, during the brushing process, there will be a sound reminder to change areas after completing brushing in one area.

Swipe the screen up and down

Press ON/OFF button to confirm the settings

Low Battery Alert
When the battery percentage is below 5%, an alert will pop up on the display of your toothbrush from time to time to indicate that the battery is low and you need to charge the toothbrush. Also, when the battery is seriously low, your toothbrush will be off and the toothbrush's motor will vibrate to alert you to charge the battery.

Put the toothbrush bottom on the charger to ensure that the toothbrush is upright and stamped on the charging base in normal charging; the toothbrush will show the charging sign and battery percentage and be fully charged for about 3.5 hours.

Important Charging Alert
As the electric toothbrush is provided with the fast charging mechanism, it is recommended to connect and charge the toothbrush when required. Don't put the toothbrush on the charger when charging is not required or if a fully charged, because keeping the fully charged toothbrush in charging for a long time may have a negative impact on the health of battery, thus affecting the voltage expected.

EU REP:	EU Authorised Representative Agency name:Ideal Link Representative Agenda Tanais	European Address Tabshag,8,Kalvinia, Lithuania Post Code:LT46237	Email service@mailbox Phone:+37067829721

Made in China

Facebook Page

www.facebook.com/ocleanglobal
Follow the
Oclean Official Facebook Page
Download App

Google Play　App Store

FDA Registration Number: 3014246581

IPX7

日语

Warranty Certificate of Oclean Sonic Electric Toothbrush

User Information

Name: _____ Contact number: _____ E-mail: _____ ZIP code: _____

Address: _____

Retailer Information

Retailer: _____ Contact number: _____ Address: _____

Sales Date: _____ ZIP code: _____ Invoice No.: _____

Product Information

Product Type: _____ Manufacturing Date: _____

Warranty Card of Oclean Smart Sonic Electric Toothbrush

Delivery Date	Fault Description/Reason Disposal	Equipment employer	Acceptance date	Serviceman

Name of parts	Toxic and harmful substance or element						Environment Protection
	Pb	Hg	Cd	Cr^{6+}	PBBs	PBDEs	6 Phthalates
PCBA	○	○	○	○	○	○	○
Plastic parts	○	○	○	○	○	○	○
Metal hardware	○	○	○	○	○	○	○

Name of parts	Toxic and harmful substance or element						Environment Protection
	Pb	Hg	Cd	Cr^{6+}	PBBs	PBDEs	6 Phthalates
Vibrating motor	○	○	○	○	○	○	○
Accessories	○	○	○	○	○	○	○
Battery	○	○	○	—	—	—	—

10 years

5 years

10 years

5 years

Remarks:
○: This indicates that the content of toxic and hazardous substances in all homogeneous materials of this component is less than the limited quantity as specified in RoHS 2.0 Directive 2015/863 & EU 2017/2102.

×: This indicates that the content of toxic and hazardous substances in at least one of the homogeneous materials of this component is above the limit requirement as specified in RoHS 2.0 Directive 2015/863 & EU 2017/2102.

— : Refer to battery Directive 2006 / 66 / EC and amendment 2013 / 56 / EU.

*: Except for very few materials, due to technical development reasons, most of the components of this product are free of this substance. Please use this product with confidence during the environmental protection period.

Oclean X Ultra Wifi スマート音波電動歯ブラシ
取扱説明書

● 重要な安全情報

この製品は12歳以上のお子様を推奨します。
この製品はOcleanの交換ブラシヘッドにのみ使用できます。Oclean以外のブラシヘッドによるその結果について責任を負いません。
この製品は個人用の清掃用途のみです。医療的目的ではありません。
この製品は屋内でのみ使用してください。直射日光を長時間当てないでください。5℃～40℃の温度範囲で充電することをお勧めします。
充電前に本体を乾燥させ、柔らかい布で拭いてください。定期的に充電台を乾いた布で拭いて排水を防止してください。

ブラシヘッド：
ブラシヘッドを取り付ける場合は、垂直方向に引き抜いてください。左右に回転しないでください。
ブラシヘッドは2～3ヶ月毎に交換することをお勧めします。

以下の症状の方は歯ぐきの敏感さに注意してください。
最近歯周病手術を受けた方、または治療中の方。
口腔内に他の症状がある方。出血が長時間続く方。
知覚過敏の歯や歯ぐきが後退している方。
上記の症状がある方は、使用前に歯ぐきや歯科医師に相談することをお勧めします。

この製品は、身体障害者、精神障害者、または関連する経験や知識が不足している人（12歳～17歳の子供を含む）が使用する場合、保護者の監督の下で使用してください。

Google Play Store & iOS APP Store

● 充電のお知らせ

ハイパワー充電対応の電動歯ブラシですので、必要な時に充電してください。充電が完了しているとき、または充電が長時間になると、バッテリーの健康に悪影響を及ぼし、バッテリー容量が低下します。

ブラシヘッドを45°の角度で歯茎に当てます。ブラシヘッドを上下に動かす必要はありません。

ブラシヘッドを軽く持ち、円を描くように動かします。力を入れすぎないでください。

歯磨き後はきれいな水でうがいをしてください。

● 充電のお知らせ

バッテリー容量が5%未満になると、ディスプレイにバッテリー容量不足の表示が表示され、時間にバッテリーが低下のメッセージが表示され、充電が必要です。バッテリーが極端に低い場合、電源が入らなくなり、モーターが振動で通知されます。

歯ブラシの充電台を電源に接続し、歯ブラシの底面にしっかりと充電台に置かれていることを確認してください。歯ブラシの充電台に充電ランプが表示され、バッテリー容量のパーセント表示がされます。正常な充電時間は約3.5時間です。

● 充電のお知らせ

この製品はハイパワー充電対応のスマートモーターが搭載されます。充電が必要な場合にのみ充電することをお勧めします。充電が不要の場合や充電が長時間になると、バッテリーの健康に悪影響を及ぼし、バッテリー容量が低下します。この場合、バッテリーが異常発熱し、故障する可能性があります。

● 保証カードと使い方

症状	主な原因	解決方法
歯ブラシの振動が弱い	ブラシヘッドを長くたるため使用する。	ブラシヘッドを新品に取り替えるようにしてください。
	ブラシヘッドの表面に傷がついたりしている。	ブラシヘッドを新品に取り替えるようにしてください。
歯ブラシが動かない	ブラシヘッドが柔らかく振動がスムーズに伝わらない。	ブラシヘッドを新品に交換するようにしてください。
	Oclean専用ブラシヘッドを使用していない。	専用品に交換して、故障ブラシを使用しないでください。
	充電中	充電中は操作できませんので、充電が終了してから使用してください。
	充電不足	充電ケーブルを接続して充電してください。

この機器は、防塵、防水、水に耐えることを意味します。
この機器は、水中で使用しないでください。使用中に水にさらさないでください。
この機器は、浸水しないでください。
水場の洗面台にいる時は使用しないでください。

● 基本仕様

製品名：	Oclean X Ultra Wifi スマート音波電動歯ブラシ
ブランド名：	Oclean
型番：	V8100
防水レベル：	IPX7
定格入力：	5=1A
バッテリー仕様：	リチウムポリマー(3.7V 1200mAh)
充電時間：	約2.5時間
本体重量：	約240g
製造業者：	Shenzhen Yuming Information Technology Co., Ltd

Made in China

● WPCワイヤレス充電器

定格入力：	5=1A
重量：	約70g
製品内容：	歯ブラシ(ホワイト)x1、ワイヤレス充電トラベルケース1、歯磨きブラシヘッド1、歯ぐきに優しい超音波ブラシヘッドFSO、ホワイトニングブラシヘッドFSW、標準ブラシヘッドFSP、WPCワイヤレス充電器(ホワイト)x1、ユーザーマニュアルx1

製品名称		外観の色名前	
お客様のご知声		ご連絡先電話番号	
		相談期間	お買い上げの日から1年間
お買い上げ日	年 月 日	販売店名	様

ご販売店ご記載シールや領収書貼付

ご注意
・保証期間（1年）内であっても以下の場合は有償修理となります。
・取扱説明書（ユーザーマニュアル）に従った正常な使用状態で保証期間内に故障した場合には、無償修理を行います。
・取扱説明書（ユーザーマニュアル）に従った正常な使用状態で保証期間内に故障した場合には、無償修理を行います。
・ご購入後の移動や輸送、落下による故障及び損傷。
・ご使用者の誤使用や不適切な修理または改造による故障及び損傷。
・火災、地震、水害、落雷、その他の天災地変、公害や異常電圧による故障及び損傷。
・一般家庭用以外（業務用など）に使用された場合の故障及び損傷。
・保証書の提示がない場合。
・保証書に必要事項の記入がない場合、または字句を書き換えた場合。
・本保証書は日本国内においてのみ有効です。
・This warranty is valid only in Japan.
・本保証書は再発行いたしませんので、大切に保管してください。
・本保証書は、本保証書に明示した期間、条件のもとにおける無償修理をお約束するものです。従って本保証書をご使用になられた方に対する、それ以外の一切の責任を免除するものではありません。
・本保証書は、お客様の法律上の権利を制限するものではありません。

Instruction for E-label

- Instruction to find the e-label in the FQA:

1. Lift up the toothbrush, the screen will be automatically awake and lights up for 15;
2. Tap up and down to select any mode and hold for 15. The firmware version will be displayed on the button.
3. Slip up and down to switch to E-label screen and the E-label can be checked by user.

The certification logo will be displayed immediately in the screen of the device .
Before the device display the certification logo , the wireless transfer will not start.
After entering into the E-label screen ,the user do not have the entrance to enter and change the identification logo as the contents of the E-label is encrypted.

E-label display as below figure:

-

CMIIT ID: 2023DP11889

ID: 218-220123

ICCAIC2LP13B0T1

FC ID : 2ANSD-V8100

FDA Registration Number : 3014246581

Made in China

Model V8100

FW V1.x.x.x

Made in China

IPX7