Damai

Product specification

Product name	[illegible]
Model number	[illegible]
CPU	Quad core Cortex-A53
OS	Android 9.0
RAM	2GB
ROM	8GB
PSU	12V⎓1A
Work Environment	Work temperature: 0°C~+40°C Humidity: <90% Storage temperature: -20°C~+60°C Humidity: <90%

Friendly reminder:

- [illegible]
- [illegible]
- [illegible]
- [illegible]
- [illegible]
- [illegible]
- [illegible]

Packing list

Storage box

MIC

Remote control

Power adapter

HDMI cable

Battery

Device connection

- Connect the HDMI OUT of the box with the TV HDMI input.
- For wired network connection, please connect the wired connection output to internet router or ADSL Modem, etc. When connected to network, the system will configure the network automatically.
- The box has embedded WiFi. You may open the WiFi function in the box, search for SSID, and connect.
- Connect power from DC interface.
- Connect the MIC to the box with the MIC input.

Network configuration

Switch on the box and check the indicator to verify if the box is working properly, then begin to configure the network. (Choose wired or wireless connection)

Wired connection configuration

System setup / Network setup / choose 'wired connection'

When chosen wired connection, system will configure the network automatically, and obtain IP address.

PPPOE configuration

System setup / Network setup / choose 'broadband dialing' in popup dialog interface, Type user account/password (the information of the account and password), click 'dialing' to go automatically. If the system is dialed, system will dial up automatically.

Wireless network configuration

System setup / Network setup / choose 'Wireless network', the system will search for WiFi signals, and choose the one needed.

Type in the right password, click network connection, wireless network connection.

Camera Operation

1. Push the top to expose or hide the camera.
2. Turn the ring to adjust vertical angle of the camera.

Remote control

Power
Volume+
Up
Left
Down
Return
Mic
Mute
Menu
Volume-
Confirm
Right
Home
Delete
Number keys
Hang up

Connecting Interface

MIC
USB
HDMI
LAN
Power

Installation instructions



FCC Caution

§15.19 Labelling requirements.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§15.21 Information to user.
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§15.105 Information to the user.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

[illegible]

Service Hotline: [illegible]