3.Login successfully, enter the software main interface,click **"My device"**.
As picture shows:

Double click **"My device"**

4.Playback:Click 🔘 icon,select **"SD card record"** can play back.If customers purchase Cloud Storage,select **"Cloud Record"** can paly back.
As picture shows:

Click and choose **"SD card record"**

FAQ

Question 1: When equipment prompt offline, remote connection failure , how to solve?
    Answer: if the device is offline, First you should to check the network which equipment used in , computer or mobile phone can normal Internet access or not; Second check the internet indicator light is normally on or flashing,if the flash device is not connected to the routing, check whether the routing is working properly, routing signal and the name has been modified or not .

Question 2: how to correctly use memory card ?
    Answer: the right way is to insert the memory card into the device firstly ,then plugged in power. the first time use new card , the device will automatically formatted, you can through APP to check the working state of the memory card .
    Connect video screen, click on the "device Settings" - "storage management", you can view equipment status, usage, video mode of the memory card .

Question 3: how many G SD card maximum support?
    Answer: the max support 128 gb memory card, it is recommended to use home furnishings TF card.

Question 4: how to modify the device password?
    Answer: there are two ways to modify the device password.
    ①Using mobile phones to change device password. Connect the video screen, click on the "device Settings", "system management", "modify the administrator password"
    ② Using the computer to modify the device password. Connect the video screen, click on the "remote Settings" - "system management" - "user management" click modify and set a new password.

Question 5 : if you forget the user password ,how to do ?
    Answer : Enter into client login screen ,Click on forget password to reset .

Question 6: if the device cannot be viewed by many people ,how to do ?
    Answer:The device supports one binding mobile phone has one user operating privileges,when many people view ,please share by first binding phone . if you want to change the binding phone ,please unbind .

Question 7: How to restore factory setting?
    Answer: Please find the RESET hole at the bottom of the camera, and use the top pin long press until the speaker is prompted.

Product warranty

Dear

    ● When require warranty service , please show the warranty card and the purchase invoice, and please fill in the relevant content in detail, the company will provide clients product warranty within One year from the date of purchase of the product

    ● If has quality problems during the warranty period, we provide maintenance and replacement services free of charge, if it is man-made damage or beyond the warranty period, the company's maintenance and replacement service will be charged .

    ● The damage caused by improper use: such as the appearance destruction of abnormal abrasion, extrusion deformation, the entry of foreign matter, moisture, The seal on the product is altered to tear up and any other visible damage, other cases: if users disassemble or modify the careless use, improper operation, the damage caused by the water. And the damage for the irresistible reason: such as earthquake, flood, typhoon or war, purchase invoices of product doesn't match Model encoding or beyond the warranty period.

Product warranty card

CUSTOMER DATA		SERIAL NO:
NAME:	TEL:	
ADD:		
P.C:	PURCHASED DATE:	Y M D

Warranty period:From date of purchase on，one—year free warranty.

MAINTENANCE AND REPAIR RECORD

DATE	CONTERTS

User Manual

SHENZHEN SECULINK TECHNOLOGYCO.,LTD

WiFi IP CAMERA

Model: C8

Dear User,

Welcome to use our intelligent network camera products.You can browse your home's real-time and wonderful videos at any time by this product wherever you are,and catch everything which you care.Let you have a good life.

Hardware Brackets Fixation

(The installation steps are only for some products)

1.Remove the disc holder and fixed with the screw. As picture 1 shows:

picture 1

2.Take out the camera ,using the bottom available location to insert disc holder then finished the installation.As picture 2 shows:

picture 2

— 1 —

---

1 Mobile remote control

1.Open the smart phone, Scan the specified QR code,download and install APP. **As picture shows :**

IOS APP
(Iphone users recommend using the UC browser or Wechat)

Android APP
（Android user recommend using the UC browser, Don't use Wechat ）

— 2 —

2.Open**"Danale"** app on the phone's desktop, Follow the steps to register an account, **As picture shows:**

Create Account

Danale

Next

Click the"Local Login"

3.Use the registered account to login, Click **"Add Device"**. **As shown below:**

Welcome to Danale

Danale

Welcome to Danale

Login

Click **"Login"**

Add devices

Click " +" add device

— 3 —

4.Input **"WIFI Password"**, Click "Next", Then Seach Device. **As picture shows:**

Network settings

Search devices

TP-seculink

Once Search Out the Camera, Add and save the device.

Input **"WIFI Password"**, Click**"Next"**

5.Click**"Add"** then can remote control DVR. As picture shows:

Search devices

denale

Choose**"Add device"**

— 4 —

---

2 CMS

1.Input **"www.cd-ipc.com/danale"** to IE, Click the**"CMS"**, to download and install this software. **As picture shows:**

www.cd-ipc.com/danale

Home   Nvsip   Xmeye   Goolink   Danale   V380

Danale

Download NOW

Input "www.cd-ipc.com/danale"

Click "Download NOW"

2.Open the **"Danacms"** , input the account and password as you just registered.**As picture shows:**

Danale

email/phone number

password

login   local login

Input Account and Password

— 5 —