VANTOP	
型号	VP1W1AA
名称	1080P投影仪
电压	AC100-240V 50/60
功率	77W Max@100W/5V, 3A@5V/2.5W/5W
遥控电池	AAA*2
出口类型	3.5mm
输出端	3.5mm
备注	本产品仅供在中国大陆销售和使用

VANKYO SUPPORT

Monday-Friday(EST) : 10AM-6PM(Sunday-Saturday)
Monday-Friday(CET) : 10AM-6PM(Sunday-Saturday)
Monday-Friday(JST) : 10AM-6PM(Sunday-Saturday)
Monday-Friday(AEST) : 10AM-6PM(Sunday-Saturday)

Scan to Download the User Manual

Scan to Download the App

PERFORMANCE V630W USER MANUAL

Thank you for choosing VANKYO! Please read this manual carefully before using your projector.

ENGLISH

PACKING LIST

NOTICE

FUNCTION OVERVIEW

QUICK START

BOOTING CORRECTION

INPUT SOURCE

PROJECTION DISTANCE&SIZE

SPECIFICATION

Display Technology	LCD	Light Source	LED
Resolution	Native:1920*1080	Color Signal	10bit, 16M color, sRGB
Installation Type	Portable/Desktop	Focus Mode	Manual focus
Throw	80 inch	Recommended Resolution	1920 x 1080
Speaker	5W(Mono)	Video Signal	NTSC/PAL/SECAM
Lens Material	Glass lens, Plastic lens	Input Signal	1 Type-C/2 HDMI
Physical Characteristic	Micro SD Card Slot	Output Signal	1 3.5mm Audio Output
Other Input Ports	1 USB Port(Support Flash Drive/Mouse/Keyboard)	Power	100-240V 50/60Hz 77W Max@100W/5V, 3A@5V/2.5W/5W
Recommended Viewing Distance	3.28ft(1m)-16.4ft(5m)	Net Weight	2.65lbs(1.2kg)

TROUBLESHOOTING GUIDE

- **The projector has no sound, muffled, unclear sound, or sound distortion?**
  - Check if the volume is too low or muted. Adjust the volume to a comfortable level.
  - Ensure the audio cable is properly connected to the projector and the audio source device.
- **After boot-up, the TV screen is small. How to correct from 4:3 to 16:9, and fill the whole screen of the projection?**
  - Go to Settings > Display > Aspect Ratio, and choose the appropriate aspect ratio for the projection.
- **Black Screen**
  - Check if the power cable is connected.
  - Ensure the projector is turned on.
  - Verify that the input source is set correctly.
- **Poor Image Quality**
  - Clean the lens with a soft, lint-free cloth.
  - Adjust the focus ring to sharpen the image.
  - Ensure the projection surface is clean and smooth.
- **Remote Control Issues**
  - Check the batteries in the remote control.
  - Ensure there are no obstructions between the remote control and the projector's sensor.
  - Try resetting the remote control by removing the batteries and pressing each button once.
- **Overheating**
  - Ensure the projector has adequate ventilation.
  - Clean the air vents and filters regularly.
  - Avoid using the projector in high-temperature environments.
- **Lamp Not Turning On**
  - Check the power connection.
  - Wait for the lamp to cool down if it was recently turned off.
  - Replace the lamp if it has reached the end of its lifespan.
- **Error Messages**
  - Refer to the user manual for specific error codes and their meanings.
  - Follow the recommended actions to resolve the issue.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

HDMI Warning

Use only high-speed HDMI cables that bear the HDMI trademark. Standard or unapproved HDMI cables may cause compatibility issues, signal loss, or failure to display 4K content properly.

Ensure that both the HDMI cable and the connected devices support the required bandwidth and resolution for 4K playback.

Avoid using HDMI cables longer than 15 feet (4.5 meters) without a signal booster, as this can degrade signal quality.

Regularly check HDMI connections for dust, debris, or damage that could affect performance.

PACKING LIST

NOTICE

FUNCTION OVERVIEW

QUICK START

BOOTING CORRECTION

Press ◁ ▷ keys to enter the Projection Settings interface, then press ▽ key to select the Projection Mode and press ◁ ▷ keys to select Ceiling Mode.

- Ceiling Mode: Select this mode to flip the image horizontally.
- Rear Projection Mode: Select this mode to flip the image horizontally.

INPUT SOURCE

Press ⏻ key to enter the Input Source interface, then press ▽ key to select Input Source.

A. Screen Mirroring

B. HDMI Connection

C. Type-C Connection

D. Bluetooth Connection

PROJECTION CONNECTION

SCREEN MIRRORING

- Press ⏻ key to enter the Input Source interface, then press ▽ key to select the Wireless Display and press ◁ ▷ keys to select Screen Mirroring.
- Press OK key.
- Enable the Screen Mirroring function on your device and search for Vankyo Screen Mirroring 2.0 System.
- Select Vankyo Screen Mirroring 2.0 System to connect.

Wireless Connection

- Ensure that your projector and mobile device are connected to the same WiFi network.
- Download and install Vankyo Screen Mirroring 2.0 App from the App Store (iOS) or Google Play (Android).
- Open the app and follow the on-screen instructions to connect your device to the projector.

SCREEN MIRRORING

- Press ⏻ key to enter the Input Source interface, then press ▽ key to select the Wireless Display and press ◁ ▷ keys to select Screen Mirroring.
- Press OK key.
- Enable the Screen Mirroring function on your device and search for Vankyo Screen Mirroring 2.0 System.
- Select Vankyo Screen Mirroring 2.0 System to connect.

Wireless Connection

- Ensure that your projector and mobile device are connected to the same WiFi network.
- Download and install Vankyo Screen Mirroring 2.0 App from the App Store (iOS) or Google Play (Android).
- Open the app and follow the on-screen instructions to connect your device to the projector.

SCREEN MIRRORING

- Press ⏻ key to enter the Input Source interface, then press ▽ key to select the Wireless Display and press ◁ ▷ keys to select Screen Mirroring.
- Press OK key.
- Enable the Screen Mirroring function on your device and search for Vankyo Screen Mirroring 2.0 System.
- Select Vankyo Screen Mirroring 2.0 System to connect.

Wireless Connection

- Ensure that your projector and mobile device are connected to the same WiFi network.
- Download and install Vankyo Screen Mirroring 2.0 App from the App Store (iOS) or Google Play (Android).
- Open the app and follow the on-screen instructions to connect your device to the projector.

Screen Mirroring with the Original USB Cable

Wireless Connection

- Ensure that your projector and mobile device are connected to the same WiFi network.
- Download and install Vankyo Screen Mirroring 2.0 App from the App Store (iOS) or Google Play (Android).
- Open the app and follow the on-screen instructions to connect your device to the projector.

Wired Connection

- Use the original USB cable that came with your projector.
- Connect one end of the USB cable to the USB port on your projector.
- Connect the other end of the USB cable to your mobile device.
- Follow the on-screen instructions to complete the connection.

Screen Mirroring with the Original USB Cable

Wireless Connection

- Ensure that your projector and mobile device are connected to the same WiFi network.
- Download and install Vankyo Screen Mirroring 2.0 App from the App Store (iOS) or Google Play (Android).
- Open the app and follow the on-screen instructions to connect your device to the projector.

Wired Connection

- Use the original USB cable that came with your projector.
- Connect one end of the USB cable to the USB port on your projector.
- Connect the other end of the USB cable to your mobile device.
- Follow the on-screen instructions to complete the connection.

PROJECTION DISTANCE&SIZE

SPECIFICATION

Display Technology	LCD	Light Source	LED
Resolution	Native:1920*1080	Color Signal	10bit, 16M color, sRGB
Installation Type	Portable/Desktop	Focus Mode	Manual focus
Throw	80 inch	Recommended Resolution	1920 x 1080
Speaker	5W(Mono)	Video Signal	NTSC/PAL/SECAM
Lens Material	Glass lens, Plastic lens	Input Signal	1 Type-C/2 HDMI
Physical Characteristic	Micro SD Card Slot	Output Signal	1 3.5mm Audio Output
Other Input Ports	1 USB Port(Support Flash Drive/Mouse/Keyboard)	Power	100-240V 50/60Hz 77W Max@100W/5V, 3A@5V/2.5W/5W
Recommended Viewing Distance	3.28ft(1m)-16.4ft(5m)	Net Weight	2.65lbs(1.2kg)

TROUBLESHOOTING GUIDE

- **The projector has no sound, muffled, unclear sound, or sound distortion?**
  - Check if the volume is too low or muted. Adjust the volume to a comfortable level.
  - Ensure the audio cable is properly connected to the projector and the audio source device.
- **After boot-up, the TV screen is small. How to correct from 4:3 to 16:9, and fill the whole screen of the projection?**
  - Go to Settings > Display > Aspect Ratio, and choose the appropriate aspect ratio for the projection.
- **Black Screen**
  - Check if the power cable is connected.
  - Ensure the projector is turned on.
  - Verify that the input source is set correctly.
- **Poor Image Quality**
  - Clean the lens with a soft, lint-free cloth.
  - Adjust the focus ring to sharpen the image.
  - Ensure the projection surface is clean and smooth.
- **Remote Control Issues**
  - Check the batteries in the remote control.
  - Ensure there are no obstructions between the remote control and the projector's sensor.
  - Try resetting the remote control by removing the batteries and pressing each button once.
- **Overheating**
  - Ensure the projector has adequate ventilation.
  - Clean the air vents and filters regularly.
  - Avoid using the projector in high-temperature environments.
- **Lamp Not Turning On**
  - Check the power connection.
  - Wait for the lamp to cool down if it was recently turned off.
  - Replace the lamp if it has reached the end of its lifespan.
- **Error Messages**
  - Refer to the user manual for specific error codes and their meanings.
  - Follow the recommended actions to resolve the issue.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

HDMI Warning

Use only high-speed HDMI cables that bear the HDMI trademark. Standard or unapproved HDMI cables may cause compatibility issues, signal loss, or failure to display 4K content properly.

Ensure that both the HDMI cable and the connected devices support the required bandwidth and resolution for 4K playback.

Avoid using HDMI cables longer than 15 feet (4.5 meters) without a signal booster, as this can degrade signal quality.

Regularly check HDMI connections for dust, debris, or damage that could affect performance.

Declaration of Conformity

We, Shenzhen Vankyo Information Technology Co., Ltd., declare under our sole responsibility that the product VP1W1AA is in conformity with the following standards or other normative documents:

EN 55032:2015+A11:2020+A1:2020
EN 55035:2017+A11:2020
EN IEC 61000-3-2:2019+A1:2021
EN 61000-3-3:2013+A1:2019+A2:2021
EN 62368-1:2020+A11:2020
EN 62311:2020
EN 50581:2012
EN 300 328 V2.2.2
EN 301 489-1 V2.2.3
EN 301 489-17 V3.2.4
EN 303 345-1 V1.1.7
EN 303 345-2 V1.1.7

The technical documentation relevant to the above equipment will be held at: Shenzhen Vankyo Information Technology Co., Ltd., Room 1101, Building 1, Yiyuan Industrial Zone, Zhenxing Road, Yantian District, Shenzhen, China

Manufacturer: Shenzhen Vankyo Information Technology Co., Ltd.
Address: Room 1101, Building 1, Yiyuan Industrial Zone, Zhenxing Road, Yantian District, Shenzhen, China