0 mm

40 mm



Design by Manuela Simonelli & Andrea Quaglio

ENGLISH

IN THE BOX — Te Unità Type-C di ricarica — Ne USB Type-C charging cable — Ve User manual

PRODUCT OVERVIEW
A. Touch area (controls the lamp's function)
B. Lamp
C. Base (for lamp synchronization)
D. Reset tiny hole
E. Reverse for wireless charging
F. LED indicator (battery & charging status)
G. USB Type-C charging port

FEATURES
- Dimmable LED lamp with 3 colors (warm white, cold white, blue, yellow, green, red, purple, light pink & light blue)
- Dimmable LED lights with memory system
- Touch control (touch & hold to turn lamp on/off)
- Suitable for outdoor use (IP54)
- Rechargeable via wireless charging or USB Type-C

CHARGING
We recommend you to fully charge the battery before using LUMA L for the first time.
The battery is fully charged when the touch dial lights automatically & the LED charging and 4 hours via wireless charging.

LED information

Operation mode	LED status (Next LED)
Charging	LED indicator remains ON
Fully charged	LED indicator remains OFF
Low battery	LED indicator remains ON

Charge with USB Cable
1. Plug the provided USB Type-C cable into the charging port of LUMA L.
2. Plug the other end of the cable into any computer or any DC 5V power supply charger.

Charge with Wireless Charge
1. Flip the base of LUMA L to reverse charging mode. You can charge the battery by using a wireless charger.
2. Place LUMA L at the center of the wireless charger.
3. Disconnect the device once the battery has been fully charged

OPERATING INSTRUCTIONS
Setting up unit LUMA L lamp
- Touch & hold the touch area to turn it ON.
- There are 9 colors options you can select by touching the top of the lamp.
- To adjust brightness, touch the top area until you reached the desired brightness then release.
- Touch & hold the touch area to turn it OFF. The unit will remember the brightness then touch again.
- The last unit will be remembered for next time.

Note: If you want to set LUMA L in cool and warm light mode only, quickly tap 3 times on the top area. To return to full set lighting mode, repeat the procedure.

Syncing several LUMA L lamps (interconnection network)
LUMA L lamps can be synced to form a network with any other third-party eco-friendly eco-friendly software.
To enjoy the multiple table synchronization feature, follow these instructions:

1. Press and hold the BT button at the bottom of each lamp for 5 seconds to turn ON the communication mode.
2. Select one of the lamps and press the BT button twice to initiate the multi-pairing procedure.
3. The lamp will automatically search for other LUMA L lamps.
4. The lamp connected to the master will become a MASTER in the system, its LED will keep flashing while others are turned OFF.

You can now interact from any lamp the touch area: adjust brightness or turn ON & OFF all lamps at once.

Important note: Bluetooth connection will be lost if the distance between the lamps is more than 10 m (33 ft).
If you enable the Bluetooth on one of your lamps to connect it to the network, but no not complete the pairing, the lamp's Bluetooth mode will turn off after 3 minutes automatically.

Add one or more LUMA L lamps to the network
1. Press and hold the BT button at the bottom of the lamp for 5 seconds (ON) to pressing and holding the BT button on each unit for 5 seconds.
2. Press once on the pairing button of any lamp from the existing network (repeat the procedure with any new device).

Exclusive LUMA L BLUETOOTH function
LUMA L is equipped with a unique locking system allowing only One lamp to control all others, preventing any change of color, brightness or on/off status. Only the master lamp can control the network. The main lamp (MASTER) is the only one to control the network, its LED is flashing.

To enable LOCK function, take the MASTER units and follow below instructions:

1. Press 3 times on the MASTER lamp touch & will emit a beep sound ALL other lamps to LOCK.
2. In LOCK mode, only MASTER interact with other lamps. All LEDs flashing every 5 seconds.
3. Network is now locked, only pressing 3 times on the BT button from the MASTER lamp

To change the MASTER device
1. Press 3 times on the touch area.
2. Press the BT button on any device for 10 times, this device will become the new MASTER device.
You can now LOCK and UNLOCK the network from this new device.

Important note: In LOCKING mode, MASTER lamp is the only one to control the network. It is strongly recommended to always keep the MASTER device in charge to fully charged to get the best experience and avoid loss of control of the entire network.

Other working conditions
- Bluetooth connection will be lost if the network is broken, double tap on the top of the MASTER device.
You'll need to tap on the MASTER again to turn all lamps back ON.
- Turning OFF the MASTER lamp will turn OFF all lamps. Turning ON the BT button from more than 10 seconds until the lamp turns OFF. (To avoid accidental turning OFF, the touch area is deactivated for 5 seconds after turning ON the lamp).
- To reset the lamp, insert a thin object into the hole (it) under the lamp and press the key inside.
- A manual shutoff allows you to reboot your device and correct miscellaneous bugs (unrecognized device, unstable Bluetooth connection...)

LED information

Operation mode	LED status (Next LED)
Pairing mode	LED indicator flashes
Connected	LED indicator remains ON

SAFETY PRECAUTIONS
- IP54 water resistant device, resistant to rain, splash, and spray water.
- Do not immerse the device in water or any other liquid. Do not use in a humid environment (bathing, tub, deformation or even explosion of the battery.
- Do not use the device in very hot or cold areas. It is recommended to use your device at room temperature.
- Do not attempt to service, repair or disassemble the device yourself.
- Do not use the device if the power cable or power plug is damaged or use a power adapter delivering more voltage output than the one indicated to avoid any irreversible damage to the internal circuit (DC input) 5V).