封面

ECS3001T

1MORE

1MORE PistonBuds 真无线耳机 用户指南
1MORE PistonBuds True Wireless In-Ear Headphones User Guide

封底

FCC ID: 2A5DJECS3001T
DM码: XXXXXXXXX IC: 24952-ECS3001T
生产日期见外包装印刷日期或产品标签
制造商：万魔声学科技有限公司
地址：深圳市南山区西丽街道留仙大道创智云城A座1603
Manufacturer: Shenzhen 1More Acoustic Technology Co., Ltd.
Address: Tianliao Building 1603, Zone A Chuangzhi Industrial Park, Taoyuan Sts, Nanshan Dist, Shenzhen City, China

简中

包装内容

耳机
充电盒
Type-C 充电线
硅胶耳塞套 (S / L)

耳机

触控区
指示灯
麦克风

充电盒

指示灯
Type-C 充电接口

说明书中的产品、部件、图片类等信息均为示意图，仅供参考，由于产品的更新与升级，产品实物与示意图可能略有差异，请以实物为准。

首次连接

1. 首次开机，左、右耳机进入 TWS 左、右连接状态，当其中一个耳机灯、蓝灯都闪烁时，表明左、右配对成功。

2. 耳机进入设备的蓝牙搜索配对模式，点击设备列表中的设备名 "1MORE PistonBuds"，进行连接。

3. 如 3 分钟内未进行任何连接和操作，左、右耳机关机，LED 灯熄灭。

* 左、右耳机入盒后，重新开盖取出，即可开机。

取出回连功能

取出耳机，同时蓝色指示灯闪烁，左、右耳机先进行 TWS 回连，再回连至最近一次连过的设备。

断开蓝牙连接

从手机断开与耳机的蓝牙连接，耳机在 TWS 左、右连接状态时，耳机进入搜索配对模式，3 分钟内未连接，左、右耳机自动关机。再放入充电盒，再次取出即可开机。

清除连接记录（仅适用于 TWS 左、右连接状态）

耳机在盒中，TWS 左、右连接状态时，同时长按左右耳机触控区 7 秒，耳机 LED 蓝灯由快闪变为长亮，即可清除耳机与设备的连接记录。

此功能针对一个耳机的连接记录，只需长按对应的耳机，进行以上同样操作。左、右耳机即可分别单独使用。

充电

● 为耳机充电

将耳机放入充电盒，自动进入充电状态，耳机红色指示灯亮起。

● 使用 Type-C 充电线为充电盒充电

充电时，充电盒红色指示灯常亮，充满电时，白灯熄灭。

查看电量

● 查看耳机电量

耳机连接手机后，可在手机状态栏查看耳机电量*。

* 手机状态栏仅显示两个耳机中电量较低的耳机电量，部分手机不支持。

待机

耳机放回充电盒，自动断连并进入充电状态。

佩戴

将耳机从充电盒取出，按照耳机左、右标识进行佩戴。

低电量关机

当电量达到关机电压时，红色 LED 长亮 1 秒，耳机自动关机。

* 耳机未在使用时，请及时将耳机放回充电盒，以延长您耳机电量及电池寿命。

按键功能

通话

接听 / 挂断：双击

* 上述功能适用于单、双耳模式
使用前打开一对耳。

播放

播放 / 暂停（双耳）：
双击右耳机
播放 / 暂停（单耳）：双击
唤醒语音助手（双耳）：
双击左耳机

* 单耳、语音功能，请在手机上进行操作。

提示

1. 使用产品前请仔细阅读本使用说明书并遵守其规定。
2. 仅交换用，请先将本产品充满电；
3. 如果产品长期（超过 3 个月）不使用，请对其充电；
4. 必须选择正规厂家生产的经过第三方权威机构认证的充电和配套设备；
5. 在干燥环境佩戴，静电可能会触发耳机产生瞬间发解的感觉，这为产品质量生感无关。

警告

1. 请勿以任何理由拆除或维修改装产品，否则会导致超保；电子击穿超出范围损坏本产品。
2. 请勿将设备置于温度过低或过高（0℃ 以下或 45℃ 以上）的环境中。
3. 请勿在雷雨天气下使用该设备，雷暴可导致设备工作不正常，并增加触电的危险；
4. 请勿将该及其它配套性使用耳机产品；
5. 请勿连续长时间佩戴耳机（超过5小时），尤其不要在时间佩戴大音量耳机；
6. 请勿在骑车或开车的状态下佩戴耳机，因为这样行为容易因影响听力甚至行为；
7. 六岁以下儿童请在成人监护下使用耳机；
8. 如佩戴耳机后感到耳朵不适，建议立即耳机，防止发生因过度佩戴而导致听力损伤；
9. 本产品内含锂电池，禁止拆解、撞击、挤压或投入火中，若出现膨胀，请勿使用。请勿置于高温环境中。

环保支持

产品中所含有物质的名称及含量

部件名称	有害物质或元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
耳机外壳	O	O	O	O	O	O
电路板组装件	X	O	O	O	O	O
扬声	X	O	O	O	O	O
充电	O	O	O	O	O	O
附件	O	O	O	O	O	O
电池组	X	O	O	O	O	O

本表格依据 SJ/T 11364 的规定编制。

O：表示该有害物质在该部件所有均质材料中的含量 GB/T 26572 规定的限量要求以下。

X：表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 规定的限量要求。

产品保修说明

1MORE PistonBuds 真无线耳机产品整包按《中华人民共和国消费者权益保护法》、《中华人民共和国产品质量法》实行产品售后服务，服务内容如下：

自产品购买之日起一年在免费保修期内，您可以获取本规定享受基础、按提、维修的权利。修理、维修、退货应当符合本三项等规定免费办理。

1、 产品无提自的退货（包装鉴退），由用户承担运费用；

2、免费维修或以换代修的产品的保修期仍然按原始产品的购买日期计算一年免费保修期。

3、本产品出现《产品性能故障表》所列性能故障的情况，经检测确定后，可以免费享受如下服务。

服务类型	服务政策
退货	自您收货日起 7 天内产品质量问题退货
换货	自您收货日起 15 天内产品质量原则换货
维修	自您收货日起 1 年内产品质量问题免费修

产品性能故障表	
名称	性能故障
1MORE PistonBuds 真无线耳机	连续不同型号两次出现耳机、麦克风无声 触控功能失效 因机械损坏问题造成硬件故障

非保修条例

1. 未经授权的维修、误用、疏忽、意外、滥用、进液、事故、改动、不正确的使用非本产品配件、或商业、违反标贴、损伤标记；
2. 已超过三包有效期；
3. 因不可抗力造成的损坏；
4. 不符合《产品性能故障表》所列性能故障的情况；
5. 因人为原因导致本产品及其他外产生《产品性能故障表》所列性能故障。

更多服务可登录 1MORE 官方网站 www.1more.com 点击 "服务" 联系客服服务热线：400-992-0909

FAQ

1. 耳机无法开机，该如何解决？
请确认耳机有电，若耳机没有电，请充电 30 分钟以上再开机。
2. 耳机与手机蓝牙无法正常连接，连接时间长，该如何解决？
1）如左、右耳机无法配对，在一个耳机可与手机连接时，可将左、右耳机放入充电盒中，同时长按左、右耳机触控区 7 秒，直至蓝灯长亮，左、右耳机即可连接，之后可与手机进行配对连接。
2）如需与新的手机设备连接，在已连接过的手机上删除与耳机的配对，或将左、右耳机放入充电盒中，同时长按左、右耳机触控区 7 秒直至蓝灯常亮，耳机即可进入搜索状态，可与新设备进行连接。
3）左、右耳机放入充电盒中约 30 秒，可保制盖口。

基本参数

型号：ECS3001T
单耳重量：4.2 克
整机重量：43.2 克
充电盒尺寸：70.0 × 25.7 × 36.8 mm
充电接口：Type-C
耳机功能：TWS
输入：5V⎓1A
输出：5V⎓100mA
蓝牙版本：Bluetooth® 5.0
蓝牙协议：HFP/HSP/A2DP/AVRCP
音频格式：AAC/SBC
通讯距离：10 米（空旷环境下）
充电盒电池容量：535mAh
充电时间：2 小时
单耳满电续航：约 3.5 小时*
耳机 + 充电盒满电续航：约 20 小时*
工作温度：0 ℃ ~ 45 ℃
频率波段：2.400 GHz ~ 2.4835 GHz

* 续航参数为实验室测试数据。
* 播放时长为 AAC 格式、50% 音量条件下的实验室测试数据，非实际使用，作用，使用情况及音乐时长因素可能有所差异。

制造商：万魔声学科技有限公司
地址：深圳市南山区西丽街道留仙大道创智云城 A 区田厦大厦 1603

简中

3. 安卓系统手机连接耳机成功后，无法听到音乐，该如何解决？
在耳机与手机连接成功后，点击所连接设备名称右边的图标，进入后确保 "媒体音频" 选项已被开启。
4. 在安卓系统手机连接耳机成功后，无法通话，该如何解决？
在耳机与手机连接成功后，点击所连接设备名称右边的图标，进入后确保 "手机通话" 选项已被开启。
5. 蓝牙连接不稳定，出现断续情况，该如何解决？
1）离开易电设备与耳机之间的距离，避开实体障碍物；
2）清出易受干扰蓝牙端（Wi-Fi / GPRS 等）；
3）请确保手机未找不成进程；
6. 使用第三方音乐播放软件时，为什么音分按键功能与说明书定义不一致？
1）手机软件与第三方软件设定义不同而导致耳机按键功能有差异；
2）建议使用品牌手机系统自带音乐播放器；
7. 使用耳机通话时音量最大型，声音仍偏小，该如何解决？
在不同的手机操作系统中（如安卓），耳机音量加减功能与手机音量加减功能是独立操作状态，请根据您的具体需求，分别调节手机及耳机的音量。

* 更多使用节的产品实际使用问题解析，请登 录 1MORE 官方网站 "技术支持" 查看详细。

英文

In The Box

Earbuds

Charging Case

Type-C Charging Cable

Silicone Ear Tip (S / L)

Earbuds

Charging Case

Note: Above illustration is for reference only. The real product may be slightly different due to product updates.

Charge

● Charge the Earbuds

Put the earbuds into the charging case and charging will start automatically. The LEDs of the earbuds will indicate in red.

● Charge the Charging Case with Type-C Cable

Connect the charging case to a power source and charging will start automatically. The LED indicator will stay white when charging and turn off once fully charged.

Check the Battery Level

● Check the Battery Level of the Earbuds

Check the battery level of the earbuds from your phone screen when successfully paired.

* Only the battery level of the earbud with lower power will be displayed in some phone models as not all support the function.

Standby Mode

Place the earbuds into the case, the earbuds will disconnect with your device and enter charging mode.

How to Wear

Take the earbuds out of the case and wear them properly as per the L and R indications.

Auto-Off when Battery Low

When battery is low the earbuds will turn off automatically with the LED indicator glowing solid red for 1 second.

* Place the earbuds back into the case when not in use to extend their service life and preserve them.

Initial Pairing

1. Uncover the case, the earbuds will turn on and connect to each other automatically (TWS mode). TWS mode connection is successful when the LED indicator turns solid blue briefly.
2. Go to your device setting, enable the Bluetooth function and find "1MORE PistonBuds" in the Bluetooth connection list. Tap on the name to connect.
3. The earbuds will turn off automatically if there is no connection in 3 minutes.

* Place the earbuds back into the case and take out, they will turn on again.

Auto Pairing

Take the earbuds out of the case, and the LEDs flash in blue, the earbuds will connect with each other first then try to reconnect with the latest connected device automatically.

Disconnect Bluetooth Connection

Disconnect the earbuds from your phone: The earbuds will disconnect from your phone with previously paired devices. The earbuds will turn off automatically if there is no connection within 3 minutes. Place earbuds back into the case first then take them out again to power on.

Clear Pairing Record (Only Available in TWS Mode)

Keep the earbuds in the case in TWS mode, open the lid, press and hold the Touch Control of earbuds simultaneously for 7 seconds, and the earbud LEDs start flashing. You can clear the pairing history if the LEDs glow in blue.

To clear either of pairing records, press and hold the Touch Control of the earbud, repeat the steps above, and then the Left and Right earbud can work separately.

Controls

Phone Call

Answer/End Call: Double Tap

* Above functions are available for either earbud in individual / stereo mode.

Playback

Play / Pause (Stereo Mode): Double click on right earbud

Play / Pause (Single Mode): Double click

Activate Voice Control: Double click on left earbud

* Volume and Song Change above operate via your mobile phone.

1MORE (1) Year Limited Warranty

1MORE warrants to the original retail purchaser that this product is to be free from defective materials and workmanship for a period of one year from the date of purchase if it is properly used and maintained. If this product proves defective in either material or workmanship during the one year period, 1MORE will replace product with new or refurbished parts; or (b) replace the product with an equivalent new or refurbished product, at no charge for parts or labor. If the product model is no longer available and cannot be repaired, 1MORE will replace it with an equivalent model. 1MORE at its sole option will replace the defective product with one of equal or greater value. In some cases, modification to the mounting surface may be required where a new model is substituted. 1MORE assumes no responsibility or liability for modification to the mounting surface. THIS IS A REPLACEMENT UNDER THE TERMS OF THIS WARRANTY. PLEASE RETURN TO THE ORIGINAL DEALER/PURCHASE AND THE ORIGINAL DEALER SHALL REPAIR THE PRODUCT WITH NEW OR REFURBISHED PARTS OR REPLACE THE PRODUCT WITH AN EQUIVALENT NEW OR REFURBISHED PRODUCT.

You will be required to submit proof of purchasing details, including but not limited to a receipt or sales invoice.

Return shipping for exchanges/repairs is the sole responsibility of the original purchasers.

Limitations:

• This limited warranty does not cover the failure of the product resulting from improper installation, misuse, abuse, accident, neglect, mishandling, or wear from ordinary use or commercial use of the product.
• This limited warranty does not cover cosmetic damage, including paint damage, or consequential damage to other components or premises which may result for any reason from the failure of the product.
• This limited warranty is null and void for products not used in accordance with 1MORE's instructions.
• This limited warranty is null and void for products with altered or missing serial numbers and for products not purchased from an AUTHORIZED dealer.
• This limited warranty terminates if you sell or otherwise transfer this product to another party.

We Appreciate Your Business

We know you will enjoy new 1MORE headphones as much as we do. At 1MORE, we value your satisfaction. If you would like more detail on this product or any of our other products, please visit us online by scanning the QR code. Go to www.1more.com and sign up for VIP and 1MORE will treat you like one.

Tips

1. Please read this instruction manual carefully and retain for future reference.
2. Please fully charge the battery before first use.
3. If the headphones have been unused for more than 3 months, we recommend that you charge them. This will improve battery capacity.
4. Only use charging cables and adapters that are FCC (Federal Communications Commission) approved.
5. In dry environments, static electricity may numb your ear. This is not related to the quality of the product.

Safety Information

1. Never disassemble the headphones. There are no user-serviceable parts inside.
2. Do not expose the headphones to temperatures below 14 °F (-10 °C) or temperatures above 113 °F (45 °C).
3. Do not use the headphones in a thunderstorm alarms. This could prevent the headphones from working properly, and also increase your chance of being electrically shocked.
4. Do not use oil or any volatile liquid to clean this product.
5. Do not listen at high volumes for extended periods of time.
6. Do not use the headphones in traffic. Do not use the headphones any time it would be dangerous to be unaware of noises around you.
7. Adult supervision is required for children of age 6 and under.

FAQ

1. Why the headphones cannot be turned on?
   Check if your headphones have enough battery life, if not, please charge them for at least 30 minutes.
2. Why the headphones cannot connect to my cellphone, or takes long time to connect?
   1) If the Left and Right earbud cannot pair to each other, and only one of earbuds is connected to the mobile phone, put earbuds into the case, press and hold the Touch Control of both earbuds for 7 seconds simultaneously. If the earbud LEDs glow in blue, which indicates Left and Right earbuds have paired successfully, then the earbuds can be connected to the mobile phone.
   2) If the earbuds fail to connect to a new mobile phone, please remove the paired record from the paired phone, or put earbuds into the case, press and hold the Touch Control of both earbuds for 7 seconds simultaneously. If the earbud LEDs glow in blue, and then take earbuds out of the case to start the pairing to a new phone.
   3) Place the earbuds into the case, and uncover the case for 30 seconds to restore the earbuds into default settings.
3. Why the headphones cannot play music after successfully connecting to my Android device?
   After pairing successfully, on the Bluetooth menu of your device, tap the icon on the right of your device name and make sure the "Media Audio" option is on.
4. Why there is no sound from the headphones while making phone calls after successfully connecting to my Android device?
   After pairing successfully, on the Bluetooth menu of your device, tap the icon on the right of your device name and make sure the "Phone Audio" option is on.
5. Why the Bluetooth connection is not stable and causes some interruptions?
   1) Try shortening the distance between your device and headphones. Avoid solid barriers in between.
   2) Please keep away from strong interference sources, such as Wi-Fi and GPRS.
   3) Please make sure the Bluetooth antenna of your device is not blocked.
6. Why some control functions do not match while playing music? Is it playing third party music/video player Apps?
   Your operating system and the third party music/video player apps may have different settings for the remote control function. We recommend that you use the music/video player apps that your device originally delivered with.
7. I turned the headphones up to the maximum volume, but why the actual volume still sounds low?
   In different operating systems, especially Android systems with different brands and your device have separate volume control systems. Please adjust the volume controls on both the device and the headphones according to your preference.
8. Why are my headphones not able to connect to "1MORE MUSIC APP for the primary pair" every time? Do I need to pair with "1MORE" every time* to access the location information of your device when entering "1MORE MUSIC APP"? Or adjust this option in your settings for this app.

* For more detailed product FAQs, please visit the product support section under www.1more.com

After pairing successfully, on the Bluetooth menu of your device, tap the icon on the right of your device name and make sure the "Phone Audio" option is on.

5. Why the Bluetooth connection is not stable and causes some interruptions?
   1) Try shortening the distance between your device and headphones. Avoid solid barriers in between.
   2) Please keep away from strong interference sources, such as Wi-Fi and GPRS.
   3) Please make sure the Bluetooth antenna of your device is not blocked.
6. Why some control functions do not match while playing music? Is it playing third party music/video player Apps?
   Your operating system and the third party music/video player apps may have different settings for the remote control function. We recommend that you use the music/video player apps that your device originally delivered with.
7. I turned the headphones up to the maximum volume, but why the actual volume still sounds low?
   In different operating systems, especially Android systems with different brands and your device have separate volume control systems. Please adjust the volume controls on both the device and the headphones according to your preference.
8. Why are my headphones not able to connect to "1MORE MUSIC APP for the primary pair" every time? Do I need to pair with "1MORE" every time* to access the location information of your device when entering "1MORE MUSIC APP"? Or adjust this option in your settings for this app.

* For more detailed product FAQs, please visit the product support section under www.1more.com

Warning

Replacement of a battery with an incorrect type that can defeat a safeguard (such as certain lithium battery types), explosion, leakage of corrosive electrolyte etc);

Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion;

Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas, or a battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

⎓ The symbol indicates DC voltage.

RECYCLING

This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE).

This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimise its impact on the environment.

User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.

To prevent possible hearing damage, do not listen at high volume levels for long periods.

WEEE

Electrical and electronic equipment, parts and batteries marked with this symbol must not be disposed of with normal household wastage. It is the responsibility of the user to dispose of separately to protect the environment.

Your 1MORE retailer will advise you of the correct way of disposal in your country.

Safety Caution

Do not expose batteries or battery packs to excessive heat such as sunshine, fire or the like.

CE

Declaration of Conformity Hereby, Tinhlo Acoustic Technology Limited declares that the radio equipment type 1MORE PistonBuds True Wireless Earbuds is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:www.1more.com

RF exposure information: The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction. Radiation Exposure Statement Power is so low that no RF exposure calculation is needed.

Declaration for EU Compliance
Operation Frequency/Max.
2400-2483.5MHz, Left ear Max.
EIRP is 9.20dBm, Right ear Max.
EIRP is 9.20dBm.

FCC

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device type: ECS300T(FCC ID: 2AHDP-ECS300T) has also been tested against this SAR limit. This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changesto this equipment. Such modifications or changes could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and

on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
•Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
•Consult the dealer or an experienced radio/TV technician for help.

Supplier's Declaration of Conformity
47 CFR § 2.1077 Compliance Information
Unique Identifier
Trade Name: 1MORE
Model No.: ECS300T
Responsible Party – U.S. Contact Information
1MORE USA, Inc.
Address: 10225 Barnes Canyon Road, Suite A202, San Diego, California, 92121
Tel:1-858-257-2973
E-mail: support@1moreusa.com

Complies with IMDA Standards DB102018(E)

IC Statement

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:
(1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. Cet appareil est conforme avec Industrie Canada RSS exemptes de licence standard(s).

Son fonctionnement est soumis aux deux conditions suivantes:
(1) cet appareil ne peut pas provoquer d'interférences, et (2) cet appareil doit accepter toute interférence, y compris celles pouvant causer un mauvais fonctionnement de l'appareil.This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

This device has been tested for compliance with IC SAR value at a typical operating near the body. To ensure that RF exposure levels below the levels tested, use accessories with this equipment to maintain a minimum separation distance of 0 cm between the body of the user and the device. The use of belt clips, holsters and similar accessories containing metallic components is not possible. It is possible that the accessories used close to the body that do not meet these requirements are not consistent with the SAR limits and it is advisable to avoid using them.

Ce dispositif a été testé pour être conformité avec les valeurs SAR à un fonctionnement typique près du corps . Pour assurer que les niveaux d'exposition aux radiofréquences en deçà des niveaux testés , utiliser des accessoires avec cet équipement pour maintenir une distance de séparation de 0 cm entre le corps de l'utilisateur et l'appareil. Des accessoires ne doivent pas contenir des composants métalliques . Il est possible que les accessoires utilisés près du corps qui ne répondent pas à ces exigences ne sont pas compatibles avec les limites SAR et il est conseillé d'éviter de les utiliser.

Specifications

Model: ECS300T
Earbud Weight: 4.2g
Product Weight: 45.2g
Case Size: 70.6 × 25.7 × 36.2 mm
Charging Port: Type C
Speaker Impedance: 16Ω
Input: 5V⎓1A
Output: 5V⎓150mA
Bluetooth: Bluetooth® 5.2
Bluetooth Profiles: HFP / A2DP / AVRCP
Audio Codec: AAC/SBC
Wireless Range: 10m
(Open and unobstructed environment)
Charging Case Battery Capacity: 535mAh
Charging Time: 2h
Playtime with each earbud fully charged: approx. 5.5h*
Total Playtime with Case: approx. 20h*
Working Temperature: 0 °C ~ 45 °C
Frequency Band: 2.400 GHz ~ 2.4835 GHz

The specifications are acquired from laboratory tested data. *The playback time, tested under the laboratory condition of AAC format and 50% volume, may vary with different device setting, environments, usage and other factors.

Manufacturer: Tinhlo Acoustic Technology Limited
Address: Tonfeo Building 1403, Zone A Tonfeo Industrial Park, Tongsan Rd., Nanshan Dis., Shenzhen, PJN, China
Product information can be found at www.1more.com