Initial Setup

HUMANCENTRIC

STEP ONE

Charge your speakerphone fully before the first use. The device will take about 3-4 hours to fully charge and lasts for about 10 hours of talk time.

To charge your device, use the included USB cable to plug the device into your computer or a standard USB charger.

STEP TWO

Connect your speakerphone to your phone or a Mac® or Windows® PC to start using the device.

Connect via Bluetooth®

When the device is powered on, hold the 🅱 button for 3 seconds. The LED light will blink blue when pairing mode is activated.

Find the device "HC-SP1" from the list of available devices. Select the device to begin pairing with the speakerphone.

Connect via USB or AUX

Use the included cable to connect the speakerphone to the USB or AUX port on a computer, or the AUX port on a phone.

The device requires no software installation, but system or application audio settings may need to be configured on your computer or phone.

IMPORTANT PRODUCT INFORMATION

Safety, compliance, recycling, warranty, and other important information regarding your device can be found online at support.humancentric.com/article/26-301-1002-safety-and-compliance

© 2018 HumanCentric Ventures LLC. All rights reserved. HumanCentric® is a trademark of HumanCentric Ventures LLC. The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by HumanCentric is under license.

MADE IN CHINA   MODEL: 301-1002
FCC ID: 2ASQ3-3011002   IC: 26081-3011002
PRODUCT TITLE: Bluetooth/USB/AUX call speakerphone

WARRANTY

Limited Two (2) Year Warranty with proof of purchase. Exempt from warranty are limited-life consumable components subject to normal wear and tear, such as batteries and other accessories. For warranty service, visit support.humancentric.com.

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

RF Warning Statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

L'appa reil a été évalué pour répondre a ux exigences généra les d'exposit ion R F. L'appa reil peut être utilisé dans des conditions d'exposit ion port a bles sans rest riction.

IC Caution:

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:
(1) This device may not cause interference, and
(2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux apparei ls radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:
(1) l'appareil ne doit pas produire de brouillage, et
(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Let's Get Started.

HUMANCENTRIC

GET TO KNOW YOUR BLUETOOTH® SPEAKERPHONE

- Power On / Off
- Volume Up
- Light Ring
- Bluetooth® / Switch Input
- Accept / End Call
- Mute
- Volume Down

USB — AUX

Power On / Off
Press and hold the ⏻ button for 2 seconds

Connect to Bluetooth®
When the device is powered on, it will automatically reconnect to a previously connected device.

To pair an additional device: Hold the ✶ button for 3 seconds. The LED light will blink blue when pairing mode is activated, and the speakerphone will be listed as "HC-SP1".

Switch Input
If multiple inputs are used at the same time (USB, AUX, Bluetooth®) tap the ✶ button to switch.

Adjust Volume
Tap the + or − to adjust the speaker volume.

Mute Microphone
Tap the ⓜ button. The light ring will light up red when the microphone is muted.

Accept Incoming Call
Tap the ☎ button to accept an incoming call.

End Current Call
Press and hold the ☎ button for 1 second while on a call to hang up.

Check Battery Level
Tap the ⏻ button and the light ring will indicate the battery percentage of the speakerphone (e.g. at 50%, half of the light ring will light up).

Open Voice Assistant
Double tap the ☎ to open the voice assistant (Siri, Google, etc.) on your phone.

Flip this over to see instructions on the initial set up