Solar Bluetooth Speaker



NT-SL01

Instruction Manual

Please read all of the instructions carefully and retain for future reference

Safety Instructions

1.When using electrical units , basic safety precautions should always be followed.
2.Children aged from 8 years and people with reduced physical , sensory or mental capabilities or lack of experience and knowledge can use this unit , only if they have been given supervision or instruction concerning use of the unit in a safe way and understand the hazards involved .
3.Children should be supervised to ensure that they do not play with unit .
4.Unless they are older than 8 and supervised , children should not perform cleaning or user maintenance .
5.This unit is not a toy .
6.This unit contains no user serviceable parts , if the unit and any of its accessories are malfunctioning or it has been dropped or damaged , only a qualified electrician should carry out repairs , improper repairs may place the user at risk of harm .
7.Keep the unit out of reach of children .
8.Keep the unit away from heat or sharp edges that could cause damage .
9.Keep the unit away from heat sources , direct sunlight , humidity , water and any other liquid .
10.Keep the unit free from dust lint etc .
11.Do not immerse the unit in water or any other liquid .
12.Do not operate the unit if it has been expose to water , moisture or any other liquid to prevent against electric shock , explosion and / or injury to yourself and damage to the unit .
13.Do not use the unit for anything other than its intended use .
14.Do not store the unit in direct sunlight or in high humidity conditions .
15.Do not put objects into any of the openings .
16.Do not play music at excessive volume levels as damage to hearing and / or the equipment may occur . It is imperative to unplug the adaptor after the unit has been used , before it is cleaned and whilst being repaired .
17.To prevent possible hearing damage , do not listen at high volume levels for long periods of time .
18.Warning : Keep the unit away from flammable materials .

Specifications

Solar Power :	DC 5V/7W
Power Supply:	DC 5V Micro USB
Output Power :	4W
Driver Unit :	2"4Ω 5W*1
Bluetooth Version :	v5.0
FM Frequency Range :	76-108 MHz
Frequency Response :	90Hz - 20KHz
S/N Ratio :	≥ 58dB
Rechargeable Battery :	Lithium 3.7V 1200mAh
Product Size :	W215*H68*D68 mm

Getting Started

1. Remove the unit from the box .
2. Remove any packaging from the unit .
3. Place the packaging inside the box and either store or dispose of safety

In The Box

Bluetooth Speaker	*1
USB Charging Cable	*1
Carry Strap	*1
Instruction Manual	*1

Instructions for Use

Auto Power off

When the machine is disconnected from bluetooth for 5 minutes, the audio will be automatically turned off and the power switch needs to be turned on again for reuse.

FM Radio

Push the power switch to “ON”, short press the “M” key to switch to FM radio. Then long press the “ ⏯ ” key to auto search and memory to save the radio.

Wireless Bluetooth

1. Push the power switch to “NO” after hearing “BT mode” search for “NT-SL01” and confirm, then hearing the two jingling sound.



After bluetooth connection between (A) and mobile phone, turn on (B) machine in bluetooth state, then press (M/BT) key of (A) machine for more than 3 seconds until you hear (B) connected (TWS) state send out “Jingle” two sound.

2. In the bluetooth state, press the key” ⏯ “ for a long time. It will forcibly disconnect the current device connection.

Instructions for Use

Wireless Call Function

1. In the “BT” state, you can talk to the phone in the front of machine while phone calls and short press the” ⏯ “ key.



2. Long press” ⏯ “ button is forced to disconnect the current bluetooth device, and then wait to connect to other bluetooth devices. Again long press the “ ⏯ “ button is reconncted to the original bluetooth device.

USB / TF Player

1. The USB /TF card are respectively inserted into the corresponding sockets.
2. The volume is controlled by a long press”+” key or long press “-” key. Short press”-” key or “+” key to select the previous and next song.

3. Press the “ ⏯ ” key to pause the playing.



Aux

1. Insert the audio cable into the “AUX” socket, turn on the power switch, and press the “M/BT” key to the “V-/V+” key.

Instructions for Use

Use Of Flashlight

Short press the high brigtness flashlight switch” ☼ “ to turn on the high brightness flashlight.



Charge

1. Plug one end of the USB charging line to the machine and insert the other end to the mobile phone charge (DC 5V ≥ 1000mA). At that time, the charging LED up(red). When the battery is full of electricity, LED does out light.

2. When using the solar charging, pelase push the power to (OFF) first.



For (NT-SL01)

3. If you don’t use this machine for a long times, please charge at least once every two months

MADE IN CHINA

Instructions for Use

FCC STATEMENT
1.This device complies with Part 15 of the FCC Rules.
Operation is subject to the following two conditions:
(1)This device may not cause harmful interference,and
(2)This device must accept any interference received, including interference that may cause undesired operation.

2.Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:
The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.

NT-SL01 Manual

1) Size : W87*H120 MM
2) Material : 80g White/Black printing , folding