Tronsmart

FORCE MAX

PORTABLE OUTDOOR SPEAKER

USER MANUAL

Button Configuration



How to Use

True Wireless Stereo Pairing

1. Turn on two speaker first.
2. Press "True Wireless Stereo Pairing button" once to enter stereo pairing mode with the yellow indicator flashes.
3. If paired successfully, the stereo pairing indicator of both speakers will stay on in yellow.
4. The Bluetooth indicator of host speaker will flash. Search and click "Tronsmart Force Max" to pair.

Disconnect from True Wireless Stereo Pairing

Press "True Wireless Stereo Pairing button" once with yellow indicator off.

Hello!

Thank you for purchasing the Force Max Portable Outdoor Speaker. Please read the user manual before you unwrap it! Kindly let us know if you have any issue or if you have any additional questions or comments. Please contact us by email at support@tronsmart.com.

Package Contents

1 x Force Max Portable Outdoor Speaker
1 x Type-C Charging Cable
1 x 3.5mm Audio Cable
1 x Warranty Card
1 x User Manual
1 x Search&Refit Card
1 x Carrying Strap

USB-A Power Bank Function

Your speaker is equipped with a power bank function that can automatically detect your device and begin to charge it when the charging cable is plugged into the USB port. The output power is up to 10.5W/2.1A. In order to maintain stable music playing performance, it's not recommended to use the music and power bank function at the same time.

Power Mode

Simply connect the speaker with your mobile phone via the 3.5 mm AUX/QCA cable. Make sure to plug in an audio cable, the speaker will automatically switch to Aux-in mode.

TF Card Playback

Insert a TF card into the micro SD card slot from your TF/micro SD card when playing the card into the Aux. The maximum supported memory card is 64 GB.

USB Flash Drive Mode

The speaker will play the music from your USB flash drive when plugging the USB into the USB-A port. The maximum supported memory card is 64 GB.

Auto Power Off

The speaker will power off automatically after 1 hour if it does not pair with any device through Bluetooth. When in low battery, the speaker will power off automatically as well.

Care & Maintenance

- Do not drop, hit or shake it roughly or during transit as it can damage the product as any type of thermal may make this device malfunction.
- Do not disassemble this product & tamper to over-ventilate it parts.
- Do not bring or carry on it and treat it with care for the best performance.
- Do not keep it in dusty & wet areas. Dust, dirt & moisture from humidity can accumulate on the body of the product that as an unit will affect.
- Do not dispose the product in fire or batteries may explode or leak.

Warranty Information

Your Tronsmart Force Max Portable Outdoor Speaker is guaranteed to be original owner for 12 months from the date of purchase against defects in materials and workmanship. Please keep your purchase receipt as proof of purchase. Warranty does not cover damage caused by misuse, abuse, accident or unauthorized repair. The product cost shall not exceed the purchase price of the product. If you have any problems with using the product, please do not hesitate to contact our customer support team at support@tronsmart.com.

Specifications

Model	Force Max
Bluetooth	5.3
Bluetooth Range	10 m
Audio Encoding	SBC
Bluetooth Profiles	A2DP 1.3, AVRCP 1.5, HFP 1.7
Driver Unit	18W
Total Power Output	36W RMS
Frequency Response	60Hz-20kHz
Battery	10000 mAh/3.85V/38.5Wh Li-ion
Battery Capacity	10000mAh
Power	36W
Waterproof	IP67
Dust Proof	IP6X
Input Interface	USB-C/3.5mm Cable AUX
Dimension	286 × 115 × 110.5 mm / 11.27 × 4.53 × 4.35 inch
Weight	1.1kg (2.43 lb)

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Warning Statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Tronsmart

SHENZHEN GEEKBUY E-COMMERCE CO., LTD.
Warehouse 101N, No. 49 Wuhe Avenue, Wuhe Community, Bantian Street, Longgang District, Shenzhen
Email: support@tronsmart.com
800-1-770-1082 (USA & Canada)
+86-755-23603740 (Global)

FCC ID: 2AV5D-FORCEMAX

FC CE RoHS

www.tronsmart.com

Made in China