Internal Photographs

Internal View of EUT-1

This antenna cannot used

Non-detachable Antenna 1

Internal View of EUT-2

Internal View of EUT-3

Antenna 1

This antenna connector cannot used

Internal View of EUT-4

Internal View of EUT-5

Internal View of EUT-6