KAWA

KAWA HD Video Wireless Baby Monitor (Model:S6)

Camera (Mr C)

Monitor (Mr M)

Directory

Box Contents 1
Monitor Features 1
Camera Features 1
Monitor charging method 1
Camera power supply method 1
Camera Installation methods 1
Add camera to the baby monitor 1
Display Mode of screen 1
Night Vision 1
Monitor menu settings & more descriptions 2
Video Settings 2
Sound Settings 2
Screen Settings 3
System Settings 3
Camera Settings 3
Warning 4
Certification 4
FCC Exposure Warning Statements 4
Declaration of conformity 4

Box contents

Baby Monitor

Camera

Power Adapter (for MC)

Power Adapter (for MC)

Wall Mount

Power Adapter (for MC)

Mounting Screws Pack

2 Antennas (for 2.4GHz Camera)

Manual

Mounting Screwdriver

Monitor features



① Menu
Enter the Settings to access the system management
② Up / Volume+
In the Function interface, press the [Up] key to switch the selection.
In the Video Recording mode, long press the [Up] key to adjust the monitoring screen.
③ ④ ⑤ Navigation buttons
④ Down / Volume-
In the Function interface, press the [Down] key to switch the selection.
In the Video Recording mode, long press the [Down] key to adjust the monitoring screen.
⑤ Talk / Confirm
Long press the [Talk] key to talk to the camera.
In the Function interface, press the [Talk] key to confirm the selection.
⑥ Talk / Hang up
Short Press the [Talk] key to pick up the voice interface.
Long press the [Talk] key to hang up the voice the voice interface or close the voice interface.
⑦ Volume- / Keys
⑧ Power On/Off
Short press the [Power] key to pick up the voice interface.
Long press the [Power] key to close the voice interface or close the voice interface.
⑨ Charging Indicator
⑩ Microphone
⑪ Support Stand

Camera features

① White Angle Area
② Microphone
③ Antenna Pairing Button
④ Infrared Sensor Whitelight Indicator
⑤ Camera Antenna
⑥ Reset
⑦ Micro USB Interface
⑧ Speaker
⑨ Power Indicator (Red/Blue)
⑩ Wall Mounting Bracket

Monitor charging method

Please fully charge the Monitor before use. Charging via Power Adapter: Connect the Micro USB cable to the Power Adapter and the other end into the power adapter. If fully charged, the Monitor will automatically switch to standby mode.

Camera power supply method

① Connect one end of the Micro USB to the camera, the camera and the other end into the power adapter. (Charging time: about 3 hours)
After fully charging the Monitor can work for 5 hours by one use of camera.

Camera Installation methods

Install Camera in a well-lit area for better results!
① Select one of the installation positions
② Drill holes in the wall according to the mounting positions and screw the mounting bracket in position.
③ Attach the camera to the bracket, then mount the camera base onto the bracket.
④ Screw through the mounting base of the upper wall bracket and into the wall to secure it.
⑤ Adjust the camera to the desired viewing angle and position, then press it down to lock it in place.

Note: If you replace the Camera power supply,please press the button on the "Please refer to section" interface to add camera.

Add camera to the baby monitor

Baby Monitor and Baby Camera are paired by the factory, after powering, additional Baby Camera is required by the factory please using, please refer to the following steps:
① Add camera: Long press the [Talk] Button, the Monitor enters the pairing interface, and the Monitor will automatically search for the camera. Then the camera will enter the pairing mode automatically.
② Delete camera: Long press the [Talk] Button, select "Settings" select "Camera Settings" select "Camera Management" select "Delete Camera" and then confirm.
③ Switch view: Set your favorite camera as the main screen in the Monitor.

Note: If you replace the Camera power supply,please press the button on the "Please refer to section" interface to add camera.

Display mode of screen

When you are still more than one Baby Camera , you can manually switch the display screen of different Baby Camera.
Display Mode Switch Method:
① Manual switching:Long press the [Talk] Button, the main screen will display the Baby Camera in turn. Release the button when the display shows the one you want to view.
② Automatic switching:Short Press "Settings" select "Camera Settings" select "Camera Management" select "Switching Mode" and then confirm. Select a desired switching mode in the screenshot Baby Camera will be played automatically.

① Display all the same time: select "Camera Management" > Display mode > "Full screen" > "Save and Exit". ② Manual switch: Short press the [Talk] button to manually switch the camera at the same time.

Night Vision

When the [Sun] icon in the screenshot is illuminated, it means that the night vision function is turned on.

Night vision mode:
Under normal lighting conditions, it is color; in dark or no light environments, it is black and white. Lorem ipsum dolor sit amet, consectetur adipiscing elit, sed do eiusmod tempor incididunt ut labore et dolore magna aliqua. Ut enim ad minim veniam, quis nostrud exercitation ullamco laboris nisi ut aliquip ex ea commodo consequat. Duis aute irure dolor in reprehenderit in voluptate velit esse cillum dolore eu fugiat nulla pariatur. Excepteur sint occaecat cupidatat non proident, sunt in culpa qui officia deserunt mollit anim id est laborum.



① Keeping all the same time: select "Camera Management" > Display mode > "Full screen" > "Save and Exit". ② Manual switch: Short press the [Talk] button to manually switch the camera at the same time.

Monitor menu settings & more descriptions

Video Settings

VOX(Voice activation): Set up Baby Monitor VOX mode to open/close. If the noise is detected above your preset level after the VOX activation delay time (3/5/10 seconds), the screen will turn on and the unit will be in active monitoring.

Alarm Threshold: Optional: 1-5 gear. Monitor will only go

Sound Settings

Sound Alerts: Turn on/off the Baby Monitor's in-unit sound alerts.
Talk Volume: Adjust the volume from the talkback by pressing the volume buttons.
Mute: Activate/deactivate the Baby sleep. Select the desired activity. Press to adjust the volume by pressing the volume buttons.
Mute: Sound alerts are automatically disabled in the Standby Mode.
Warning: The sound notifications may not be heard by a hearing impaired baby.

Screen Settings

Flashing Sleeper Charging Other
Off / On: Turn on/off the LED flashing.

Description:
Flashing when charging the battery and the Number is off.
1. 0%-5%: Red, 6%-15%: Off, 16%-100%:Blue 2. Number blinking: Number after 10/15/20 S (VOX Power). Eg. Battery below 5%, the number will flash red for 10 seconds after the VOX Power. 3. Number Flash: Low and the duration is blinking in the form to enable mode.

System Settings

Camera Switching: Select the camera. Note: You can only pair 4 cameras to the unit.
Display Mode: Full Display: Static full screen, two split screen. Picture-in-Picture: Four split screen and one full screen.
Note: When activating the screen are momentarily disabled in the Standby Mode.
Warning: The sound notifications may not be heard by a hearing impaired baby.

Camera Settings

Night Vision Mode: Activate/ and close any optional.

When set the switch time, Camera automatically switches to night vision mode at the set time and switches to color mode at 7:00. Note: If the night vision mode is set to off, the Monitor's icon will not be displayed on the Monitor. The Camera remains in the night vision mode.

Camera Name: Set the name of the Baby monitor Numeric, letters and Symbols optional.

Temperature Unit: Optional: Fahrenheit °F and °C optional.

Camera Pairing: Pair the camera to the Baby Monitor. Please refer to the Pairing section for detailed instructions. Note: Only one camera can be paired to the Monitor at a time. To pair additional cameras, repeat the pairing process.

Factory Reset: Reset all settings to factory default setting.

Camera Installation Guide

How to Mount the Monitor on the Monitor to Display the Hardware Kit

Mounting Screws Pack

Mounting Screwdriver

Wall Mount

Power Adapter (for MC)

Power Adapter (for MC)

Power Adapter (for MC)

Power Adapter (for MC)

Power Adapter (for MC)

Warning

① Maximum power line impedance must not exceed 0.3Ω.
② Use only power supply with UL and CE mark.

① Do not use in a high-risk area, such as near a pool, or during a thunderstorm.
② Do not use in a high-temperature environment.

① Please keep the camera out of the reach of children. Many cords pose a strangulation hazard.
② Do not use the camera near flammable materials.

Certification

Certificate no.: E351961-20201202-001

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Exposure Warning Statements

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & body.

This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

End-users and installers must be provided with Antenna Installation Instructions and transmitter operating conditions for satisfying RF exposure compliance.

This equipment is operated in accordance with the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

-Consult the dealer or an experienced radio/TV technician for help.

-Installers must ensure that the antenna is located or oriented that it does not emit RF field in excess of Health Canada limits for the general population; consult Safety Code 6, obtainable from Health Canada's website www.hc-sc.gc.ca/rpb.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

(1) this device may not cause interference, and

(2) this device must accept any interference, including interference that may cause undesired operation of the device.

-Consult the dealer or an experienced radio/TV technician for help.

Declaration of conformity

Please use the standard Ctrl+Shift+ Page Up and Ctrl+Shift+ Page Down keyboard shortcuts to navigate between pages.

Hereby,Shenzhen Kawa Electronics Co.,Ltd declares that the radio equipment type Wireless Baby Monitor is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address: www.kawa-electronics.com

Manufacturer: Shenzhen Kawa Electronics Co.,Ltd

Email: support@kawa-tech.com

Web: www.kawa-tech.com

Address: 3rd Floor, Building 1, Fuhai Industrial Park, Shenzhen, China