USER'S MANUAL

PSX36

BLUETOOTH® | 36" AMPLIFIED SOUND BAR
FEATURES BUILT-IN CLASS A/B AMPLIFIER

Planet Audio

TABLE OF CONTENTS

INFORMATION TO THE USER ---------- 2
BEFORE YOU START ---------- 3
GETTING TO KNOW YOUR PSX36 ---------- 4
BLUETOOTH OPERATION ---------- 5
BLUETOOTH OPERATION ---------- 6
STREAMING MUSIC ---------- 7
AUX INPUT ---------- 8
USB INPUT ---------- 9
REMOTE CONTROL ---------- 10
INSTALLATION ---------- 11
TROUBLESHOOTING ---------- 12
WIRE DIAGRAM ---------- 13
SPECIFICATIONS ---------- 13

SUPPORT

For the latest information about this product please visit www.planetaudio.com

TECH SUPPORT:805-751-4854
www.planetaudio.com/customer-support

Please read thr

After you have

1- *PSX36* All-Terr

1- Mounting Kit

1- Power Accesso

1- Remote control

1- User Manual

1- Warranty Card

Bluetooth®

The Bluetooth® wor
Bluetooth SIG, Inc.
Other trademarks a

Thank you for purchasing this

Planet Audio®

PSX36 All-Terrain Sound System

rough these instructions carefully so you will know how to operate your model properly.

finished reading the instructions, keep this document in a safe place for future reference.

THIS PACKAGE CONTAINS

ain Speaker System



ory Extension Adaptor

USER MANUAL

WARRANTY CARD

INFORMATION TO THE USER

rd mark and logos are registered trademarks owned by and any use of such marks is under license.
nd trade names are those of their respective owners.

Planet Audio®

WARNING

Warning:
Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Statement:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.
These limits are designed to provide reasonable protection against harmful interference in a residential installation.
This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

Planet Audio®

BEFORE YOU START

IMPORTANT SAFETY PRECAUTIONS

- Do not operate mobile equipment while driving a motorized vehicle - safe driving and safety consideration of others should always be your highest priority.
- In the event you should notice smoke, strange noises or odor from this product, or any other abnormal signs, immediately turn off the power and consult your dealer or the nearest authorized ***Planet Audio*** Service Center. Using this product in this condition may result in permanent damage to the system.
- Set your volume control at a low setting, then slowly increase the sound until you can hear it comfortably without distortion, or ear discomfort.
- **BE SURE TO OBSERVE THE FOLLOWING GUIDELINES:**

- Do not turn up the volume so high that you can't hear what's around you.
- Use caution or temporarily discontinue use in potentially hazardous situations.

INSTALLATION PRECAUTIONS

WARNING - Always consult a professional installer

- Professional installation recommended. Do not attempt to service this product by yourself.
- Servicing of this product by persons without professional training and experience in electronic equipment and motorized vehicle accessories may be dangerous and could expose you to the risk of electric shock, Injury or other hazards.
- Contact Planet Audio for any installation, service questions or requests.
- The PSX36 can be powered from a vehicles cigarette lighter / auxiliary power port, or hard wired directly to the battery through an optional relay / accessory switch
- When wiring directly to the vehicles battery, be sure to disconnect the batteries negative terminal wire before starting any wiring procedures, it is suggested that an optional fuse and fuse holder (not included) with minimum rating of 15 Amps be in line with the positive battery terminal
- The ground cable length should not exceed 18-inches (See wiring diagram)
- The PSX36 has a weather resistant design, it should not be submerged in or under water under any circumstances
- Use only the installation parts provided with the PSX36
- Wash with a mild soap or detergent and lukewarm water using a clean sponge or a soft cloth. Rinse well with clean water.

"Don'ts" - Very Important

- DON'T clean in hot sun or on very hot days.
- DON'T use abrasive or highly alkaline cleaners on the main body
- DON'T scrape the main body with razor blades, or other sharp instruments
- DON'T ever use, gasoline, acetone or carbon tetrachloride

⚠ **CAUTION!!**
Using other mounting methods may void this warranty

Planet Audio®

GETTING TO KNOW YOUR PSX36



A	**Planet Audio PSX36**
1	**3.5mm AUX-INPUT**
2	**CIGARETTE POWER CABLE ADAPTOR**
3	**LED POWER INDICATOR**
4	**CONTROL PANEL**
5	**USB JACK**

BLUETOOTH OPERATION



PAIRING & DISCOVERING A NEW BLUETOOTH CONNECTION

1) Power on the ***PSX36*** by plugging in the male cigarette lighter adaptor into ② a female cigarette lighter receptacle.

2) Press the button ⑨ . The ***PSX36*** will automatically go in to pairing mode:

ANDROID users:

- a. Go into the ***Settings Menu*** of your device
- b. Enter the ***Bluetooth Menu***
- c. ***TURN ON Bluetooth*** and press ***SCAN***
- d. ***" Planet Audio PSX36"*** will now be displayed under ***AVAILABLE DEVICES***
- e. If prompted, enter passcode: ***"0000"***

iOS users:

- a. Go into the ***Settings Menu*** of your ***iOS*** device
- b. Enter the ***Bluetooth Menu***
- c. ***TURN ON Bluetooth***
- d. ***" Planet Audio PSX36"*** will now be displayed
- e. If prompted, enter passcode: ***"0000"***

NOTE: You have 2 minutes before you must restart this procedure over again.

3) If ***Planet Audio PSX36*** is not seen, repeat the above steps to refresh the ***"Device List"***

4) When the connection is successful, you are now ready to stream music from your favorite media player to the ***PSX36***

BLUETOOTH OPERATION



RECONNECTION

1) Power on the ***PSX36*** and your last paired ***Bluetooth device.***

2) Press the button ⑨ . The unit will now automatically reconnect

3) If your device was previously paired with the ***PSX36***, but it wasn't the last paired device:

- a. Ensure no other ***devices*** are currently paired
- b. Enter the ***Bluetooth Menu*** on your device being paired
- c. ***" Planet Audio PSX36"*** will display under ***AVAILABLE DEVICES***
- d. Choose the ***" Planet Audio PSX36"*** to reconnect

4) If the device is out of range from the ***PSX36*** , it will disconnect automatically:

- a. The ***PSX36*** will automatically reconnect to the device once back in range

Tips: **To avoid battery exhaustion, be sure to occasionally run the vehicles engine while using this product.**
Using this product without running the engine can drain the battery.

STREAMING MUSIC



MULTIFUNCTION CONTROLLER BLUETOOTH OPERATION

1) Press the ⑧ ***PLAY/PAUSE*** once to start playing music or press the ***PLAY*** button from your devices touchscreen
2) To skip songs or advance, press the ⑪ ***NEXT TRACK*** button
3) To select the previous song, press the ⑥ ***PREVIOUS TRACK*** button

VOLUME CONTROL

1) To raise the volume press the ⑩ ***VOLUME UP*** button or use your devices controls
2) To lower the volume press the ⑦ ***VOLUME DOWN*** button or use your devices controls

Tips: **For maximum audio performance, ensure your device Bluetooth volume is set to a minimum 75% level before stowing**

AUX INPUT



PSX36 can play audio from any device that has a 3.5mm headphone audio jack.

AUX-IN OPERATION

1) Power on the ***PSX36*** by plugging in the male cigarette lighter adaptor into ② a female cigarette lighter receptacle.
2) Press the button ⑨. Select ***AUX*** mode:
3) Connect the integrated 3.5mm ***AUX-IN*** cable ① to your devices headphone jack
4) Route the wire back to ***PSX36*** , and secure your device

VOLUME CONTROL

1) To raise the volume press the ⑩ ***VOLUME UP*** button or use your devices controls
2) To lower the volume press the ⑦ ***VOLUME DOWN*** button or use your devices controls

Tips: **For maximum audio performance, ensure your device headphone volume is set to a minimum 75% level before stowing**

USB INPUT



USB IN OPERATION

1) Power on the ***PSX36*** by plugging in the male cigarette lighter adaptor into ② a female cigarette lighter receptacle.
2) Insert the USB Flash drive on ⑤ and play the music automatically.
3) Press the ⑧ ***PLAY/PAUSE*** once to start playing music or pause
4) To skip songs or advance, press the ⑪ ***NEXT TRACK*** button
5) To select the previous song, press the ⑥ ***PREVIOUS TRACK*** button
6) To raise the volume press the ⑩ ***VOLUME UP*** button or use your devices controls
7) To lower the volume press the ⑦ ***VOLUME DOWN*** button or use your devices controls

Tips: USB can play music formats MP3 and WMA.
USB can provide 1A current.

REMOTE CONTROL



REMOTE CONTROL OPERATION

1) Remote control receiver window ⑬





REPLACEMENT BATTERY - CR2025

INSTALLATION

1) use the supplied adjustable bracket to secure to rails.

2) always recheck bracket before every ride



TROUBLESHOOTING

TROUBLE	CAUSE	SOLUTION
Unit will not turn on	The fuse is blown	Check / replace the fuse
	Main acc switch not engaged	Turn switch to on position
No sound is heard	Device volume is low / muted	Turn the volume level up
	Device is paused or muted	Check your devices playing / volume status
Cannot pair Bluetooth	The Bluetooth function of the device is not enabled	Refer to the user manual of the device for how to enable the Bluetooth function
The audio quality is poor after connection with a Bluetooth enabled device	The Bluetooth reception is poor	Move the device closer to the audio system or remove any obstacle between the device
Unit has become unresponsive	Power glitch or interference	Disconnect power for 10 seconds to reset

SUPPORT

For the latest information about this product please visit www.planetaudio.com

TECH SUPPORT:805-751-4854
www.planetaudio.com/customer-support

DIMENSIONS



WIRE DIAGRAM



SPECIFICATIONS

BLUETOOTH
- Version: 5.0 / EDR
- A2DP
- Range:33ft(10m)

SPEAKERS
- Dimensions: (6) 4" / 101.6mm
- Tweeter Size: (2) 1" Soft Dome

AMPLIFIER
- Class A/B
- Input impedance: 10k
- Frequency Response: 45Hz-22kHz

GENERAL
- Operational Power: 12VDC (10-16V allowable)
- MAX Current Draw: 10A
- Replacement Fuse: 15A AGC TYPE
- Color: Black
- Weight: 17.0 lbs / 7.7 Kg
- Dimensions mm WxHxD: 910x124x95
- Dimensions Inches WxHxD: 35.83x4.88x3.74

SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

Planet Audio®

USER'S MANUAL

PSX36

BLUETOOTH® | 36" AMPLIFIED SOUND BAR
FEATURES BUILT-IN CLASS A/B AMPLIFIER

www.planetaudio.com

TELEPHONE
805-751-4854 Customer Service

TECHNICAL SUPPORT
www.planetaudio.com/support

CE e1

0620