Tx. Spurious NVNT n40 2422MHz Ant1 Ref



Tx. Spurious NVNT n40 2422MHz Ant1 Emission



MKR	MODE	TRC	SCL	X	Y	FUNCTION	FUNCTION WIDTH	FUNCTION VALUE
1	N	1	f	2.434 4 GHz	-0.561 dBm			
2	N	1	f	26.286 5 GHz	-45.411 dBm			
3	N	1	f	4.948 1 GHz	-55.599 dBm			
4	N	1	f	7.266 0 GHz	-56.427 dBm			
5	N	1	f	9.861 0 GHz	-56.702 dBm			
6								
7								
8								
9								
10								
11								

Tx. Spurious NVNT n40 2422MHz Ant2 Ref



Tx. Spurious NVNT n40 2422MHz Ant2 Emission



MKR	MODE	TRC	SCL	X	Y	FUNCTION	FUNCTION WIDTH	FUNCTION VALUE
1	N	1	f	2.424 7 GHz	-0.923 dBm			
2	N	1	f	26.143 5 GHz	-46.133 dBm			
3	N	1	f	4.915 5 GHz	-56.114 dBm			
4	N	1	f	7.221 9 GHz	-55.927 dBm			
5	N	1	f	9.558 3 GHz	-56.539 dBm			
6								
7								
8								
9								
10								
11								

Tx. Spurious NVNT n40 2437MHz Ant1 Ref



Tx. Spurious NVNT n40 2437MHz Ant1 Emission



Tx. Spurious NVNT n40 2437MHz Ant2 Ref



Tx. Spurious NVNT n40 2437MHz Ant2 Emission



MKR	MODE	TRC	SCL	X	Y	FUNCTION	FUNCTION WIDTH	FUNCTION VALUE
1	N	1	f	2.428 2 GHz	-1.230 dBm			
2	N	1	f	25.622 1 GHz	-46.019 dBm			
3	N	1	f	4.965 8 GHz	-56.680 dBm			
4	N	1	f	7.289 0 GHz	-56.700 dBm			
5	N	1	f	9.566 3 GHz	-56.814 dBm			
6								
7								
8								
9								
10								
11								

Tx. Spurious NVNT n40 2452MHz Ant1 Ref



Tx. Spurious NVNT n40 2452MHz Ant1 Emission



MKR	MODE	TRC	SCL	X	Y	FUNCTION	FUNCTION WIDTH	FUNCTION VALUE
1	N	1	f	2.467 9 GHz	-0.494 dBm			
2	N	1	f	25.737 7 GHz	-45.869 dBm			
3	N	1	f	5.002 8 GHz	-55.882 dBm			
4	N	1	f	7.403 7 GHz	-55.933 dBm			
5	N	1	f	9.660 7 GHz	-56.675 dBm			
6								
7								
8								
9								
10								
11								

Tx. Spurious NVNT n40 2452MHz Ant2 Ref



Tx. Spurious NVNT n40 2452MHz Ant2 Emission



MKR	MODE	TRC	SCL	X	Y	FUNCTION	FUNCTION WIDTH	FUNCTION VALUE
1	N	1	f	2.454 7 GHz	0.571 dBm			
2	N	1	f	25.715 6 GHz	-46.134 dBm			
3	N	1	f	4.932 2 GHz	-55.733 dBm			
4	N	1	f	7.334 0 GHz	-55.609 dBm			
5	N	1	f	9.716 3 GHz	-56.754 dBm			
6								
7								
8								
9								
10								
11								

APPENDIX 2-PHOTOS OF TEST SETUP

Note: See test photos in setup photo document for the actual connections between Product and support equipment.

※※※※※END OF THE REPORT※※※※※