材质: 128G铜版纸单色印刷, 风琴折
尺寸: 98*140mm

1 2 3 4 封底

Table of Contents

1. Package Contents — 02
2. Button Configuration — 02
3. Connectivity — 03
4. Basic Operation — 04-05
5. Pairing Process — 06
6. TWS Pairing Process — 06
7. Modes and Functions — 07
8. Product Specification — 08
9. Care and Maintenance — 08

Thank you for purchasing your new GEARit Boombox Bluetooth Speaker. This user manual will help provide you with all the information needed to get started. Please read this manual carefully before using the product and reference it for later use.

Enjoy your new product.

Live it. Experience it. GEARit.

1. Package Contents



Bluetooth Speaker x 1 | USB-C Charge Cable x 1 | 3.5mm Cable x 1 | Shoulder Belt x 1 | User Manual x 1

2. Button Configuration



1. Power Button
2. RGB Modes
3. Play/Pause Answer/Refuse Calls
4. Volume+ /Next Track
5. TWS Status LED
6. Power Status LED
7. Input Switch / Activate Voice Assistant*
8. Bluetooth / TWS Button
9. Volume- / Previous Track
10. Bluetooth Status LED

*When paired to a mobile device.

3. Connectivity



1. USB-C Charging Port
2. 3.5mm Aux-In Port
3. 6.35mm MIC IN Port
4. TF/MicroSD Card Slot
5. USB-A Port

4. Basic Operation

Power Button
- x 2s — Turn ON/Turn OFF: Press and Hold 2s
- x 1 — Switch EQs: Press Once
  - One Prompt: Full-Range(Indoor EQ)
  - Two Prompts: Bass Plus (Bass Enhanced)
  - Three Prompts: Vocal (Outdoor EQ)
- x 8s — Product RESET: Press and Hold 8s to Reset When the Speaker Crashes

RGB Modes
- x 1 — Switch RGB Modes: Press Once
- x 2s — Turn OFF RGB Lighting: Press and Hold 2s

Input Switch
- x 2s — Switch Inputs: Press Once
  - Bluetooth > USB-A > MicroSD Card > Aux
- x 2s — Activate/Exit Voice Assistant: Press and Hold 2s

Play/Pause Button
- x 1 — Play/Pause: Press Once
- x 1 — Answer/Hang up a Call: Press Once
- x 2s — Reject a Call: Press and Hold 2s

Volume-
- x 1 — Turn Down Volume: Press Once
- x 2s — Previous Track: Press and Hold 2s

Volume+
- x 1 — Turn Up Volume: Press Once
- x 2s — Next Track: Press and Hold 2s

Pairing Button
- x 1 — Enter Bluetooth Pairing Mode: Press Once
- x 2s — Enter TWS Pairing Mode: Press and Hold 2s; Exit TWS Pairing Mode: Press and Hold 2s
- x 8s — Reset Connections: Press and Hold 8s

5. Pairing Process

1. Turn on the Bluetooth Speaker.
2. If the speaker reconnects to its last paired device automatically, press " " to enter Bluetooth pairing mode.
3. Activate Bluetooth on your device and search for "GEARit Boombox", tap to connect.

6. TWS Pairing Process

1. Ensure both speakers are not connected to any devices before pairing.
2. Power on both speakers. Press and hold the " " on either speaker to enter TWS mode. This speaker becomes the main unit (left channel), so place it on your left.
3. Once TWS pairing is done, the main speaker's white light will be solid, and the secondary speaker's white light will flash slowly. Blue light of main speaker is flashing, while the blue LED of the other is solid.
4. The secondary speaker is the right channel, so place it on your right.
5. Search for "GEARit Boombox" on your device's Bluetooth settings and connect to enjoy the stereo sound.

7. Modes and Functions

Power Bank Function

When the speaker is powered on, connecting a cable to its USB-A port enables emergency charging for your smartphone or other devices.

Aux/MicroSD Card/USB Drive Modes

In addition to Bluetooth mode, playback is also available via Aux, MicroSD card, and USB drive modes.

Automatic Power Off

The speaker will automatically turn off after 30 minutes of inactivity. (No connections with Bluetooth, MicroSD card, AUX cable, or USB drive).

Wired Karaoke Function

GEARit Boombox can be used as a karaoke speaker since it has a 6.35mm mic input.

8. Product Specification

Model	GI-SPKR-BT-BOOM-BK
Color	Black
Bluetooth Version	5.3
Frequency Range	65Hz - 20KHz
Input Power	5V/2A via USB-C Port
Battery Capacity	7.4V/4000mAh
Playback Time	Up to 12 Hours @ 65dB SPL
Charging Time	5 Hours

9. Care and Maintenance

- Do not use any form of detergents or cleaning materials to clean the product, as any type of chemical may make this device unusable.
- Do not disassemble this product. It contains no user serviceable parts.
- Do not drop the product or jump on it. Treat it with care for the best performance.
- Keep the product in a dry location. Dust, dirt, and moisture from humidity can accumulate on the body of the product.
- Do not dispose this product in fire, or batteries may leak or explode.

10. RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

GEARit LIMITED WARRANTY

Warranty Coverage:
We stand behind our products with confidence, offering warranties designed to give you peace of mind and a worry-free experience. Our commitment covers most GEARit products with specific exclusions, including those that have such as cables, cases, wall chargers, and more. Either warranty is protected from defects in materials and workmanship.
• Speakers (Bluetooth Products): 24 Months
30-Day Money-Back Guarantee:
You may return undamaged products within 30 days for a full refund. Products must include all accessories and original packaging. Shipping costs for non-quality-related returns are the responsibility of the Buyer.
Replacement Warranty:
If a defect arises within the warranty period, GEARit will repair, replace, or issue a credit for the product. Repaired or replacement products are covered for 90 days or the remainder of the original warranty, whichever is longer.
How to Contact?
For more information or to file a warranty claim, please visit GEARit's Warranty Support.
(https://www.gearit.com/pages/warranty-information)
(866) 658-9501
support@gearit.com
Mon – Fri: 9:00 AM – 5:30 PM (PST)
www.gearit.com

FCC Compliance Statement
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.

⚠ **WARNING:** This product can expose you to chemicals known to the State of California to cause cancer.
For more information, go to **www.P65Warnings.ca.gov.**

GEARit



Boombox Bluetooth Speaker
with RGB Lighting

GI-SPKR-BT-BOOM-BK
User Manual

5 6 7 8 封面

Poppins Bold /Poppins 字体