BLING BLING
TRUE WIRELESS EARBUDS

USER MANUAL

SMART-BLING-BLK, SMART-BLING-PNK, SMART-BLING-SVR

SPECIFICATIONS		CHARGING TIME	
Bluetooth:	Version5.4	Earbuds:	1-2 Hours
Operating Distance	15m/50ft	Charging Case:	2 Hours
Driver Unit:	13mm	Earbud Battery:	40mAh
Impedance	32Ω±15%@1KHz	Charging Case:	400mAh
Sensitivity:	118 ± 3 dB at 1KHz	Play Time	24 Hours
Frequency:	2.4-2.48 GHz	Data Interface:	Type-C

SAFETY & CARE INSTRUCTIONS

Do NOT expose any portion of this product to liquid, humidity, moisture, sharp objects or extreme temperatures as this can damage it and void the warranty.
Do NOT attempt to disassemble or modify the Earbuds or Charging Case in any way
Spot Clean ONLY.
The earbuds are sweat and water-resistant but should not be submerged into water as it will damage them.
Keep out of reach of children.
This product is not a toy.

RoHS CE UK CA

CONTENTS: 2 x Earbuds, 1 x Charging Case, 1 x Type C Charging Cable, 1 x Manual, Silicone Ear Tips

FC

CHARGING YOUR EARBUDS

1.Place each earbud into its charging slot and close the cover.
2.Use the charging cable provided and plug the other end into any USB charging port.
**To prevent damage, it is recommended to use the charging cable that is provided. Fully charge the charging case and earbuds before first use.

POWERING ON & OFF

1.Take the earbuds out from the case, they will automatically power on.
2.Place the earbuds back into the charging case, the earbuds will automatically power off.
3.To manually power off, press and hold button on either one of earbuds for 4-5 seconds.

BLUETOOTH PAIRING WITH YOUR DEVICE

1.Open the charging case, remove the earbuds & they will automatically power on and pair to each other, voice will prompt 'CONNECTED'. The right earbud will automatically connect to the left earbud.
2.Pairing mode will last for 2 minutes.While in pairing mode, turn ON the Bluetooth Connection on your device.

Scan/Search & select " ANC TOUCH ".
3.Once paired," ANC TOUCH" will voice prompt 'CONNECTED'.

Single Earbud Mode: When Bluetooth connected, you can use either Earbud of the earbuds only by putting the other one back into the charging case and closing the cover.

NOTE: Power on ANC TOUCH and they will automatically connect to the last connected device if available within the Bluetooth range.

EARBUD TAP-TOUCH FUNCTION GUIDE

NOTE: ANC TOUCH has a sensitive tap-touch feature. There is a multi-function touch button on each earbud.

L/R **ACTIVATE VOICE ASSISTANT** Tap 4 Times

L/R MODE Press & Hold For 2 Seconds

L/R **PREVIOUS SONG** Tap Twice

L/R **NEXT SONG** Tap 3 Times

L/R **PLAY/ PAUSE** Tap Once

L/R **ANSWER CALL** Tap Once

L/R **END CALL** Tap Once

L/R **REJECT CALL** Tap Twice

L/R **VOLUME DOWN** Slide Your Finger Down

L/R **VOLUME UP** Slide Your Finger Up

TOUCH SCREEN FUNCTIONAL GUIDE

Swipe From Left To Right To Start

Play, Pause, Skip Tracks, Track Title Display

Adjust Volume

Brightness Level

Select ANC & Ambient

Answer Calls

Adjust Equalizer Level

5,10 & 30 Min Quick Timer

Change Language

Find Lost Earbuds

Selfie Mode

Screen Turns White for Flashlight Mode

ACTIVATING NOISE CANCELLING MODE

When you take out earbuds from charging case, it is in the default, standard Bluetooth mode.

Press and hold for 2 seconds left or right earbud to enter TRANSPARENT MODE.

Press and hold for 2 seconds left or right earbud to enter ANC MODE.

Press and hold for 2 seconds left or right to go back to standard Bluetooth mode.

ANC MODE - multiple microphones work to cancel out up to 100% of noise for a truly immersive experience.

TRANSPARENT MODE - filters out most noise so you can still hear your surroundings

FCC ID : 2BKTL-BLNG01

FC

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

TECHNICAL SUPPORT & WARRANTY INFO

This product is backed by a One Year Warranty from any defects. For warranty replacements, questions or if you have any issues about this product, contact us at help@SimplyTechCorp.com.

SimplyTech Electronics Inc declared that radio equipment is compliant with Directives 2014/53/EU, 2011/65/EU & 2012/19/EU.

EU Declaration of Conformity for this product can be viewed at www.SimplyTech Corp.com/docs.

DISTRIBUTED BY: SimplyTech Electronics, Inc. 1407 Broadway New York, NY 10018
MADE IN CHINA

Please read before using this product and retain manual for future reference.