
MDS 4310 TRANSCEIVER
SET-UP & ADJUSTMENT POINTS