WKB-2388M
蓝牙键盘
说明书

注意：正确操作本产品，请仔细阅读用户手册。





支持系统

Win/iOS/Android

● iOS系统连接使用说明：

1.请打开键盘电源开关，蓝色灯亮起，选择通道，按Fn+C对码蓝灯闪烁进入对码模式。

2.打开“蓝牙”进入搜索模式。

3.直到发现“Bluetooth 5.1 Keyboard”，然后点击配对名连接。

4.提示连接配对成功，您就可以舒适地使用您的键盘了。

● Win 10 系统连接使用说明：

1.请打开键盘电源开关，蓝色灯亮起，选择通道，按Fn+C对码蓝灯闪烁进入对码模式。

2.打开设置，打开蓝牙，点击添加蓝牙或其他设备。

3.在添加设备里选择“ 蓝牙 ”进行搜索。

4.直到发现“Bluetooth 5.1 keyboard”，然后点击配对名连接。

5.提示连接成功，你就可以舒适地使用你的键盘了。

● Android系统连接使用说明：

1.请打开键盘电源开关，蓝色灯亮起，选择通道，按Fn+C对码蓝灯闪烁进入对码模式。

2.在开始页面打开“设置”，然后打开蓝牙，进行搜索模式。

3.直到发现“Bluetooth 5.1 Keyboard”，然后点击配对名连接。

4.提示连接配对成功，您就可以舒适地使用您的键盘了。

注：配对成功以后下次使用只需要打开蓝牙键盘电源及使用设备的蓝牙，蓝牙键盘将会自动搜索连接上次使用过的设备，不需要再进行配对操作。

产品功能

iOS/Android		Windows		Windows	
Fn+	对应功能	Fn+Shift	对应功能	Fn+	对应功能
~ Ф ` +Esc	返回桌面	~ Ф ` +Esc	主页	~ Ф ` +Esc	Esc
! 1 搜索	搜索	! 1 搜索	搜索	! 1 搜索	F1
@ 2 全选	全选	@ 2 全选	全选	@ 2 全选	F2
# 3 复制	复制	# 3 复制	复制	# 3 复制	F3
$ 4 粘贴	粘贴	$ 4 粘贴	粘贴	$ 4 粘贴	F4
% 5 剪切	剪切	% 5 剪切	剪切	% 5 剪切	F5
^ 6 上一曲	上一曲	^ 6 上一曲	上一曲	^ 6 上一曲	F6
& 7 暂停/播放	暂停/播放	& 7 暂停/播放	暂停/播放	& 7 暂停/播放	F7
* 8 下一曲	下一曲	* 8 下一曲	下一曲	* 8 下一曲	F8
(9 静音	静音	(9 静音	静音	(9 静音	F9
) 0 音量减小	音量减小	) 0 音量减小	音量减小	) 0 音量减小	F10
_ - 音量增大	音量增大	_ - 音量增大	音量增大	_ - 音量增大	F11
+ = 锁屏	锁屏	+ = 锁屏	锁屏	+ = 锁屏	F12

三系统切换语言：

Windows： Alt+Shift 切换语言　　iOS： Ctrl+空格键 切换语言

Android： Shift+空格键 切换语言

技术规格

键盘尺寸：270 x 101 x 11.9 mm (打开)
142 x 101 x 24 mm (折叠)

键盘重量：185 g

使用按键工作电流：< 3.0 mA

待机电流：< 1.0 mA

工作距离：8-10 m

休眠电流：< 20 μA

锂电池容量：90 mAh

休眠时间：10 分钟

工作电压：3.3-4.2 V

唤醒方式：按键唤醒

状态显示LED

- 对码：打开电源开关，蓝牙指示灯蓝灯亮起，按下对码键，蓝灯闪烁.
- 充电：指示灯红色，充满灯灭
- 低电压指示：当电压低于3.3V，红色指示灯闪烁.

多通道连接

- 连接第一个设备时，先按Fn+ ❶ ，再按Fn+C对码，开始连接.
- 连接第2个设备前，先按一次Fn+ ❷ ， 再按Fn+C对码，开始连接.
- 连接第3个设备前，先按一次Fn+ ❸ ， 再按Fn+C对码，开始连接.
- 在多个设备同时使用，按Fn+ ❶ / ❷ / ❸ 切换，即可自由切换到已连接的设备.

故障分析

请与售后服务人员联系

知识产权信息

未经本司的许可，禁止复制本用户手册的内容。

安全提醒

请不要打开或修理该设备，请不要在潮湿环境内使用设备，请用干布擦拭该设备。

质保条款

本设备自购买之日起，提供1年保修服务。

键盘保养

1、请勿将设备暴露在液体和潮湿的环境中或使其淋雨，请勿在浴缸、水槽、桑拿房、游泳池或蒸汽房附近使用。
2、请勿将设备暴露于过高或过低的温度下。
3、请勿长时间放置在阳光直射的地方。
4、请勿靠近明火，如烟灰缸、蜡烛或者壁炉。
5、避免使用锋利器物刮擦产品，及时给产品进行充电以保证正常使用。

常见问题解答

1、平板无法连接蓝牙键盘？

1）请先检查蓝牙键盘是否有进入配对状态。然后再打开平板电脑蓝牙搜索设备进行连接。

2）检查蓝牙键盘电量是否充足，电量不足也会导致无法连接，请将蓝牙键盘充电后再使用。

2、键盘指示灯在使用途中一直闪烁？

键盘指示灯在使用途中一直闪烁，表示电池即将没电，请尽快将键盘充电。

3、设备显示蓝牙键盘断开连接？

蓝牙键盘在一段时间内不使用，设备为了省电将自动关闭蓝牙功能，按键盘任意键唤醒，蓝牙连接自动恢复。

保修卡

用户填写资料

公司或个人全称 _____

通讯地址 _____

电话 _____　　邮编 _____

所购产品名称及型号 _____

购买日期 _____

本商品经检验合格予以下列质保期内的免费维修：
（1）整机零件、部件、组件及电路板因质量问题或损坏；
（2）整机或整机零件、部件及电路板因质量问题或损坏而造成的损坏；
（3）由使用所导致的非正常操作或保养造成的损坏；（包括使用电压、环境要求、保养方法、操作方法等）

注意事项

● Android Connection Instructions:

1.Please open the power switch, blue lights up. Select channel, press the Fn+C connect button, blue light twinkles.

2.Open the set up button at the starting interface and select "Bluetooth",then searching.

3. You will find the "Bluetooth 5.1keyboard " and click the pairing name to connect.

4.There is a tip for connecting successfully , you can use your keyboard comfortably .

Remarks：After connecting successfully the next time you don't need match code, just open the Bluetooth keyboard power switch and the tablet PC "Bluetooth." The BT keyboard will search the device and automatic connects.

● Win 10 Connection Instructions:

1.Please open the power switch, blue lights up. Select channel, press the Fn+C connect button, blue light twinkles.

2. Open settings, turn on Bluetooth, click Add Bluetooth or other devices.

3.Select "Bluetooth" in the Add Device to search.

4. You will find the "Bluetooth 5.1keyboard " and click the pairing name to connect.

5.There is a tip for connecting successfully , you can use your keyboard comfortably .

● iOS Connection Instructions:

1.Please open the power switch, blue lights up. Select channel, press the Fn+C connect button, blue light twinkles.

2.Open the tablet PC setting "Bluetooth" into searching and pairing status .

3.You will find the "Bluetooth 5.1 Keyboard"and click to next step .

4.There is a tip for connecting successfully ,you can use your keyboard comfortably .



Compatible System

Win /IOS /Android

WKB-2388M
Bluetooth 5.1 Keyboardd
User’s Manual

Note: Please read the user manual carefully before you start using this product

Warranty Card

User information

Company or personage full name

_____

Contact address _____

TEL _____　　Zip _____

The purchased product name and model NO.

_____

Purchased date _____

This reason due to the product broken and damage is not include on the warranty.
(1) accidents, misuse, improper operation, or any unauthorized maintenance, alteration, or disassembly.
(2) Improper installation or maintenance, violation of product instructions or improper connection of power during use.
(3) Or use consumables (such as spare batteries) that are not provided by the company but applicable laws Except where such restrictions are prohibited.

Certification
Customer name _____
Contact Phone _____

FAQ

1.The tablet PC can't connect the BT keyboard?

1） At first check the BT keyboard is into match code state, then open the table PC Bluetooth searching.

2） Checking the BT keyboard Battery is enough, the battery low is also lead to can't connect, you need charge.

2.The keyboard indication light always flashing when use?

Keyboard indication always flashing when use, is means the keyboard will be no power ,please charge the power as soon as possible.

3.The table PC display BT keyboard is disconnect?

The Bluetooth keyboard is not used for a period of time, the device will automatically enter the sleep state in order to save power. Press any key on the keyboard to wake up, and the Bluetooth connection will be automatically restored.

Troubleshooting

Please contact the after-sales service.

Copyright

It is forbidden to reproduce any part of this manual without the permission of seller.

Safety instructions

Do not open or repair this device. Do not use the device in a damp environment. Clean the device with a dry cloth.

Warranty

The device is provided with one-year limited hardware warranty from the purchase day.

Keyboard Maintenance

1.Please keep the keyboard away from liquid or humid environment, saunas, swimming pool, steam room and don't let the keyboard get wet in the rain.
2.Please don't expose the keyboard at too high or too low temperature condition.
3.Please don't put keyboard under sun for a long time.
4.Please don't put keyboard close to the flame, such as cooking stoves, candles or fireplace.
5. Avoid sharp objects scratching products, timely to recharge products to ensure the normal use.

Technical Specifications

Keyboard size: 270 x 101 x 11.9 mm (open)
142 x 101 x 24 mm (folding)

Weight：185 g

Key working current：< 3.0 mA

Standby current：< 1.0 mA

Working distance：8-10 m

Sleep current：< 20 μA

Lithium battery capacity：90 mAh

Sleep time：Ten minutes

Working voltage：3.3-4.2 V

Awaken way：Press key

Status Display LED

- Connect : Open the power switch, blue lights up, press the connect button,blue light twinkles.
- Charging : Indicator light will be on red, after fully charging, the light crush out.
- Low Voltage Indication : When the voltage is below 3.3 V, red light twinkles.

Multi-channel connection

- When connecting the first device, first press Fn+ ❶ and then press Fn+C to start the connection.
- Before connecting the second device, press Fn+ ❷ once, then press Fn+C to start the connection.
- Before connecting the third device, press Fn+ ❸ once, then press Fn+C to start the connection.
- To use multiple devices at the same time, press Fn + ❶ / ❷ / ❸ to switch to freely switch to connected devices.

Product features

iOS/Android		Windows		Windows	
Fn+	Corresponding function	Fn+Shift	Corresponding function	Fn+	Corresponding function
~ Ф ` +Esc	Return to Desk	~ Ф ` +Esc	Home Page	~ Ф ` +Esc	Esc
! 1 Search	Search	! 1 Search	Search	! 1 Search	F1
@ 2 Select	Select	@ 2 Select	Select	@ 2 Select	F2
# 3 Copy	Copy	# 3 Copy	Copy	# 3 Copy	F3
$ 4 Stick	Stick	$ 4 Stick	Stick	$ 4 Stick	F4
% 5 Cut	Cut	% 5 Cut	Cut	% 5 Cut	F5
^ 6 Pre-Track	Pre-Track	^ 6 Pre-Track	Pre-Track	^ 6 Pre-Track	F6
& 7 Play/Pause	Play/Pause	& 7 Play/Pause	Play/Pause	& 7 Play/Pause	F7
* 8 Next	Next	* 8 Next	Next	* 8 Next	F8
(9 Mute	Mute	(9 Mute	Mute	(9 Mute	F9
) 0 Volume-	Volume-	) 0 Volume-	Volume-	) 0 Volume-	F10
_ - Volume+	Volume+	_ - Volume+	Volume+	_ - Volume+	F11
+ = lock	lock	+ = lock	lock	+ = lock	F12

Three system switching languages

Windows： Alt+Shift　switch language

iOS： Ctrl+Space key　switch language

Android： Shift+Space key　switch language

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.