146-88 Pit Crew Radio
6 x 9 “



Hot Wheels

PIT CREW RADIO

FCC ID: NS6-14688-49

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Battery Warnings:

Only adult should replace batteries.
Use alkaline batteries recommended.
Do not use rechargeable batteries.
Non-rechargeable batteries are not to be recharged.
Do not mix old and new batteries.
Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
Only batteries of the same or equivalent type as recommended are to be used.
Batteries are to be inserted with the correct polarity.
Exhausted batteries are to be removed from the toy.
The supply terminals are not to be short-circuited.
Please keep this information for future reference.
Remove batteries from the product before extended storage.

1. Push the ON/OFF switch to ON position. The power indicator light will come on.
2. Place the ear bud into your ear carefully and adjust the microphone so that it is between 2in (5.1cm) and 3in (7.6cm) from your mouth. Adjust the ear holder to secure the walkie talkie to fit in your ear.
3. Press the “Push to talk” button to transmit when you speak into the microphone.
4. Release the “Push to talk” button when you have finished speaking.
5. Turn the ON/OFF switch to OFF position when you are not using the walkie talkie. The power indicator light will go out.

Antenna
Push To Talk
Power Indicator Light
On / Off
Battery Door
Ear Holder
Speaker
Microphone
USES 8 “AG13” BATTERY (INCLUDED) FOR TWO WALKIE TALKIE.

Complies with Toy Safety standard ASTM F963
MADE IN CHINA
Hot Wheels™ and associated trademarks and trade dress are owned by and used under license from, Mattel, Inc.
© 2011 Mattel, Inc. All Rights Reserved.

CONTENTS AND SPECIFICATIONS MAY VARY FROM THOSE ILLUSTRATED.
PLEASE RETAIN THIS INFORMATION FOR FUTURE REFERENCE.

ITEM / Model #: 14688

Distributed by:
DOLGENCORP, LLC
100 MISSION RIDGE
GOODLETTSVILLE, TN
37072-2170

97KF11

UPC: 400024718118

MADE IN CHINA F11