Service Provider:

Additional Information

This product is manufactured under licence to one or more of the patents of Qualcomm Incorporated, other patents pending.

4,901,307	5,416,797	5,566,357	5,627,857
5,056,109	5,426,392	5,568,483	5,629,955
5,099,204	5,442,627	5,572,172	5,629,975
5,101,501	5,452,473	5,574,773	5,633,881
5,103,459	5,461,639	5,576,662	5,638,412
5,107,225	5,469,115	5,577,022	5,640,414
5,109,390	5,475,870	5,577,025	5,642,398
5,228,054	5,479,475	5,581,575	5,644,591
5,257,283	5,485,486	5,588,043	5,644,596
5,265,119	5,487,175	5,590,069	5,646,991
5,267,261	5,490,165	5,590,406	5,652,599
5,267,262	5,497,395	5,590,408	5,654,979
5,283,536	5,499,280	5,592,481	5,655,220
5,289,527	5,504,773	5,592,548	5,657,420
5,307,405	5,506,865	5,594,718	5,666,122
5,309,474	5,509,015	5,596,570	5,673,259
5,339,046	5,511,067	5,600,754	5,675,644
5,341,456	5,511,073	5,602,833	5,687,229
5,373,259	5,528,593	5,603,096	5,689,557
5,383,219	5,544,196	5,604,730	5,691,974
5,392,287	5,546,459	5,617,060	5,692,006
5,396,516	5,561,618	5,621,784	
5,408,697	5,566,000	5,621,853	
5,414,796	5,566,206	5,625,876	

Fixed Access Unit (FAU)
## USER GUIDE

Globalstar.

System Overview

The Globalstar Fixed Access Unit (FAU) is a new type of radio terminal that allows you to make and receive telephone calls via Globalstar's satellite network. The FAU acts as an interface between the Globalstar satellite network and a locally connected telephone. This guide represents the FAU used in a residential application but is indicative of the other application configurations.

A diagram of the Globalstar network is shown below. Your local service provider will be able to advise you on the range of compatible devices

FAU Installation

Typical Network

Safety ⚠️

When using your telephone equipment basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons:

• Do not use the telephone near water.
• Avoid using the telephone (other than a cordless type) during an electrical storm.
• Do not use the telephone to report a gas leak in the vicinity of the leak.
• Do not attempt to modify your FAU installation or remove the FAU from it's mounting.
• Use only the power supply provided by your service provider to power the FAU.

Making a Call

	Lift telephone receiver.
	Listen for dial tone. *Note: If a busy tone is heard try again later.*
01234 567890 #	Dial the number required and finish with the # key. *Note: If an engaged tone is heard try again later.*
	Make call.
END	Hang up receiver to end call.

Receiving an Incoming Call

	Lift telephone receiver.
	Talk to caller
END	Hang up receiver to end call.

Do's and Don'ts

The following tips will help you find simple faults in your telephone system.
- Do wait to hear dial tone before dialling a telephone number.
- Do consider waiting a few minutes to make your telephone call if the line is busy.
- Do consult your local service provider/operator if you want to connect an extension telephone to the FAU
- Do follow the procedure below if the telephone line appears not to be working:
  - check that the power to the FAU is ON.
  - check that the telephone is properly plugged into the socket.
  - if the line is still not working switch the power to the FAU OFF and then switch the power ON again.
  - wait for 1 minute before attempting to make a new telephone call.
  - if the problem persists report it to your local service provider/operator.
- Don't use telephones with the FAU that have not been recommended by your local service provider/operator.
- Don't connect more than three phones to an FAU.
- Don't tamper with the FAU installation or use non-approved power supplies
- Don't allow objects to obstruct the FAU's view of the sky.