SUPPORT

Having Trouble? We're here to help.

For detailed product videos, manuals, and more, visit our support website: www.lacrossetechnology.com/support

Make sure you have your product's model number handy (**C80765**).

If you need additional support, get in touch with our friendly customer support team:

Online: bit.ly/contact_lacrosse
Phone Number: **1.877.658.2676**
Representatives are available Monday-Friday, 8:00am to 6:00pm CST

Trademarks & Warning

La Crosse Technology is not responsible for any damage or injury caused by the improper use of this unit or any items used in association with the accessory.

Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPhone, iPod, or iPad may affect wireless performance.

MFi, iPhone, iPod, iPod nano, iPod touch, iPod shuffle, iPod classic, Retina, Mac, Mac OS and OS X are trademarks of Apple Inc., registered in the U.S. and other countries.

The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by La Crosse Technology is under license. Other trademarks and trade names are those of their respective owners.

Qi is a trademark of the Wireless Power Consortium.

Samsung, Galaxy and Note are registered trademarks or trademarks of the respective companies.

Phone, charging accessories, and smart watch not included.

⚠ **WARNING: CHOKING HAZARD—Small Parts.** Not for children under 3 yrs.

Stay in Touch

Ask questions, watch set up videos, and provide feedback on our social media outlets.

Follow La Crosse Technology on Youtube, Facebook, Twitter, and Instagram.

LA CROSSE® TECHNOLOGY

Wattz⚡

- projection alarm
- wireless charger
- temperature & humidity

3-in-1 projection alarm clock

SET UP GUIDE

MODEL NUMBER **C80765**

Table of Contents

BASICS
Initial Setup 02
Buttons 03
LCD Display 04
Ports 04
LCD Display Brightness 05
Auto-Dim Settings 05
Display Modes 06
Display Mode Options 06

ALARM
Setting the Alarm 07
Activate/Deactivate 07
Snooze Duration 08

CHARGING
Charging Your Devices 11
Phone Compatibility 11
USB Charging Port 12

ADD-ON SENSOR
Purchase Information 13
ADD-On Sensor Setup 13
Lost Connection 14

MISC
Cable Organizer 16
Smart Watch Stand 16
Guest Watch Stand Storage 16

APPENDICES
Specifications 16
Warranty 17
Recycling & Disposal 17
Cautions/Statements 17-18

PROJECTION
Projection Brightness 09
Adjusting the Projection 09
Projection Image Options 10

SUPPORT
Support Information 19
Trademarks & Info 19
Stay in Touch 19

BASICS

Initial Setup

Power Up

Insert the 9V Power Adapter into an outlet, and then plug it into the Power Jack on the bottom of the alarm clock.

A greeting will appear on the LCD display and then your clock will move into the Settings Menu.

Settings Menu Order

12/24 Format → Hour → Minutes → Year → Month → Date → Fahrenheit/Celsius → Beep On/Off

Use the +/- buttons on the top of the clock to adjust the values.

Tap the ☐ button to confirm selection and move to next step.

You may exit the Settings Menu at any time by tapping the SNOOZE/BACKLIGHT button.

Note: Weekday will set automatically after year, month, & date settings are adjusted.

BASICS

Buttons



1. **DISPLAY OPTION**
Tap to select LCD display mode options

2. **ALARM**
Tap to activate/deactivate or hold to enter alarm settings

3. **SNOOZE/BACKLIGHT**
Tap to snooze sounding alarm, adjust backlight, or hold for Auto-Dim Settings

4. **ROTATION WHEEL**
Scroll to rotate the projection image (left or right)

5. **PROJECTION**
Tap to adjust projection intensity or hold to change projection mode*

6. **SET**
Hold to enter Settings Menu

7. **PLUS/MINUS (+/-)**
Tap to increase/decrease values, hold to change values quickly

* A sensor is required for additional projection options.

BASICS

LCD Display

Ports



Note: To enter the Settings Menu after the initial setup, hold the ☐ button on the top of the clock.

BASICS

LCD Display Brightness

Adjusting the LCD Display Brightness

Tap the SNOOZE/BACKLIGHT button on the top of the clock to adjust the backlight intensity. There are 4 brightness levels, plus an off option.

Auto-Dim Settings

Program your LCD display to automatically dim during preselected times.

1. Hold the SNOOZE/BACKLIGHT button to enter the Auto-Dim Settings Menu.
2. Tap the +/- buttons to turn the Auto-Dim feature on or off. Tap SNOOZE/BACKLIGHT to confirm.
3. Tap the +/- buttons to adjust the starting hour. Tap SNOOZE/BACKLIGHT to confirm.
4. Tap the +/- buttons to adjust the stopping hour. Tap SNOOZE/BACKLIGHT to confirm and exit.

The ☼ icon will appear on the LCD when activated.

BASICS

Display Modes

Selecting the Display Mode

Tap the ☐ button on the front of the clock to select a display mode or automatically cycle through all of the available options.

The Color Bars above the time on the LCD indicate the current display mode.

The ⟲ icon will appear on the LCD when the Cycle Mode Icon is active. The clock will automatically toggle through the available display mode options.

Display Mode Options

*Outdoor data requires an add-on sensor (sold separately). See page 13 for more information.

ALARM

Time Alarm

Setting the Alarm

1. Hold the 🔔 button on the top of the clock to enter the Alarm Settings Menu.
2. Use the +/- buttons to set your desired time. Tap 🔔 to confirm.
3. Next, use the +/- buttons to set your desired snooze duration (5 to 120 minutes). Tap 🔔 to confirm and exit the Alarm Settings Menu.
4. Your sound alarm is now activated, indicated by the 🔔 icon on the LCD.

Activating & Deactivating the Alarm

1. Tap the 🔔 button to activate/ deactivate the alarm and to view your alarm time.
2. The 🔔 icon will appear on the LCD when the alarm is active.

ALARM

Time Alarm

Crescendo Alarm

The alarm will increase in volume over 2 minute period. After the 2 minute time frame, the alarm will stop if not snoozed or turned off.

Example:



Based on 7:15am alarm time

Snooze Duration Countdown

When your alarm sounds, tap the SNOOZE/BACKLIGHT button to snooze for the preselected snooze duration. A countdown will appear on screen. When the snooze time reaches "00," the alarm will sound again. The snooze feature can be repeated as many times as desired.

PROJECTION

Adjusting the Projection Image

Tap the ☼ button to adjust the projection's brightness (HI/LOW/OFF).

The Projection Arm tilts forwards and backwards to adjust the location of the projection image.

Use the Rotation Wheel on the top of the Projection Arm to rotate viewing angle of the image.

Note: The fixed focus projection image will look best at about 7ft. (2.1m).

PROJECTION

Projection Options

Projection Image Options

You can choose to see the (1) time, (2) outdoor temperature and humidity, or (3) cycle through both options (indicated by the ⟲ icon on the LCD). Outdoor weather information is only available if an add-on sensor is connected.

Selecting Your Projection Image

1. When an outdoor sensor is connected, hold the ☼ button on the top of the clock to toggle between the projection options. If no sensor is connected, this button will only adjust the projection's brightness.
2. Time will be the default projection image. Hold and release the ☼ button each time to switch between projection modes. The Color Bar on the display will indicate your current selection.

Note: A sensor is required for outdoor information. If no sensor is connected, the projection will only show current time.

CHARGING

5W Wireless Charger

Charging your Qi-Enabled Phone

- Place your Qi-Enabled phone on the platform. Your phone should be centered and should sit flush to the charging cradle.
- The blue Charging Indicator Light below the LCD will illuminate when your phone is successfully charging.
- The light will flash slowly if your device is not positioned properly or if your device is not compatible with the Qi wireless charging technology. If this problem persists, try removing any bulky/pulsy cases.

Phone Compatibility

Works with all Qi-Enabled phones, such as:

- iPhone X Series
- iPhone 8 Plus / 8
- Galaxy S8+ / S8
- Galaxy Note 8

Compatibility may vary based on phone model and/or case selection. This list is not comprehensive. Please check your phone's manual for details regarding Qi-enabled capabilities.

CHARGERS

USB Charging Port

There is a 1 Amp USB Charging Port located on the left side of your alarm clock.

- Connect your external device's USB charging cable (not included) into the USB Charging Port.
- Charging times may vary.
- USB Power Output: 1 Amp maximum current

Magnetic Cable Organizer

Use the included Cable Organizer to keep your charging cables neat and secure. The inset magnetic square on back of dock ensures a snug and secure fit.

Charging Cables Not Included

ADD-ON SENSOR

Optional Add-On Sensor

You can purchase an add-on Thermo-Hygro Sensor to get real-time temperature and humidity data, straight from your backyard!

Purchase Your Add-On Sensor at (or scan QR Code) **www.lacrossetechnology.com/sensor-finder**

Search for the compatible sensor using the alarm clock's model number (**C80765**).

Add-On Sensor Set Up

1. Insert 2 "AA" Batteries into the sensor battery compartment.
2. Hold the + button on the clock to search for the sensor.
3. Press the TX button inside the sensor battery compartment to transmit a signal.

The sensor's data should now be viewable on your LCD Display and/or as an option for your Projection Image.

ADD-ON SENSOR

Optional Add-On Sensor

Lost Connection

- If the sensor loses connection to the clock for any reason, the clock will show NO after 30 minutes of disconnection. This will appear in both the Outdoor Temperature & Humidity Display Modes.

- The Sensor Reception Icon 📶 will disappear from the bottom right of the LCD and the clock will search for up to 6 minutes every hour to try to reestablish the connection.
- To manually reconnect, hold the + button on the top of the clock to search for the sensor.
- Display will show while searching or the sensor and the 📶 icon will flash for up to 3 minutes or until the sensors connected.

Low Battery

The 🔋 icon will appear when the sensor batteries needs to be replaced.

MISC

Smart Watch Stand

The removable Smart Watch Stand is engineered to fit a variety of smart watch brands. Its open design allows for easy access to your device's unique charging port location, for use with the included USB Charging Port.

How to attach the Smart Watch Stand

The open design the Apple Watch charger (not included).

How to store the Smart Watch Stand

The Smart Watch Stand can be stored in the integrated storage compartment on the bottom of the clock when not in use.

APPENDIX

Specifications



Power Requirements: **5.0V Power Cord** (included) FW3-0502500-AU-001

Projection Brightness: **3 Intensity Levels + OFF**

LCD Brightness: **4 Intensity Levels + OFF** (Programmable Auto-Dim Backlight Option)

Wireless Charger Power Output: **5 Watts**

USB Charging Port: **1 Amp Maximum Current** (Charging Cord Not Included)

Programmable Snooze Duration
5 to 120 Minutes

Indoor Temperature Range:
32°F to 122°F (0°C to 50°C)

Indoor Humidity Range: **10% to 99% RH**

Settings Backup: **The alarm clock will keep its settings for 6 minutes in the event it loses power.**

Factory Reset: **If you're experiencing issues with your station, use a pen or paper clip to press the factory reset button on the left side of your clock.**

APPENDIX

Warranty

La Crosse Technology, Ltd. provides a 1-year limited (mo) warranty (from date of purchase) on this product, relating to its manufacturing defects in materials and workmanship.

For full warranty details, you can visit: www.lacrossetechnology.com/support

La Crosse Technology, Ltd · 2809 S. 29th Street · La Crosse, WI 54601

Recycling & Disposal

Please consider the environment when deciding to dispose of this product. Recycling is the preferred option, but generally safe to use as a daily basis. Incorrect disposal can cause negative and potentially irreversible impacts on our environment.

Check with local disposition centers to see if your product can be donated for future use. If disposal is the only option, federal agencies, local governments, and certified retailers may have electronic recycling programs in place. Programs may vary based on location.

Please Recycle

Caution!

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such changes or modifications could void the user authority to operate the equipment.

All rights reserved. This manual may not be reproduced in any form, even in part, or duplicated or processed using electronic, machine-read or chemical processes without the written consent of the publisher.

This manual was created with great care and thoroughness. The information it contains is regularly checked and corrections are included in subsequent editions. We disclaim any responsibility for any technical error or printing error, or their consequences. All trademarks and plants are recognized.

APPENDIX

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Canada Statement

This device complies with CNR Industry Canada license-exempt devices.

Operation is subject to the following two conditions: (1) This device may not cause interference and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

California Residents

⚠ **WARNING**

This product can expose you to chemicals including styrene, which is known to the State of California to cause cancer.

For more information, go to www.P65Warnings.ca.gov

Designed in La Crosse, Wisconsin · Made in China · Printed in China · **DC 062018**