autec
safety remote control



AJS label and its dimension

(under the battery)

AJS label position