


FJM label and its dimension




*(under the battery)*

FJM label position